

ABB machinery drives

Supplement

ACS355 enhanced sequence program (+N830)



Power and productivity
for a better world™

ABB

List of related manuals

Drive manuals and guides	Code (English)
ACS355 user's manual	3AUA0000066143
ACS355 drives with IP66/67 / UL Type 4x enclosure supplement	3AUA0000066066
ACS355 quick installation guide	3AUA0000092940
ACS355 common DC application guide	3AUA0000070130
ACS355 enhanced sequence program (+N830) supplement	3AXD50000017465
Option manuals and guides	
FCAN-01 CANopen adapter module user's manual	3AFE68615500
FDNA-01 DeviceNet adapter module user's manual	3AFE68573360
FECA-01 EtherCAT® adapter module user's manual	3AUA0000068940
FENA-01/-11 Ethernet adapter module user's manual	3AUA0000093568
FLON-01 LonWORKS® adapter module user's manual	3AUA0000041017
FMBA-01 Modbus adapter module user's manual	3AFE68586704
FPBA-01 PROFIBUS DP adapter module user's manual	3AFE68573271
FRSA-00 RS-485 adapter board user's manual	3AFE68640300
MFDT-01 FlashDrop user's manual	3AFE68591074
MPOT-01 potentiometer module instructions for installation and use	3AFE68591082
MREL-01 output relay module user's manual	3AUA0000035974
MTAC-01 pulse encoder interface module user's manual	3AFE68591091
MUL1-R1 installation instructions for ACS150, ACS310, ACS320, ACS350 and ACS355	3AFE68642868
MUL1-R3 installation instructions for ACS310, ACS320, ACS350 and ACS355	3AFE68643147
MUL1-R4 installation instructions for ACS310, ACS320, ACS350 and ACS355	3AUA0000025916
SREA-01 Ethernet adapter module quick start-up guide	3AUA0000042902
SREA-01 Ethernet adapter module user's manual	3AUA0000042896
ACS355 and AC500-eCo application guide	2CDC125152M0201
AC500-eCo PLC and ACS355 quick installation guide	2CDC125145M0201

Maintenance manuals and guides

Guide for capacitor reforming in ACS50, ACS55, ACS150, 3AFE68735190
ACS310, ACS350, ACS355, ACS550, ACH550 and R1-R4 OINT/SINT boards

You can find manuals and other product documents in PDF format on the Internet. See section [Document library on the Internet](#) on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

Supplement

ACS355 enhanced sequence program (+N830)

Table of contents



Table of contents

1. Introduction to the supplement

What this chapter contains	7
Safety	7
Scope	7
Applicability	8
Target audience	8
Purpose of the manual	8
Contents of this supplement	9
Related documents	9
Quick start-up flowchart	10
Terms and abbreviations	10

2. Control panels

What this chapter contains	11
About control panels	11
Applicability	11
Set sequence program parameters	13
Monitor sequence program signals	13



3. Application macros

What this chapter contains	15
Overview of macros	15
Summary of the I/O connections of the application macros	17

4. Program features

What this chapter contains	19
Enhanced sequence program	19
Settings	21
State shifts	22
Example 1	24
Example 2	25
External control	29
Start, stop, direction source for External Control	29
Reference source for External Control	29
Programmable analog inputs	29
Settings	30
Programmable analog output	30
Settings	30
Programmable digital inputs	30
Settings	31
Programmable relay output	32
Settings	32

Transistor output	32
Settings	32
Actual signals	32
Acceleration and deceleration ramps	33
Settings	33
Supervisions	33
Settings	34
Real-time clock and timed functions	34
Settings	34
User parameter set change	34
Settings	35
Counter	35
Counter position functions	35
Settings	36
Position control example 1	37
Position control example 2	43

5. Actual signals and parameters

What this chapter contains	49
Terms and abbreviations	49
Actual signals	50
Parameters	52



1

Introduction to the supplement

What this chapter contains

The chapter describes safety issues, scope of this supplement, applicability, target audience and purpose of this supplement. It describes the contents of this supplement and refers to a list of related manuals for more information. The chapter also contains a Quick start-up flow chart which can be followed when commissioning.

Safety

Safety related instructions please refer to *ACS355 user's manual* (3AUA0000066143 [English]). The safety instructions must be followed when installing, operating and servicing the drive. Please study the complete safety instructions carefully.

Scope

This document is supplement of *ACS355 user's manual* (3AUA0000066143 [English]). This supplement covers all differences between enhanced sequence program and sequence program in ACS355 standard firmware. Only the enhanced sequence program contents are given in each chapter of this supplement.

8 Introduction to the supplement

Following chapters please refer to *ACS355 user's manual* (3AUA0000066143 [English]):

- Operation principle and hardware description
- Mechanical installation
- Planning the electrical installation
- Electrical installation
- Installation checklist
- Startup, control with I/O and ID run
- Fieldbus control with fieldbus adapter
- Fault tracing
- Maintenance and hardware diagnostics
- Technical data
- Appendixes

Applicability

The manual is applicable to the ACS355 enhanced sequence program firmware version 6.200 or later. See parameter 3301 *FIRMWARE*. Option code +N830 in the drive type code shows that the drive has the enhanced sequence program installed.

Target audience

This supplement is intended for people who work with ACS355 enhanced sequence program. The reader of this supplement is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

Purpose of the manual

This manual provides information needed for commissioning, operating and maintaining the ACS355 enhanced sequence program.

Contents of this supplement


The supplement consists of the following chapters:

- *Introduction to the supplement* (this chapter, page 7) describes safety issues, scope of supplement, applicability, target audience and purpose of this manual. It also contains a quick start-up flowchart.
- *Control panels* (page 11) describes different control panels, interfaces to adjust sequence program parameters and monitoring related actual values.
- *Application macros* (page 15) describes the application macros. Overview of macros shows suitable application of each macros. Default function of each I/O is also shown in section summary of I/O connections of the application macros.
- *Program features* (page 19) describes program features. There are also lists of related user settings in each section.
- *Actual signals and parameters* (page 49) describes the actual signals and parameters related to sequence program and gives the fieldbus equivalent values for each signal/parameter. It also contains a table of the default values for the different macros.
- *Further information* (inside of the back cover) tells how to make product and service inquiries, get information on product training, provide feedback on ABB Drives manuals and how to find documents on the Internet.

Related documents

See *List of related manuals* on page 2 (inside of the front cover).

Quick start-up flowchart



Terms and abbreviations

Term/abbreviation	Explanation
SEQ PROG	Sequence program

Other terms and abbreviations please refer to *ACS355 user's manual* (3AUA0000066143 [English]).

2

Control panels

What this chapter contains

The chapter describes different control panels compatible with ACS355 enhanced sequence program firmware, applicability panel versions and parameters or signals in enhanced sequence program which can be set or monitored using control panels.

About control panels

Use a control panel to control the ACS355 enhanced sequence program, read sequence status data, and adjust sequence program parameters. The drive works with one of following control panel types:

- Basic control panel – This panel (described in chapter control panels of *ACS355 user's manual* (3AUA0000066143 [English])) provides basic tools for manual entry of parameter values.
- Assistant control panel – This panel (described in section Assistant control panel on page 89 of *ACS355 user's manual* (3AUA0000066143 [English])) includes pre-programmed assistants to automate the most common parameter setups. The panel provides language support. It is available with different language sets.

Basic operations of Basic control panel and Assistant control panel please refer to the *ACS355 User's manual* (3AUA0000066143 [English]).

Applicability

The supplement is applicable to panels with the panel revisions and the panel firmware versions given in the table below.

Panel type	Type code	Panel revision	Panel firmware version
Basic control panel	ACS-CP-C	M or later	1.13 or later
Assistant control panel	ACS-CP-A	F or later	2.04 or later

12 Control panels

Panel type	Type code	Panel revision	Panel firmware version
Assistant control panel (Asia)	ACS-CP-D	Q or later	2.04 or later

To find out the panel revision, see the label on the back of the panel. An example label and explanation of the label contents are shown below.



1	Panel type code
2	Serial number of format YYYYWWRXXXX, where M: Manufacturer YY: 09, 10, 11, ... for 2009, 2010, 2011, ... WW: 01, 02, 03, ... for week 1, week 2, week 3, ... R: A, B, C, ... for panel revision XXXX: Integer starting every week from 0001
3	RoHS mark (the label of your drive shows the valid markings)

To find out the panel firmware version of your assistant control panel or basic control panel, please refer to chapter Control panels of *ACS355 User's manual* (3AUA0000066143 [English]).

See parameter 9901 LANGUAGE in *ACS355 User's manual* (3AUA0000066143 [English]) to find out the languages supported by the different assistant control panels.

■ Set sequence program parameters

Following related parameter groups in enhanced sequence program can be set with control panel:

- 10 START/STOP/DIR, 22 ACCEL/DECEL parameters.
- 11 REFERENCE SELECT parameters.
- 13 ANALOG INPUTS, 14 RELAY OUTPUTS, 15 ANALOG OUTPUTS, 18 FREQ IN & TRAN OUT parameters.
- 19 TIMER & COUNTER, 36 TIMED FUNCTIONS parameters.
- 32 SUPERVISION parameters.
- 84 SEQUENCE PROG, 85 SEQUENCE PROG2 parameters.

How to set sequence program parameters

Information about setting parameters using different control panels please refer to the chapter Control panels of *ACS355 User's manual* (3AUA0000066143 [English]).

■ Monitor sequence program signals

Following related signals can be selected as monitored signals in control panel:

- 0167 SEQ PROG STS
- 0168 SEQ PROG STATE
- 0169 SEQ PROG TIMER
- 0170 SEQ PROG AO VAL
- 0171 SEQ CYCLE CNTR
- 0190 POS STATUS
- 0192 COUNTER VALUE HI
- 0193 COUNTER VALUE LO
- 0194 SPEED ACT POS

How to select the monitored signals

Information about selecting the monitored signals please refer to the chapter Control panels of *ACS355 User's manual* (3AUA0000066143 [English]).

3

Application macros

What this chapter contains

The chapter describes the application macros available in ACS355 enhanced sequence program. Overview of macros shows suitable application of each macros. Default function of each I/O is also shown in section summary of I/O connections of the application macros.

Overview of macros

Basic information of application macros please refer to the chapter application macros of *ACS355 User's manual* (3AUA0000066143 [English]).

The ACS355 enhanced sequence program has seven macros and three user macros. Summary of following macros and suitable applications please refer to the chapter application macros of *ACS355 User's manual* (3AUA0000066143 [English]) and the table below.

Macro	Suitable applications
ABB standard	Ordinary speed control applications where no, one, two or three constant speeds are used. Start/stop is controlled with one digital input (level start and stop). It is possible to switch between two acceleration and deceleration times.
3-wire	Ordinary speed control applications where no, one, two or three constant speeds are used. The drive is started and stopped with push buttons.
Alternate	Speed control applications where no, one, two or three constant speeds are used. Start, stop and direction are controlled by two digital inputs (combination of the input states determines the operation).
Motor potentiometer	Speed control applications where no or one constant speed is used. The speed is controlled by two digital inputs (increase / decrease / keep unchanged).

16 Application macros

Macro	Suitable applications
Hand/Auto	Speed control applications where switching between two control devices is needed. Some control signal terminals are reserved for one device, the rest for the other. One digital input selects between the terminals (devices) in use.
Torque control	Torque control applications. It is possible to switch between torque and speed control: Some control signal terminals are reserved for torque control, others for speed control. One digital input selects between torque and speed control.
AC500 Modbus	Applications that require a complex control logic and when several drives are connected together through a Modbus link. AC500-eCo PLC is used for controlling and monitoring the system.
User	The user can save the customized standard macro, ie the parameter settings including group 99 START-UP DATA, and the results of the motor Identification run into the permanent memory, and recall the data at a later time. For example, three user macros can be used when switching between three different motors is required.

Note: In Start-up assistant, the PID assistant can not be used because all related PID functions has been removed in ACS355 enhanced sequence program firmware.

Summary of the I/O connections of the application macros

The following table gives the summary of the default I/O connections of all application macros available in ACS355 enhanced sequence program. All of the I/O mapping diagrams of each macro please refer to *ACS355 User's manual* (3AUA0000066143 [English]).

4

Program features

What this chapter contains

The chapter describes ACS355 enhanced sequence program features. There are also lists of related user settings in each section. Other standard program features please refer to chapter Program features in *ACS355 user's manual* (3AUA0000066143 [English]).

Control program introduction

Enhanced sequence program extends number of sequence states from 8 to 16. Together with counter positioning control function, the drive can be applied to more complicated applications, such as Stocker Machine and simple Crane applications. More state triggers and logic values are added, please refer to the related parameter list in chapter [Actual signals and parameters](#). Detailed introduction and settings for each related sequence program function please refer to each section below.

Note: STx TRIG TO ST N2 and STx N2 are added to states 1-16. STx TRIG TO ST N3/4 and STx N3/4 are added to state 9 and 10.

Note: For State 8, parameter 8495 ST8 TRIG TO ST 1 remains the same function as in ACS355 standard firmware. Parameter 8510 ST8 TRIG TO ST9 is added as a new parameter in ACS355 enhanced sequence program.

Enhanced sequence program

The drive can be programmed to perform a sequence where the drive shifts typically through 1...16 states. User defines the operation rules of the whole sequence for each state. The rules of a particular state are effective when the Sequence program is active and the program has entered the state. The rules to be defined for each state are:

- Run, stop, direction commands for the drive
- Acceleration and deceleration ramp time for the drive
- Source for the drive reference value
- State duration
- RO/DO/AO status
- Signal source for triggering the shift to the next state
- Signal source for triggering the shift to any state (1...16)
- Counter reset state out control

Every state can also activate drive outputs to give an indication to external devices.

Enhanced sequence program allows state transitions either to the next state or to state N/N2/N3/N4 (State N3/N4 only available for state 9 and 10). State change can be activated with e.g. timed functions, digital inputs and supervision functions. For state 8, enhanced sequence program also allows both state transition to state 1 and state 9.

Enhanced sequence program allows definition of User Macro change state and User Macro selection.

Enhanced sequence program can be applied in simple mixer applications as well as in more complicated traverse applications. Together with counter function this can be applied in positioning control applications as well as in some simple crane applications.


The enhanced sequence program can be implemented with control panel or a PC tool. The drive is supported by version 2.94 or later of the DriveWindow Light 2 PC tool which includes a graphical Sequence program tool supporting 16 sequence program states.


Note: By default all Sequence program parameters can be changed even when the Sequence program is active. It is recommended that after the Sequence program parameters are set, parameters are locked with parameter [1602 PARAMETER LOCK](#). Related parameters are listed in table below:

■ Settings

Parameter	Additional information
1001/1002	Start, stop and direction commands for EXT1/EXT2
1102	EXT1/EXT2 selection
1103/1106	REF1/2 source
1401, 1402, 1403, 1410	Sequence program output through RO 1/2/3/4
1501	Sequence program output through AO
1601	Run enable activation/deactivation
1605	User parameter set change by sequence program
1805	Sequence program output through DO
Group 19 TIMER & COUNTER	State change according to counter limit
2201...2207	Acceleration/deceleration and ramp time settings
Group 32 SUPERVISION	Supervision settings
Group 36 TIMED FUNCTIONS	Timed state change
Group 84 SEQUENCE PROG	Sequence program settings
Group 85 SEQUENCE PROG2	

State shifts






*Trigger priority: Trigger to N4 > N3 > N2 > N > Next.

**Trigger to state N3 and N4 are only available in state 9 and 10.

***State 8 trigger to state 1 has lowest priority.

Example 1



Sequence program is activated by digital input DI1.

ST1: Drive is started in reverse direction with -50 Hz reference and 10 s ramp time.
State 1 is active for 40 s.

ST2: Drive is accelerated to 20 Hz with 60 s ramp time. State 2 is active for 120 s.


ST3: Drive is accelerated to 25 Hz with 5 s ramp time. State 3 is active until the Sequence program is disabled or until booster start is activated by DI2.

ST4: Drive is accelerated to 50 Hz with 5 s ramp time. State 4 is active for 200 s and after that the state shifts back to state 3.

Parameter	Setting	Additional information
1002 EXT2 COMMANDS	SEQ PROG	Start, stop, direction commands for EXT2
1102 EXT1/EXT2 SEL	EXT2	EXT2 activation
1106 REF2 SELECT	SEQ PROG	Sequence program output as REF2
1601 RUN ENABLE	NOT SEL	Deactivation of Run enable
2102 STOP FUNCTION	RAMP	Ramp stop
2201 ACC/DEC 1/2 SEL	SEQ PROG	Ramp as defined by parameter 8422/.../8452.
8401 SEQ PROG ENABLE	ALWAYS	Sequence program enabled
8402 SEQ PROG START	DI1	Sequence program activation through digital input (DI1)
8404 SEQ PROG RESET	DI1(INV)	Sequence program reset (ie reset to state 1, when DI1 signal is lost (1 -> 0))

ST1		ST2		ST3		ST4		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8420 ST1 REF SEL	100%	8430	40%	8440	50%	8450	100%	State reference
8421 ST1 COMMANDS	START REV	8431	START FRW	8441	START FRW	8451	START FRW	Run, direction and stop command
8422 ST1 RAMP	10 s	8432	60 s	8442	5 s	8452	5 s	Ramp time
8424 ST1 CHANGE DLY	40 s	8434	120 s	8444		8454	200 s	State change delay
8425 ST1 TRIG TO ST 2	CHANGE DLY	8435	CHANGE DLY	8445	DI2	8455		State change trigger
8426 ST1 TRIG TO ST N	NOT SEL	8436	NOT SEL	8446	NOT SEL	8456	CHANGE DLY	
8427 ST1 STATE N	-	8437	-	8447	-	8457	STATE 3	

Example 2



Drive is programmed for traverse control with 30 sequences.

Sequence program is activated by digital input DI1.

ST1: Drive is started in forward direction with AI1 (AI1 + 50% - 50%) reference and ramp pair 2. State shifts to the next state when reference is reached. All relay and analog outputs are cleared.

ST2: Drive is accelerated with AI1 + 15% (AI1 + 65% - 50%) reference and 1.5 s ramp time. State shifts to the next state when reference is reached. If reference is not reached within 2 s, state shifts to state 8 (error state).

ST3: Drive is decelerated with AI1 + 10% (AI1 + 60% - 50%) reference and 0 s ramp time¹⁾. State shifts to the next state when reference is reached. If reference is not reached within 0.2 s, state shifts to state 8 (error state).

ST4: Drive is decelerated with AI1 - 15% (AI1 + 35% -50%) reference and 1.5 s ramp time. State shifts to the next state when reference is reached. If reference is not reached within 2 s, state shifts to state 8 (error state).²⁾

ST5: Drive is accelerated with AI1 -10% (AI1 + 40% -50%) reference and 0 s ramp time¹⁾. State shifts to the next state when reference is reached. Sequence counter value is increased by 1. If sequence counter elapses, state shifts to state 7 (sequence completed).

ST6: Drive reference and ramp times are the same as in state 2. Drive state shifts immediately to state 2 (delay time is 0 s).

ST7 (sequence completed): Drive is stopped with ramp pair 1. Digital output DO is activated. If Sequence program is deactivated by the falling edge of digital input DI1, state machine is reset to state 1. New start command can be activated by digital input DI1 or by digital inputs DI4 and DI5 (both inputs DI4 and DI5 must be simultaneously active).

ST8 (error state): Drive is stopped with ramp pair 1. Relay output RO is activated. If Sequence program is deactivated by the falling edge of digital input DI1, state machine is reset to state 1. New start command can be activated by digital input DI1 or by digital inputs DI4 and DI5 (both inputs DI4 and DI5 must be simultaneously active).

¹⁾ 0 second ramp time = drive is accelerated/decelerated as rapidly as possible.

²⁾ State reference must be between 0...100%, ie scaled AI1 value must be between 15...85%. If AI1 = 0, reference = 0% + 35% -50% = -15% < 0%.

Parameter	Setting	Additional information
1002 EXT2 COMMANDS	SEQ PROG	Start, stop, direction commands for EXT2
1102 EXT1/EXT2 SEL	EXT2	EXT2 activation
1106 REF2 SELECT	AI1+SEQ PROG	Sequence program output as REF2
1201 CONST SPEED SEL	NOT SEL	Deactivation of constant speeds
1401 RELAY OUTPUT 1	SEQ PROG	Relay output RO 1 control as defined by parameter 8423/.../8493
1601 RUN ENABLE	NOT SEL	Deactivation of Run enable
1805 DO SIGNAL	SEQ PROG	Digital output DO control as defined by parameter 8423/.../8493
2102 STOP FUNCTION	RAMP	Ramp stop
2201 ACC/DEC 1/2 SEL	SEQ PROG	Ramp as defined by parameter 8422/.../8452.
2202 ACCELER TIME 1	1 s	Acceleration/deceleration ramp pair 1
2203 DECELER TIME 1	0 s	
2205 ACCELER TIME 2	20 s	Acceleration/deceleration ramp pair 2
2206 DECELER TIME 2	20 s	
2207 RAMP SHAPE 2	5 s	Shape of the acceleration/deceleration ramp 2
3201 SUPERV 1 PARAM	171	Sequence counter (signal 0171 SEQ CYCLE CNTR) supervision
3202 SUPERV 1 LIM LO	30	Supervision low limit
3203 SUPERV 1 LIM HI	30	Supervision high limit
8401 SEQ PROG ENABLE	EXT2	Sequence program enabled
8402 SEQ PROG START	DI1	Sequence program activation through digital input (DI1)
8404 SEQ PROG RESET	DI1(INV)	Sequence program reset (ie reset to state 1, when DI1 signal is lost (1 -> 0))
8406 SEQ LOGIC VAL 1	DI4	Logic value 1
8407 SEQ LOGIC OPER 1	AND	Operation between logic value 1 and 2
8408 SEQ LOGIC VAL 2	DI5	Logic value 2
8415 CYCLE CNT LOC	ST5 TO NEXT	Sequence counter activation, ie sequence count increases every time the state changes from state 5 to state 6.
8416 CYCLE CNT RST	STATE 1	Sequence counter reset during state transition to state 1


ST1		ST2		ST3		ST4		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8420 ST1 REF SEL	50%	8430	65%	8440	60%	8450	35%	State reference
8421 ST1 COMMANDS	START FRW	8431	START FRW	8441	START FRW	8451	START FRW	Run, direction and stop commands
8422 ST1 RAMP	-0.2 (ramp pair 2)	8432	1.5 s	8442	0 s	8452	1.5 s	Acceleration/deceleration ramp time
8423 ST1 OUT CONTROL	R=0,D=0 ,AO=0	8433	AO=0	8443	AO=0	8453	AO=0	Relay, digital and analog output control
8424 ST1 CHANGE DLY	0 s	8434	2 s	8444	0.2 s	8454	2 s	State change delay
8425 ST1 TRIG TO ST 2	ENTER SETPNT	8435	ENTER SETPNT	8445	ENTER SETPNT	8455	ENTER SETPNT	State change trigger
8426 ST1 TRIG TO ST N	NOT SEL	8436	CHANG EDLY	8446	CHANG EDLY	8456	CHANG EDLY	
8427 ST1 STATE N	STATE 1	8437	STATE 8	8447	STATE 8	8457	STATE 8	

ST5		ST6		ST7		ST8		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8460 ST5 REF SEL	40%	8470	65%	8480	0%	8490	0%	State reference
8461 ST5 COMMANDS	START FRW	8471	START FRW	8481	DRIVE STOP	8491	DRIVE STOP	Run, direction and stop commands
8462 ST5 RAMP	0 s	8472	1.5 s	8482	-0.1 (ramp pair 1)	8492	-0.1 (ramp pair 1)	Acceleration/deceleration ramp time
8463 ST5 OUT CONTROL	AO=0	8473	AO=0	8483	DO=1	8493	RO=1	Relay, digital and analog output control

ST5		ST6		ST7		ST8		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8464 ST5 CHANGE DLY	0.2 s	8474	0 s	8484	0 s	8494	0 s	State change delay
8465 ST5 TRIG TO ST6	ENTER SETPNT	8475	NOT SEL	8485	NOT SEL	8495	LOGIC VAL	
8466 ST5 TRIG TO ST N	SUPRV1 OVER	8476	CHANG E DLY	8486	LOGIC VAL	8496	NOT SEL	State change trigger
8467 ST5 STATE N	STATE 7	8477	STATE 2	8487	STATE 1	8497	STATE 1	

External control

ACS355 enhanced sequence program can only works in External control mode (Remote control). External control is indicated with REM on the panel display, see picture below. Using LOC/REM panel key, user can switch to External control.



Both two external control locations, EXT1 or EXT2 can be used for sequence program. Depending on the user selection, either one is active at a time. This function operates on a 2ms time level.

Start, stop, direction source for External Control

In order to use enhanced sequence program, Start, stop, direction source should be set for sequence program by setting parameters [1001/1002](#) to SEQ PROG.

Reference source for External Control

In order to use enhanced sequence program, Reference source of EXT1/EXT2 should be set for sequence program by setting parameters [1103/1106](#) to SEQ PROG.

Programmable analog inputs

Two programmable analog inputs can be set for references of enhanced sequence program. Related parameters are listed in table below:

■ Settings

Parameter	Additional information
Group 13 ANALOG INPUTS	Analog input processing
8420, 8425, 8426, 8428 8520, 8525, 8526, 8528 8430, 8435, 8436, 8438 8530, 8535, 8536, 8538 ... 8490, 8495, 8496, 8498 8590, 8595, 8596, 8598 8510, 8512, 8514, 8516, 8518	AI as Sequence program reference or trigger signal
8406, 8408, 8410	AI as SEQ logic value 1-3 signal source
8501, 8503, 8505	AI as SEQ logic2 value 1-3 signal source

Programmable analog output

One programmable current output (0...20 mA) is available. Analog output can be controlled with enhanced sequence program by setting parameter [1501 AO1 CONTENT SEL](#) to any related SEQ PROG values:

- [0167 SEQ PROG STS](#)
- [0168 SEQ PROG STATE](#)
- [0169 SEQ PROG TIMER](#)
- [0170 SEQ PROG AO VAL](#)
- [0171 SEQ CYCLE CNTR](#)

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
Group 15 ANALOG OUTPUTS	AO value selection and processing
8423, 8433, ..., 8493 8523, 8533, ..., 8593	AO control with Sequence program

Programmable digital inputs

The drive has five programmable digital inputs which can be programmed as control source of enhanced sequence program. Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
8402 SEQ PROG START	DI as SEQ start signal source
8403 SEQ PROG PAUSE	DI as SEQ pause signal source
8404 SEQ PROG RESET	DI as SEQ reset signal source
8406, 8408, 8410	DI as SEQ logic value 1-3 signal source
8501, 8503, 8505	DI as SEQ logic2 value 1-3 signal source
8416 CYCLE CNT RST	DI as cycle counter reset signal source
8420, 8430, 8440, 8450,..., 8490	DI as SEQ reference Mot.Pot control source
8520, 8530, 8540, 8550,..., 8590	
8425, 8435, 8445,..., 8485, 8510 8525, 8535, 8545, 8555,..., 8595	DI as SEQ state trig to next state signal source
8426, 8436, 8446, 8456,..., 8496 8526, 8536, 8546, 8556,..., 8596	DI as SEQ state trig to STN signal source
8428, 8438, 8448, 8458,..., 8498 8528, 8538, 8548, 8558,..., 8598	DI as SEQ state trig to STN2 signal source
8512, 8516	DI as SEQ state trig to STN3 signal source
8514, 8518	DI as SEQ state trig to STN4 signal source
8595 ST8 TRIG TO ST1	DI as ST8 trig to ST1 signal source

Programmable relay output

Relay output can be controlled by enhanced sequence program. The relay output control must be activated by setting parameter [1401 RELAY OUTPUT 1](#), [1402 RELAY OUTPUT 2](#), [1403 RELAY OUTPUT 3](#) or [1410 RELAY OUTPUT 4](#) to SEQ PROG.

Note: Extended relay output 2-4 (which is extended by MREL-01) can also be controlled by enhanced sequence program. They must be activated by setting [1402 RELAY OUTPUT 2](#), [1403 RELAY OUTPUT 3](#) or [1410 RELAY OUTPUT 4](#) to SEQ PROG.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
Group 14 RELAY OUTPUTS	RO value selections and operation times
8423 / 8433 /.../ 8493 8523 / 8533 /.../ 8593	RO control with Sequence program

Transistor output

The drive has one programmable transistor output can be controlled by enhanced sequence program. The transistor output must work as digital output by setting parameter [1805 DO SIGNAL](#) to SEQ PROG.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
Group 18 FREQ IN & TRAN OUT	Transistor output settings
8423 / 8433 /.../ 8493 8523 / 8533 /.../ 8593	Transistor output control with Sequence program

Actual signals

Several related actual signals in enhanced sequence program are available:

- Active control location (EXT1 or EXT2)
- Reference values
- Digital I/O, Relay output and Analog I/O status
- COMM Value 1/2
- SEQ status parameters

Actual signals used for position control are also available:

- Position control status word
- 32-bits counter value
- Scaled position speed actual value

Three signals can be shown simultaneously on the assistant control panel display (one signal on the basic control panel display). It is also possible to read the values through the serial communication link or through the analog outputs.

Acceleration and deceleration ramps

Two groups of user-selectable acceleration and deceleration ramps are available in ACS355 enhanced sequence program, same as in standard FW. Enhanced sequence program also offers additional ramp time for each state.


S-curve only effect on the two groups of user-selectable acceleration and deceleration ramps, doesn't effect additional ramps.

Note: Default value of Par.2102 STOP FUNCTION is changed to be RAMP in enhanced sequence program.

Related parameters are listed in the table below:

Settings

Parameter	Additional information
Group 22 ACCEL/DECEL	Acceleration and deceleration ramp settings
8422/8432/.../8492 8522/8532/.../8592	Ramp settings of each sequence program states



Supervisions

Supervision status can be used as state change trigger signal and logic calculation value source in enhanced sequence program. Supervision status available are listed below:

- SUPRV1 OVER/UNDER: Supervision 1 over/under
- SUPRV2 OVER/UNDER: Supervision 2 over/under
- SUPRV3 OVER/UNDER: Supervision 3 over/under

Related parameters are listed in the table below:

■ Settings

Actual signal	Additional information
Group 32 <i>SUPERVISION</i>	Supervision parameter settings
8425, 8426 / 8435, 8436 /.../8495, 8496, 8498 8525, 8526 / 8535, 8536 /.../8595, 8596 8510,8512/8514/8516/8518	Sequence program state change according to supervision functions
8406, 8408, 8410	Logic value source of sequence program
8501, 8503, 8505	Logic2 value source of sequence program

Real-time clock and timed functions

The real-time clock can be used as state change trigger signal and also logic calculation value source in enhanced sequence program.

For more information, see section **Real-time clock and timed functions** in ACS355 user's manual (3AUA0000066143 [English]).

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
36 <i>TIMED FUNCTIONS</i>	Timed functions settings
8402 <i>SEQ PROG START</i>	Timed Sequence program activation
8425, 8426 / 8435, 8436 /.../8495, 8496, 8498 8525, 8526 / 8535, 8536 /.../8595, 8596 8510,8512/8514/8516/8518	Sequence program state change trigger with timed function
8406, 8408, 8410	Logic value source of sequence program
8501, 8503, 8505	Logic2 value source of sequence program

User parameter set change

Enable the change of the User parameter set through enhance sequence program. The sequence programming of User parameter set change is activated by setting parameter *1605 USER PAR SET CHG* to *SEQ PROG*.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
1605 <i>USER PAR SET CHG</i>	Timed functions settings

Parameter	Additional information
8406 MACRO CHG ST	Sequence program state change the User Parameter set.
8407 USER MACRO SEL	The User Macro is selected by the sequence programming.

Counter

■ Counter position functions

Counter function is rebuilt to fulfill simple position control requirements. The counter target value can be used as state command and the counter value can be reset by out control in sequence program.

After counter function is enabled, both DI5 and Encoder can be selected as counter pulse source. If PLS IN(DI5) is selected, DI5 directly gives the pulse signal to the counter. If Filtered DI5 is selected, pulse is given from filtered digital input DI5 as counter pulse source. If ENC W/O DIR is selected, pulse is given from encoder module but the direction of the motor is not considered. If ENC WITH DIR is selected, the counter goes up/down according to the direction of motor.

The following values are extended from 16 bits to 32 bits value (HI and LO value in two parameters):

- Counter actual value HI/LO
- Counter reset value HI/LO
- Counter limit value HI/LO

Selecting MOTOR DIR of [1910 COUNT DIRECTION](#) makes it is possible to count up/down with motor rotation direction. The value of counter will be increased when the direction of rotation is forward and will be decreased when the direction of rotation is reverse.


The counter can be reset by sequence program. The following conditions are added for counter reset:

- SEQ PROG: Sequence program state resets counter. Three counter reset conditions can be selected in state's out control, such as RST CNT ENT (reset counter when the state is entered), RST CNT STNX (reset counter when current state trigger to STNx) and RST CNT NEXT (reset counter when current state trigger to next state).
- SEQ OR DI1-5: Sequence program state or DI 1-5 resets counter.
- SEQ OR CV1#0-7: Sequence program state or COMM VALUE 1 (Par.0135) resets counter.


When DI5 is used as the counter input source, [1927 DI5 PPR](#) is preset the number of pulse per one revolution.

In enhanced sequence program, [1921 POS CORRECT](#) is used for positioning fine tuning parameter which is multiplied by actual speed.

Four target positions can be preset in Target A/B/C/D HI/LO VALUE parameters. In enhanced sequence program, the state command can be given as TARGET A/B/C/D and drive runs towards target automatically. Motor rotation direction follows the current position and target position.



In the following ranges, Target window defines that the “At target X” status(0190 POS STATUS) is true. Similarly, Slowdown window defines that the “Slowdown X” status is true. The “At target X” and “Slowdown X” can also be used as the trigger signal of state change in enhanced sequence program.



Counter numeration and denomination are used instead of counter divider. The following formula shows how counter value is calculated:

$$\text{counter val.} = \text{old val.} + \text{addition val.} * \frac{\text{COUNTER NUM}}{\text{COUNTER DEN}}$$

The counter function can also be used as the trigger signal of state change in enhanced sequence program. See section [Settings](#) on page 36.


Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
1001, 1002	Start/Stop signal sources
Group 19 TIMER & COUNTER	Counter for start and stop, reset sources, limit/reset value, target value, target/slowdown window, numeration/denomination, pos correct, DI5 PPR.

Parameter	Additional information
8421 , 8431, 8441, 8451/.../8491, 8521, 8531, 8541, 8551/.../8591	Target X as the state command.
8423, 8433, 8443, 8453/.../8493, 8523, 8533, 8543, 8553/.../8593	Reset counter by the sequence program state out control.
8425 , 8426 / 8435, 8436 /.../8495, 8496, 8498 8525, 8526 / 8535, 8536 /.../8595, 8596 8510, 8512/8514/8516/8518	Sequence program state change trigger with counter function

Position control example 1




Encoder is installed in motor and connected to MTAC-01.

Sequence programming is activated by digital input DI1.

Counter value indicates the current position. Firstly, counter value is reset to 0 as the initial position.

Counter catches both rising and falling edge of the signals from phase A and phase B (shows in the picture below). So if parameter [5001 PULSE NR](#) is set to 1024, the counter will receive 4096 pulses per one revolution. If parameter [1929 COUNTER DEN](#) is set to 4096, the counter will count up/down 1 during one revolution, that is, counter will calculate the numbers of revolution.



Initial motor position (counter value) is reset to 0.

ST1: Drive is started toward Target A (forward direction) with 25Hz reference and 5s ramp time. State1 is activated until reaches the range of Target A slowdown window, and then shifts to State 2 (ST1 STATE N2).

ST2: Drive runs toward Target A (forward direction) with 5Hz reference and 2s ramp time. State 2 shifts to state 3 (ST2 STATE N) when the position value reaches the range of target A window.

ST3: Drive is stopped with ramp pair 1 and shifts to state 4 (ST3 STATE N2) after 5s delay.

ST4: Drive runs toward Target B (forward direction) with 25Hz reference and 5s ramp time. State 4 is activated until reaches the range of Target B slowdown window, and then shifts to State 5 (ST4 TRIG TO ST 5).

ST5: Drive runs toward Target B (forward direction) with 5Hz reference and 3s ramp time. State 5 shifts to state 6 (ST5 TRIG TO ST 6) when the position value reaches the range of target B window.

ST6: Drive is stopped with ramp pair 2 and shifts to state 7 (ST6 STATE N2) after 5s delay.

ST7: Drive runs toward Target C (reverse direction) with 30Hz reference and 5s ramp time. State 7 shifts to state 8 (ST7 STATE N) when the position value reaches the range of target C slowdown window.

ST8: Drive runs toward Target C (reverse direction) with 5Hz reference and 2s ramp time. State 8 is activated until reaches the range of target C window, and then shifts to State 9 (ST8 STATE N2).

ST9: Drive is stopped with 2s ramp time and shifts to state 10 (ST9 TRIG TO ST10) after 5s delay.

ST10: Drive runs toward Target D (reverse direction) with 25Hz reference and 2s ramp time. State 10 shifts to state 11 (ST10 STATE N2) when the position value reaches the range of target D slowdown window.

ST11: Drive runs toward Target D (reverse direction) with 5Hz reference and 2s ramp time. State 11 shifts to state 12 (ST11 STATE N) when the position value reaches the range of target B window.

ST12: Drive is stopped with 2s ramp time. Counter is reset. After 5s delay, state 12 shifts to state 1 (ST12 STATE N).

Parameter	Setting	Additional information
1001 EXT1 COMMANDS	SEQ PROG	Start, stop, direction commands for EXT1
1102 EXT1/EXT2 SEL	EXT1	EXT1 activation
1103 REF1 SELECT	SEQ PROG	Sequence program output as REF1
1201 CONST SPEED SEL	NOT SEL	Deactivation of constant speeds
1401 RELAY OUTPUT 1	SEQ PROG	Relay output RO 1 control as defined by parameter 8423 .../8493,8523/.../8593
1601 RUN ENABLE	NOT SEL	Deactivation of Run enable



1805 DO SIGNAL	SEQ PROG	Digital output DO control as defined by parameter 8423 .../8493,8523/...8593
1904 COUNTER ENABLE	ENABLED	Counter enable signal
1906 COUNTER INPUT	ENC W/O DIR	Selects encoder as the input signal source.
1907 COUNTER RESET	SEQ PROG	Set the reset source to the sequence programing
1910 COUNT DIRECTION	MOTOR DIR	Counter direction by the motor direction.
1912 TAR A HI VALUE	0	Setting the Target A value
1913 TAR A LO VALUE	500	
1914 TAR B HI VALUE	0	Setting the Target B value
1915 TAR B LO VALUE	1000	
1916 TAR C HI VALUE	0	Setting the Target C value
1917 TAR C LO VALUE	600	
1918 TAR D HI VALUE	0	Setting the Target D value
1919 TAR D LO VALUE	0	
1920 TAR WINDOW ST	10	Defines the size of positioning status target window
1921 POS CORRECT	100%	Defines positioning fine tuning parameter
1922 SLOWDOWN WINDOW	100	Defines the size of positioning status target slowdown window
1928 COUNTER NUM	1	Defines the multiplier (numerator) for the pulse counter
1929 COUNTER DEN	4096	Defines the divider (denominator) for the pulse counter
2102 STOP FUNCTION	RAMP	Ramp stop
2201 ACC/DEC 1/2 SEL	SEQ PROG	Ramp as defined by parameter 8422 .../8492,8522/..8492.
2202 ACCELER TIME 1	5 s	Acceleration/deceleration ramp pair 1
2203 DECELER TIME 1	5 s	
2205 ACCELER TIME 2	10 s	Acceleration/deceleration ramp pair 2
2206 DECELER TIME 2	10 s	
5001 PULSE NR	1024	The number of encoder pulses per one revolution
5002 ENCODER ENABLE	ENABLE	Enable the encoder
8401 SEQ PROG ENABLE	EXT1	Sequence program enabled
8402 SEQ PROG START	DI1	Sequence program activation through digital input (DI1)
8404 SEQ PROG RESET	DI1(INV)	Sequence program reset (ie reset to state 1, when DI1 signal is lost (1 -> 0)

ST1		ST2		ST3		ST4		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8420 ST1 REF SEL	50%	8430	10%	8440	0%	8450	50%	State reference
8421 ST1 COMMANDS	TARGET A	8431	TARGET A	8441	DRIVE STOP	8451	TARGET B	Run, direction, stop, Target X commands
8422 ST1 RAMP	5 s	8432	2 s	8442	-0.1 (ramp pair 1)	8452	5 s	Acceleration/deceleration ramp time
8423 ST1 OUT CONTROL	AO=0	8433	AO=0	8443	AO=0	8453	AO=0	Relay, digital and analog output control
8424 ST1 CHANGE DLY	0 s	8434	0 s	8444	5 s	8454	0s	State change delay
8425 ST1 TRIG TO ST 2	NOT SEL	8435	NOT SEL	8445	NOT SEL	8455	SLOWD OWN B	State change trigger
8426 ST1 TRIG TO ST N	NOT SEL	8436	AT TARGET A	8446	NOT SEL	8456	NOT SEL	
8427 ST1 STATE N	STATE 1	8437	STATE 3	8447	STATE 1	8457	STATE 1	
8428 ST1 TRIG TO STN2	SLOWD OWN A	8438	NOT SEL	8448	CHANG E DLY	8458	NOT SEL	
8429 ST1 STATE N2	STATE 2	8439	STATE 1	8449	STATE 4	8459	STATE 1	

ST5		ST6		ST7		ST8		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8460 ST5 REF SEL	10%	8470	0%	8480	60%	8490	10%	State reference
8461 ST5 COMMANDS	TARGET B	8471	DRIVE STOP	8481	TARGET C	8491	TARGET C	Run, direction, stop, Target X commands
8462 ST5 RAMP	3 s	8472	-0.2 (ramp pair 2)	8482	5 s	8492	2 s	Acceleration/deceleration ramp time
8463 ST5 OUT CONTROL	AO=0	8473	AO=0	8483	AO=0	8493	AO=0	Relay, digital and analog output control
8464 ST5 CHANGE DLY	0 s	8474	5 s	8484	0 s	8494	0 s	State change delay
8465 ST5 TRIG TO ST6	AT TARGET B	8475	NOT SEL	8485	NOT SEL	8495	NOT SEL	
8466 ST5 TRIG TO ST N	NOT SEL	8476	NOT SEL	8486	SLOWD OWN C	8496	NOT SEL	
8467 ST5 STATE N	STATE 1	8477	STATE 1	8487	STATE 8	8497	STATE 1	
8468 ST5 TRIG TO ST N2	NOT SEL	8478	CHANGE DLY	8488	NOT SEL	8498	AT TARGET C	State change trigger
8469 ST5 STATE N2	STATE 1	8479	STATE 7	8489	STATE 1	8499	STATE 9	

ST9		ST10		ST11		ST12		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8520 ST9 REF SEL	0%	8530	50%	8540	10%	8550	0%	State reference
8521 ST9 COMMANDS	DRIVE STOP	8531	TARGET D	8541	TARGET D	8551	DRIVE STOP	Run, direction, stop, Target X commands
8522 ST9 RAMP	2 s	8532	2 s	8542	2 s	8552	2s	Acceleration/deceleration ramp time
8523 ST9 OUT CONTROL	AO=0	8533	AO=0	8543	AO=0	8553	RST CNT ENT	Relay, digital and analog output control
8524 ST9 CHANGE DLY	5 s	8534	0 s	8544	0 s	8554	5 s	State change delay
8565 ST9 TRIG TO ST10	CHANGE DLY	8535	NOT SEL	8545	NOT SEL	8555	NOT SEL	
8526 ST9 TRIG TO ST N	NOT SEL	8536	NOT SEL	8546	AT TARGET D	8556	CHANGE DLY	
8527 ST9 STATE N	STATE 1	8537	STATE 1	8547	STATE 12	8557	STATE 1	
8528 ST9 TRIG TO ST N2	NOT SEL	8538	SLOWDOWN D	8548	NOT SEL	8558	NOT SEL	State change trigger
8529 ST9 STATE N2	STATE 1	8539	STATE 11	8549	STATE 1	8559	STATE 1	

Position control example 2



DI5 is used as the counter input source. If there is a pulse during one motor revolution, parameter [1927 DI5 PPR](#) will be set to 1.

Sequence programming is activated by digital input DI1. The number of pulses captured from DI5 indicates the position value (counter value). The initial motor position (counter value) is reset to 0.

ST1: Stopped state. The counter value is reset by out control. State1 shifts to State2 (ST1 TRIG TO ST2) when DI2 is activated; State1 shifts to State9 (ST1 STATE N) when DI2 is inactivated.

ST2: Drive accelerates to 40Hz in forward direction with 5s ramp time. State2 shifts to State3 (ST2 TRIG TO ST3) when the counter value reaches [3203 SUPERV 1 LIM HI](#).

ST3: Drive decelerates to 10Hz in forward direction with 5s ramp time. State3 shifts to State4 (ST3 TRIG TO ST4) when the counter value reaches [3209 SUPERV 3 LIM HI](#).

ST4: Drive stops with 0.1s ramp time. When DI3 is activated, State4 shifts to state5 (ST4 TRIG TO ST5) after 10s delay time.

ST5: Drive accelerates to 50Hz with 5s ramp time in reverse direction. State5 shifts to state6 (ST5 TRIG TO ST6) when the counter value is lower than [3202 SUPERV 1 LIM LO](#).

ST6: Drive runs with 5Hz reference and 2s ramp time in the reverse direction. State6 shifts to state7 (ST6 TRIG TO ST7) when DI4 is activated.

ST7: Drive stops with 0.1s ramp time. State7 shifts to state1 (ST7 STATE N) after 10s delay time.

ST9: Drive runs toward Target A (forward direction) with 40Hz reference and 5s ramp time. State 9 shifts to state10 (ST9 TRIG TO ST10) when the counter value reaches the range of Target A slowdown window.

ST10: Drive runs toward Target A (forward direction) with 5Hz reference and 2s ramp time. State10 shifts to state11 (ST10 TRIG TO ST11) when the counter value reaches the range of Target A window.

ST11: Drive stops with 0.1s ramp time. State11 shifts to state12 (ST11 TRIG TO ST12) after 10s delay time.

ST12: Drive runs toward Target B (reverse direction) with 40Hz reference and 5s ramp time. State12 shifts to state13 (ST12 TRIG TO ST13) when the counter value reaches the range of Target B slowdown window.

ST13: Drive runs toward Target B (reverse direction) with 5Hz reference and 2s ramp time. State13 shifts to state14 (ST13 TRIG TO ST14) when the counter value reaches the range of Target B window.

ST14: Drive stops with 0.1s ramp time, State14 shifts to state1 (ST14 STATE N) after 10s delay time.

Parameter	Setting	Additional information
1001 EXT1 COMMANDS	SEQ PROG	Start, stop, direction commands for EXT1
1102 EXT1/EXT2 SEL	EXT1	EXT1 activation
1103 REF1 SELECT	SEQ PROG	Sequence program output as REF1
1201 CONST SPEED SEL	NOT SEL	Deactivation of constant speeds
1601 RUN ENABLE	NOT SEL	Deactivation of Run enable
1904 COUNTER ENABLE	ENABLED	Counter enable signal
1906 COUNTER INPUT	PLS IN(DI 5)	Selects DI 5 as the input signal source.

1907 COUNTER RESET	SEQ PROG	Set the reset source to the sequence programing
1910 COUNT DIRECTION	MOTOR DIR	Counter direction by the motor direction.
1912 TAR A HI VALUE	0	Setting the Target A value
1913 TAR A LO VALUE	1500	
1914 TAR B HI VALUE	0	Setting the Target B value
1915 TAR B LO VALUE	10	
1916 TAR C HI VALUE	0	Setting the Target C value
1917 TAR C LO VALUE	600	
1918 TAR D HI VALUE	0	Setting the Target D value
1919 TAR D LO VALUE	0	
1920 TAR WINDOW ST	10	Defines size of positioning status target window
1921 POS CORRECT	100%	Defines positioning fine tuning parameter
1922 SLOWDOWN WINDOW	50	Defines size of positioning status target slowdown window
1927 DI5 PPR	1	Defines the number of DI5 pulses per one revolution
1928 COUNTER NUM	1	Defines the multiplier (numerator) for the pulse counter
1929 COUNTER DEN	1	Defines the divider (denominator) for the pulse counter
2102 STOP FUNCTION	RAMP	Ramp stop
2201 ACC/DEC 1/2 SEL	SEQ PROG	Ramp as defined by parameter 8422 /.../8492,8522/...8492.
2202 ACCELER TIME 1	1 s	Acceleration/deceleration ramp pair 1
2203 DECELER TIME 1	2 s	
2205 ACCELER TIME 2	10 s	Acceleration/deceleration ramp pair 2
2206 DECELER TIME 2	10 s	
3201 SUPERV 1 PARAM	CNT VALUE LO	Set the counter value low word as the supervision1 signal.
3202 SUPERV 1 LIM LO	50	Setting the low limit for the supervision1 signal.
3203 SUPERV 1 LIM HI	1000	Setting the high limit for the supervision1 signal.
3207 SUPERV 3 PARAM	CNT VALUE LO	Set the counter value low word as the supervision3 signal.
3208 SUPERV 3 LIM LO	50	Setting the low limit for the supervision3 signal.
3209 SUPERV 3 LIM HI	1500	Setting the high limit for the supervision3 signal.
5001 PULSE NR	1024	The number of encoder pulses per one revolution
5002 ENCODER ENABLE	Disable	Disable the encoder

ST1		ST2		ST3		ST4		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8420 ST1 REF SEL	0%	8430	80%	8440	20%	8450	0%	State reference
8421 ST1 COMMANDS	DRIVE STOP	8431	START FRW	8441	START FRW	8451	DRIVE STOP	Run, direction and stop, Target X commands
8422 ST1 RAMP	0 s	8432	5 s	8442	5s	8452	0.1 s	Acceleration/deceleration ramp time
8423 ST1 OUT CONTROL	RST CNT ENT	8433	AO=0	8443	AO=0	8453	AO=0	Relay, digital and analog output control
8424 ST1 CHANGE DLY	0 s	8434	0 s	8444	0 s	8454	10 s	State change delay
8425 ST1 TRIG TO ST 2	DI2	8435	SUPRV1 OVER	8445	SUPRV3 OVER	8455	DLY AND DI3	State change trigger
8426 ST1 TRIG TO ST N	DI2(INV)	8436	NOT SEL	8446	NOT SEL	8456	NOT SEL	
8427 ST1 STATE N	STATE 9	8437	STATE 1	8447	STATE 1	8457	STATE 1	
8428 ST1 TRIG TO STN2	NOT SEL	8438	NOT SEL	8448	NOT SEL	8458	NOT SEL	
8429 ST1 STATE N2	STATE 1	8439	STATE 1	8449	STATE 1	8459	STATE 1	

ST5		ST6		ST7		ST8		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8460 ST5 REF SEL	100%	8470	10%	8480	0%	8490		State reference
8461 ST5 COMMANDS	START REV	8471	START REV	8481	DRIVE STOP	8491		Run, direction and stop commands
8462 ST5 RAMP	5 s	8472	2 s	8482	0.1 s	8492		Acceleration/deceleration ramp time
8463 ST5 OUT CONTROL	AO=0	8473	AO=0	8483	AO=0	8493		Relay, digital and analog output control

ST5		ST6		ST7		ST8		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8464 ST5 CHANGE DLY	0 s	8474	0 s	8484	10 s	8494		State change delay
8465 ST5 TRIG TO ST6	SUPRV1 UNDER	8475	NOT SEL	8485	NOT SEL	8495		
8466 ST5 TRIG TO ST N	NOT SEL	8476	NOT SEL	8486	CHANG E DLY	8496		
8467 ST5 STATE N	STATE 1	8477	STATE 1	8487	STATE 1	8497		
8468 ST5 TRIG TO ST N2	NOT SEL	8478	DI4	8488	NOT SEL	8498		State change trigger
8469 ST5 STATE N2	STATE 1	8479	STATE 7	8489	STATE 1	8499		

ST9		ST10		ST11		ST12		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8520 ST9 REF SEL	80%	8530	10%	8540	0%	8550	80%	State reference
8521 ST9 COMMANDS	TARGET A	8531	TARGET A	8541	DRIVE STOP	8551	TARGET B	Run, direction and stop commands
8522 ST9 RAMP	5 s	8532	2 s	8542	0.1 s	8552	5 s	Acceleration/deceleration ramp time
8523 ST9 OUT CONTROL	AO=0	8533	AO=0	8543	AO=0	8553	AO=0	Relay, digital and analog output control
8524 ST9 CHANGE DLY	0 s	8534	0 s	8544	10 s	8554	0 s	State change delay
8525 ST9 TRIG TO ST10	SLOWD OWN A	8535	AT TARGET A	8545	CHANG E DLY	8555	SLOWD OWN B	
8526 ST9 TRIG TO ST N	NOT SEL	8536	NOT SEL	8546	NOT SEL	8556	NOT SEL	
8527 ST9 STATE N	STATE 1	8537	STATE 1	8547	STATE 1	8557	STATE 1	
8528 ST9 TRIG TO ST N2	NOT SEL	8538	NOT SEL	8548	NOT SEL	8558	NOT SEL	State change trigger
8529 ST9 STATE N2	STATE 1	8539	STATE 1	8549	STATE 1	8559	STATE 1	

ST13		ST14		ST15		ST16		Additional information
Par.	Setting	Par.	Setting	Par.	Setting	Par.	Setting	
8560 ST13 REF SEL	10%	8570	0%					State reference
8561 ST13 COMMANDS	<i>TARGET B</i>	8571	<i>DRIVE STOP</i>					Run, direction and stop commands
8562 ST13 RAMP	2 s	8572	0.1 s					Acceleration/deceleration ramp time
8563 ST13 OUT CONTROL	<i>AO=0</i>	8573	<i>AO=0</i>					Relay, digital and analog output control
8564 ST13 CHANGE DLY	0 s	8574	10 s					State change delay
8565 ST13 TRIG TO ST14	<i>AT TARGET B</i>	8575	<i>NOT SEL</i>					
8566 ST13 TRIG TO ST N	<i>NOT SEL</i>	8536	<i>CHANGE DLY</i>					
8567 ST13 STATE N	<i>STATE 1</i>	8577	<i>STATE 1</i>					
8568 ST13 TRIG TO ST N2	<i>NOT SEL</i>	8578	<i>NOT SEL</i>					State change trigger
8569 ST13 STATE N2	<i>STATE 1</i>	8579	<i>STATE 1</i>					

5

Actual signals and parameters

What this chapter contains

The chapter describes the actual signals and parameters related to sequence program and gives the fieldbus equivalent values for each signal/parameter. It also contains a table of the default values for the different macros available in ACS355 enhanced sequence program firmware.

Terms and abbreviations

Term	Definition
Actual signal	Sequence program related signals measured or calculated by the drive. Can be monitored by the user. No user setting possible.
Def	Parameter default value
Parameter	A user-adjustable sequence program operation instruction of the drive. Note: Parameter selections are shown on the basic control panel as integer values. Eg parameter 1001 EXT1 COMMANDS selection COMM is shown as value 10 (which is equal to the fieldbus equivalent FbEq).
FbEq	Fieldbus equivalent: The scaling between the value and the integer used in serial communication.

Note: More information about drive parameters please refer to the section Actual signal and parameters in *ACS355 User's manual* (3AUUA0000066143 [English]).

Actual signals

Actual signals			
No.	Name/Value	Description	FbEq
01 OPERATING DATA		Basic signals for monitoring the drive (read-only)	
0135 COMM VALUE 1		Data received from fieldbus	1 = 1
0136 COMM VALUE 2		Data received from fieldbus	1 = 1
0167 SEQ PROG STS		Status word of the Sequence program:	1 = 1
		Bit 0 = ENABLED (1 = enabled) Bit 1 = STARTED Bit 2 = PAUSED Bit 3 = LOGIC VALUE (logic operation defined by parameters 8406...8410). Bit 4 = LOGIC2 VALUE (logic operation defined by parameters 8501...8505).	
0168 SEQ PROG STATE		Active state of the Sequence program. 1...16 = state 1...16.	1 = 1
0169 SEQ PROG TIMER		Current state time counter of the Sequence program	1 = 2 s
0170 SEQ PROG AO VAL		Analog output control values defined by the Sequence program. See parameter 8423 ST1 OUT CONTROL .	1 = 0.1%
0171 SEQ CYCLE CNTR		Executed sequence counter of the Sequence program. See parameters 8415 CYCLE CNT LOC and 8416 CYCLE CNT RST .	1 = 1
0190 POS STATUS		Active target position status word.	1 = 1
		Bit 0...3 = At Target A...D. when counter value enter the Target x range which range is defined by parameter 1920 TAR WINDOW ST , the corresponding positioning status bit (Target x) will be set. Bit 4...7 = Reserved. Bit 8...11 = Slowdown A...D, see parameter 1922 SLOWDOWN WINDOW . Bit 12...14 = Reserved. Bit 15 = At target. When sequence programing function enable and sequence state command set Target x(A...D), as motor running toward to Target x and at last current position running at TargetA...D, Bit 15 will be set.	
0192 COUNTER VALUE HI		High part word of pulse counter value. See parameter group 19 TIMER & COUNTER .	1 = 1
0193 COUNTER VALUE LO		Low part word of pulse counter value. See parameter group 19 TIMER & COUNTER .	1 = 1


Actual signals		
No.	Name/Value	Description
0194	SPEED ACT POS	Actual motor speed after tuning motor speed in the sequence programing application which is calculated results by parameter 1921 POS CORRECT multiplied with actual motor speed.

Parameters

All parameters			
No.	Name/Value	Description	Def/FbEq
	10 START/STOP/DIR	The sources for external start, stop and direction control	
1001	EXT1 COMMANDS	Defines the connections and the source for the start, stop and direction commands for external control location 1 (EXT1). Note: Start signal must be reset if the drive has been stopped through STO (Safe torque off) input (see parameter 3025 STO OPERATION) or emergency stop selection (see parameter 2109 EMERG STOP SEL).	DI1,2
	NOT SEL	No start, stop and direction command source	0
	DI1	Start and stop through digital input DI1. 0 = stop, 1 = start. Direction is fixed according to parameter 1003 DIRECTION (setting REQUEST = FORWARD).	1
	DI1,2	Start and stop through digital input DI1. 0 = stop, 1 = start. Direction through digital input DI2. 0 = forward, 1 = reverse. To control direction, parameter 1003 DIRECTION setting must be REQUEST .	2
	DI1P,2P	Pulse start through digital input DI1. 0 -> 1: Start. (In order to start the drive, digital input DI2 must be activated prior to the pulse fed to DI1.) Pulse stop through digital input DI2. 1 -> 0: Stop. Direction of rotation is fixed according to parameter 1003 DIRECTION (setting REQUEST = FORWARD). Note: When the stop input (DI2) is deactivated (no input), the control panel start and stop keys are disabled.	3
	DI1P,2P,3	Pulse start through digital input DI1. 0 -> 1: Start. (In order to start the drive, digital input DI2 must be activated prior to the pulse fed to DI1.) Pulse stop through digital input DI2. 1 -> 0: Stop. Direction through digital input DI3. 0 = forward, 1 = reverse. To control direction, parameter 1003 DIRECTION setting must be REQUEST . Note: When the stop input (DI2) is deactivated (no input), the control panel start and stop keys are disabled.	4
	DI1P,2P,3P	Pulse start forward through digital input DI1. 0 -> 1: Start forward. Pulse start reverse through digital input DI2. 0 -> 1: Start reverse. (In order to start the drive, digital input DI3 must be activated prior to the pulse fed to DI1/DI2). Pulse stop through digital input DI3. 1 -> 0: Stop. To control the direction, parameter 1003 DIRECTION setting must be REQUEST . Note: When the stop input (DI3) is deactivated (no input), the control panel start and stop keys are disabled.	5

All parameters																		
No.	Name/Value	Description	Def/FbEq															
	KEYPAD	Start, stop and direction commands through control panel when EXT1 is active. To control the direction, parameter 1003 DIRECTION setting must be REQUEST .	8															
	DI1F,2R	Start, stop and direction commands through digital inputs DI1 and DI2. <table border="1"> <thead> <tr> <th>DI1</th> <th>DI2</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>1</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> </tbody> </table> Parameter 1003 DIRECTION setting must be REQUEST .	DI1	DI2	Operation	0	0	Stop	1	0	Start forward	0	1	Start reverse	1	1	Stop	9
DI1	DI2	Operation																
0	0	Stop																
1	0	Start forward																
0	1	Start reverse																
1	1	Stop																
	COMM	Fieldbus interface as the source for the start and stop commands, ie Control word 0301 FB CMD WORD 1 bits 0...1. The Control word is sent by the fieldbus controller through the fieldbus adapter or embedded fieldbus (Modbus) to the drive.	10															
	TIMED FUNC 1	Timed start/stop control. Timed function 1 active = start, timed function 1 inactive = stop. See parameter group 36 TIMED FUNCTIONS .	11															
	TIMED FUNC 2	See selection TIMED FUNC 1 .	12															
	TIMED FUNC 3	See selection TIMED FUNC 1 .	13															
	TIMED FUNC 4	See selection TIMED FUNC 1 .	14															
	DI5	Start and stop through digital input DI5. 0 = stop, 1 = start. Direction is fixed according to parameter 1003 DIRECTION (setting REQUEST = FORWARD).	20															
	DI5,4	Start and stop through digital input DI5. 0 = stop, 1 = start. Direction through digital input DI4. 0 = forward, 1 = reverse. To control direction, parameter 1003 DIRECTION must be REQUEST .	21															
	TIMER STOP	Stop when timer delay defined by parameter 1901 TIMER DELAY has passed. Start with timer start signal. Source for the signal is selected by parameter 1902 TIMER START .	22															
	TIMER START	Start when timer delay defined by parameter 1901 TIMER DELAY has passed. Stop when timer is reset by parameter 1903 TIMER RESET .	23															
	COUNTER STOP	Stop when counter limit defined by parameter 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO has been exceeded. Start with counter start signal. Source for the signal is selected by parameter 1911 CNTR S/S COMMAND .	24															


All parameters			
No.	Name/Value	Description	Def/FbEq
	COUNTER START	Start when counter limit defined by parameter 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO has been exceeded. Stop with counter stop signal. Source for the signal is selected by parameter 1911 CNTR S/S COMMAND .	25
	SEQ PROG	Start, stop and direction commands through Sequence program. See parameter group 84 SEQUENCE PROG and group 85 SEQUENCE PROG2 .	26
1002	EXT2 COMMANDS	Defines the connections and the source for the start, stop and direction commands for external control location 2 (EXT2).	NOT SEL
		See parameter 1001 EXT1 COMMANDS .	
1003	DIRECTION	Enables the control of rotation direction of the motor, or fixes the direction.	REQUEST
	FORWARD	Fixed to forward	1
	REVERSE	Fixed to reverse	2
	REQUEST	Control of rotation direction allowed	3
11 REFERENCE SELECT		Panel reference type, external control location selection and external reference sources and limits	
1102	EXT1/EXT2 SEL	Defines the source from which the drive reads the signal that selects between the two external control locations, EXT1 or EXT2.	EXT1
	EXT1	EXT1 active. The control signal sources are defined by parameters 1001 EXT1 COMMANDS and 1103 REF1 SELECT .	0
	DI1	Digital input DI1. 0 = EXT1, 1 = EXT2.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	EXT2	EXT2 active. The control signal sources are defined by parameters 1002 EXT2 COMMANDS and 1106 REF2 SELECT .	7
	COMM	Fieldbus interface as the source for EXT1/EXT2 selection, ie Control word 0301 FB CMD WORD 1 bit 5 (with ABB drives profile 5319 EFB PAR 19 bit 11). The Control word is sent by the fieldbus controller through the fieldbus adapter or embedded fieldbus (Modbus) to the drive.	8
	TIMED FUNC 1	Timed EXT1/EXT2 control selection. Timed function 1 active = EXT2, timed function 1 inactive = EXT1. See parameter group 36 TIMED FUNCTIONS .	9
	TIMED FUNC 2	See selection TIMED FUNC 1 .	10

All parameters			
No.	Name/Value	Description	Def/FbEq
	TIMED FUNC 3	See selection TIMED FUNC 1 .	11
	TIMED FUNC 4	See selection TIMED FUNC 1 .	12
	DI1(INV)	Inverted digital input DI1. 1 = EXT1, 0 = EXT2.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
1103	REF1 SELECT	Selects the signal source for external reference REF1.	AI1
	KEYPAD	Control panel	0
	AI1	Analog input AI1	1
	AI2	Analog input AI2	2
AI1/JOYST	Analog input AI1 as joystick. The minimum input signal runs the motor at the maximum reference in the reverse direction, the maximum input at the maximum reference in the forward direction. Minimum and maximum references are defined by parameters 1104 REF1 MIN and 1105 REF1 MAX . Note: Parameter 1003 DIRECTION must be set to REQUEST .		3
	 WARNING! If parameter 1301 MINIMUM AI1 is set to 0 V and analog input signal is lost (ie 0 V), the rotation of the motor is reversed to the maximum reference. Set the following parameters to activate a fault when analog input signal is lost: Set parameter 1301 MINIMUM AI1 to 20% (2 V or 4 mA). Set parameter 3021 AI1 FAULT LIMIT to 5% or higher. Set parameter 3001 AI<MIN FUNCTION to FAULT.		
AI2/JOYST	See selection AI1/JOYST .		4
DI3U,4D(R)	Digital input DI3: Reference increase. Digital input DI4: Reference decrease. Stop command resets the reference to zero. Parameter 2205 ACCELER TIME 2 defines the rate of the reference change.		5

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI3U,4D	Digital input DI3: Reference increase. Digital input DI4: Reference decrease. The program stores the active speed reference (not reset by a stop command). When the drive is restarted, the motor ramps up at the selected acceleration rate to the stored reference. Parameter 2205 ACCELER TIME 2 defines the rate of the reference change.	6
	COMM	Fieldbus reference REF1	8
	COMM+AI1	Summation of fieldbus reference REF1 and analog input AI1.	9
	COMM*AI1	Multiplication of fieldbus reference REF1 and analog input AI1.	10
	DI3U,4D(RNC)	Digital input DI3: Reference increase. Digital input DI4: Reference decrease. Stop command resets the reference to zero. The reference is not saved if the control source is changed (from EXT1 to EXT2, from EXT2 to EXT1 or from LOC to REM). Parameter 2205 ACCELER TIME 2 defines the rate of the reference change.	11
	DI3U,4D(NC)	Digital input DI3: Reference increase. Digital input DI4: Reference decrease. The program stores the active speed reference (not reset by a stop command). The reference is not saved if the control source is changed (from EXT1 to EXT2, from EXT2 to EXT1 or from LOC to REM). When the drive is restarted, the motor ramps up at the selected acceleration rate to the stored reference. Parameter 2205 ACCELER TIME 2 defines the rate of the reference change.	12
	AI1+AI2	Reference is calculated with the following equation: $REF = AI1(\%) + AI2(\%) - 50\%$	14
	AI1*AI2	Reference is calculated with the following equation: $REF = AI1(\%) \cdot (AI2(\%) / 50\%)$	15
	AI1-AI2	Reference is calculated with the following equation: $REF = AI1(\%) + 50\% - AI2(\%)$	16
	AI1/AI2	Reference is calculated with the following equation: $REF = AI1(\%) \cdot (50\% / AI2 (\%))$	17
	KEYPAD(RNC)	Defines the control panel as the reference source. Stop command resets the reference to zero (the R stands for reset). The reference is not saved if the control source is changed (from EXT1 to EXT2, from EXT2 to EXT1).	20
	KEYPAD(NC)	Defines the control panel as the reference source. Stop command does not reset the reference to zero. The reference is stored. The reference is not saved if the control source is changed (from EXT1 to EXT2, from EXT2 to EXT1).	21

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI4U,5D	See selection DI3U,4D .	30
	DI4U,5D(NC)	See selection DI3U,4D(NC) .	31
	FREQ INPUT	Frequency input	32
	SEQ PROG	Sequence program output. See parameter 8420 ST1 REF SEL	33
	AI1+SEQ PROG	Addition of analog input AI1 and Sequence program output	34
	AI2+SEQ PROG	Addition of analog input AI2 and Sequence program output	35
1104	REF1 MIN	Defines the minimum value for external reference REF1. Corresponds to the minimum setting of the used source signal.	0.0 Hz / 1 rpm
	0.0...500.0 Hz / 0...30000 rpm	Minimum value in rpm. Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. Example: Analog input AI1 is selected as the reference source (value of parameter 1103 is AI1). The reference minimum and maximum correspond to the 1301 MINIMUM AI1 and 1302 MAXIMUM AI1 settings as follows: <p>The graph illustrates the mapping between the AI1 signal percentage and the resulting reference value (REF). The top segment represents the positive range from 1301% to 1302%, and the bottom segment represents the negative range from -1301% to -1302%. The y-axis is labeled REF (Hz/rpm) and the x-axis is labeled AI1 signal (%). Reference values are marked at 1301 and 1302, while -1301 and -1302 are also shown. The labels REF1 MAX (1105), REF1 MIN (1104), -REF1 MIN (1104), and -REF1 MAX (1105) are placed near their respective points on the graph.</p>	1 = 0.1 Hz / 1 rpm
1105	REF1 MAX	Defines the maximum value for external reference REF1. Corresponds to the maximum setting of the used source signal.	E: 50.0 Hz U: 60.0 Hz
	0.0...500.0 Hz / 0...30000 rpm	Maximum value in rpm. Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. See the example for parameter 1104 REF1 MIN .	1 = 0.1 Hz / 1 rpm
1106	REF2 SELECT	Selects the signal source for external reference REF2.	AI2
	KEYPAD	See parameter 1103 REF1 SELECT .	0
	AI1	See parameter 1103 REF1 SELECT .	1
	AI2	See parameter 1103 REF1 SELECT .	2
	AI1/JOYST	See parameter 1103 REF1 SELECT .	3
	AI2/JOYST	See parameter 1103 REF1 SELECT .	4


All parameters			
No.	Name/Value	Description	Def/FbEq
	DI3U,4D(R)	See parameter 1103 REF1 SELECT .	5
	DI3U,4D	See parameter 1103 REF1 SELECT .	6
	COMM	See parameter 1103 REF1 SELECT .	8
	COMM+AI1	See parameter 1103 REF1 SELECT .	9
	COMM*AI1	See parameter 1103 REF1 SELECT .	10
	DI3U,4D(RNC)	See parameter 1103 REF1 SELECT .	11
	DI3U,4D(NC)	See parameter 1103 REF1 SELECT .	12
	AI1+AI2	See parameter 1103 REF1 SELECT .	14
	AI1*AI2	See parameter 1103 REF1 SELECT .	15
	AI1-AI2	See parameter 1103 REF1 SELECT .	16
	AI1/AI2	See parameter 1103 REF1 SELECT .	17
	KEYPAD(RNC)	See parameter 1103 REF1 SELECT .	20
	KEYPAD(NC)	See parameter 1103 REF1 SELECT .	21
	DI4U,5D	See parameter 1103 REF1 SELECT .	30
	DI4U,5D(NC)	See parameter 1103 REF1 SELECT .	31
	FREQ INPUT	See parameter 1103 REF1 SELECT .	32
	SEQ PROG	See parameter 1103 REF1 SELECT .	33
	AI1+SEQ PROG	See parameter 1103 REF1 SELECT .	34
	AI2+SEQ PROG	See parameter 1103 REF1 SELECT .	35
1107	REF2 MIN	Defines the minimum value for external reference REF2. Corresponds to the minimum setting of the used source signal.	0.0%
0.0...100.0%		Value as a percentage of the maximum frequency / maximum speed / nominal torque. See the example for parameter 1104 REF1 MIN for correspondence to the source signal limits.	1 = 0.1%
1108	REF2 MAX	Defines the maximum value for external reference REF2. Corresponds to the maximum setting of the used source signal.	100.0%
0.0...100.0%		Value as a percentage of the maximum frequency / maximum speed / nominal torque. See the example for parameter 1104 REF1 MIN for correspondence to the source signal limits.	1 = 0.1%

All parameters			
No.	Name/Value	Description	Def/FbEq
	13 ANALOG INPUTS	Analog input signal processing	
1301 MINIMUM AI1		<p>Defines the minimum %-value that corresponds to minimum mA/(V) signal for analog input AI1. When used as a reference, the value corresponds to the reference minimum setting.</p> <p>0...20 mA $\hat{=}$ 0...100%</p> <p>4...20 mA $\hat{=}$ 20...100%</p> <p>-10...10 mA $\hat{=}$ -50...50%</p> <p>Example: If AI1 is selected as the source for external reference REF1, this value corresponds to the value of parameter 1104 REF1 MIN.</p> <p>Note: <i>MINIMUM AI1</i> value must not exceed <i>MAXIMUM AI1</i> value.</p>	1.0%
	-100.0...100.0%	<p>Value as a percentage of the full signal range.</p> <p>Example: If the minimum value for analog input is 4 mA, the percentage value for 0...20 mA range is: $(4 \text{ mA} / 20 \text{ mA}) \cdot 100\% = 20\%$</p>	1 = 0.1%
1302 MAXIMUM AI1		<p>Defines the maximum %-value that corresponds to maximum mA/(V) signal for analog input AI1. When used as a reference, the value corresponds to the reference maximum setting.</p> <p>0...20 mA $\hat{=}$ 0...100%</p> <p>4...20 mA $\hat{=}$ 20...100%</p> <p>-10...10 mA $\hat{=}$ -50...50%</p> <p>Example: If AI1 is selected as the source for external reference REF1, this value corresponds to the value of parameter 1105 REF1 MAX.</p>	100.0%
	-100.0...100.0%	<p>Value as a percentage of the full signal range.</p> <p>Example: If the maximum value for analog input is 10 mA, the percentage value for 0...20 mA range is: $(10 \text{ mA} / 20 \text{ mA}) \cdot 100\% = 50\%$</p>	1 = 0.1%
1303 FILTER AI1		<p>Defines the filter time constant for analog input AI1, ie the time within which 63% of a step change is reached.</p> 	0.1 s
	0.0...10.0 s	Filter time constant	1 = 0.1 s

All parameters			
No.	Name/Value	Description	Def/FbEq
1304	MINIMUM AI2	Defines the minimum %-value that corresponds to minimum mA/(V) signal for analog input AI2. See parameter 1301 MINIMUM AI1 .	20%
	-100.0...100.0%	See parameter 1301 MINIMUM AI1 .	1 = 0.1%
1305	MAXIMUM AI2	Defines the maximum %-value that corresponds to maximum mA/(V) signal for analog input AI2. See parameter 1302 MAXIMUM AI1 .	100.0%
	-100.0...100.0%	See parameter 1302 MAXIMUM AI1 .	1 = 0.1%
1306	FILTER AI2	Defines the filter time constant for analog input AI2. See parameter 1303 FILTER AI1 .	0.1 s
	0.0...10.0 s	Filter time constant	1 = 0.1 s
14 RELAY OUTPUTS		Status information indicated through relay output, and relay operating delays. Note: Relay outputs 2...4 are available only if the MREL-01 output relay module is connected to the drive. See <i>MREL-01 output relay module user's manual</i> (3AUA0000035974 [English]).	
1401	RELAY OUTPUT 1	Selects a drive status indicated through relay output RO 1. The relay energizes when the status meets the setting.	FAULT(-1)
	NOT SEL	Not used	0
	READY	Ready to function: Run enable signal on, no fault, supply voltage within acceptable range and emergency stop signal off.	1
	RUN	Running: Start signal on, Run enable signal on, no active fault.	2
	FAULT(-1)	Inverted fault. Relay is de-energized on a fault trip.	3
	FAULT	Fault	4
	ALARM	Alarm	5
	REVERSED	Motor rotates in reverse direction.	6
	STARTED	The drive has received start command. Relay is energized even if Run enable signal is off. Relay is de-energized when drive receives a stop command or a fault occurs.	7
	SUPRV1 OVER	Status according to supervision parameters 3201...3203 . See parameter group 32 SUPERVISION .	8
	SUPRV1 UNDER	See selection SUPRV1 OVER .	9
	SUPRV2 OVER	Status according to supervision parameters 3204...3206 . See parameter group 32 SUPERVISION .	10
	SUPRV2 UNDER	See selection SUPRV2 OVER .	11
	SUPRV3 OVER	Status according to supervision parameters 3207...3209 . See parameter group 32 SUPERVISION .	12

All parameters								
No.	Name/Value	Description					Def/FbEq	
	SUPRV3 UNDER	See selection <i>SUPRV3 OVER</i> .					13	
	AT SET POINT	Output frequency is equal to the reference frequency.					14	
	FAULT(RST)	Fault. Automatic reset after the autoreset delay.					15	
	FLT/ALARM	Fault or alarm					16	
	EXT CTRL	Drive is under external control.					17	
	REF 2 SEL	External reference REF 2 is in use.					18	
	CONST FREQ	A constant speed is in use.					19	
	REF LOSS	Reference or active control location is lost.					20	
	OVERCURREN T	Alarm/Fault by overcurrent protection function					21	
	OVERVOLTAG E	Alarm/Fault by overvoltage protection function					22	
	DRIVE TEMP	Alarm/Fault by drive overtemperature protection function					23	
	UNDERVOLTA GE	Alarm/Fault by undervoltage protection function					24	
	AI1 LOSS	Analog input AI1 signal is lost.					25	
	AI2 LOSS	Analog input AI2 signal is lost.					26	
	MOTOR TEMP	Alarm/Fault by motor overtemperature protection function.					27	
	STALL	Alarm/Fault by stall protection function.					28	
	UNDERLOAD	Alarm/Fault by underload protection function.					29	
	FLUX READY	Motor is magnetized and able to supply nominal torque.					33	
	USER MACRO 2	User macro 2 is active.					34	
	COMM	Fieldbus control signal 0134 COMM RO WORD. 0 = de-energize output, 1 = energize output.					35	
		0134 value	Binary	RO4 (MREL)	RO3 (MREL)	RO2 (MREL)	DO	RO1
		0	00000	0	0	0	0	0
		1	00001	0	0	0	0	1
		2	00010	0	0	0	1	0
		3	00011	0	0	0	1	1
		4	00100	0	0	1	0	0
		5...30
		31	11111	1	1	1	1	1

All parameters								
No.	Name/Value	Description					Def/FbEq	
	COMM(-1)	Fieldbus control signal 0134 COMM RO WORD. 0 = de-energize output, 1 = energize output.					36	
		0134 value	Binary	RO4 (MREL)	RO3 (MREL)	RO2 (MREL)	DO	RO1
		0	00000	1	1	1	1	1
		1	00001	1	1	1	1	0
		2	00010	1	1	1	0	1
		3	00011	1	1	1	0	0
		4	00100	1	1	0	1	1
		5...30
		31	11111	0	0	0	0	0
	TIMED FUNC 1	Timed function 1 is active. See parameter group 36 TIMED FUNCTIONS .					37	
	TIMED FUNC 2	Timed function 2 is active. See parameter group 36 TIMED FUNCTIONS .					38	
	TIMED FUNC 3	Timed function 3 is active. See parameter group 36 TIMED FUNCTIONS .					39	
	TIMED FUNC 4	Timed function 4 is active. See parameter group 36 TIMED FUNCTIONS .					40	
	M.TRIG FAN	Cooling fan running time counter is triggered.					41	
	M.TRIG REV	Revolutions counter is triggered.					42	
	M.TRIG RUN	Run time counter is triggered.					43	
	M.TRIG MWH	MWh counter is triggered.					44	
	SEQ PROG	Relay output control with Sequence program. See parameter 8423 ST1 OUT CONTROL .					50	
	MBRK	On/Off control of a mechanical brake.					51	
	JOG ACTIVE	Jogging function active.					52	
	STO	STO (Safe torque off) has been triggered.					57	
	STO(-1)	STO (Safe torque off) is inactive and the drive operates normally.					58	
	AT TARGET A	Parameter 0190 POS STATUS bit 0(AT TARGET A) active.					60	
	AT TARGET B	Parameter 0190 POS STATUS bit 1(AT TARGET B) active.					61	
	AT TARGET C	Parameter 0190 POS STATUS bit 2(AT TARGET C) active.					62	
	AT TARGET D	Parameter 0190 POS STATUS bit 3(AT TARGET D) active.					63	
	AT TARGET	Parameter 0190 POS STATUS bit 15(AT TARGET) active.					68	
1402	RELAY OUTPUT 2	See parameter 1401 RELAY OUTPUT 1 . Available only if the MREL-01 output relay module is connected to the drive.					NOT SEL	
1403	RELAY OUTPUT 3	See parameter 1401 RELAY OUTPUT 1 . Available only if the MREL-01 output relay module is connected to the drive.					NOT SEL	

All parameters			
No.	Name/Value	Description	Def/FbEq
1404	RO 1 ON DELAY 0.0...3600.0 s	Defines the operation delay for relay output RO 1. Delay time. The figure below illustrates the operation (on) and release (off) delays for relay output RO. 	0.0 s 1 = 0.1 s
1405	RO 1 OFF DELAY 0.0...3600.0 s	Defines the release delay for relay output RO 1. Delay time. See the figure for parameter 1404 RO 1 ON DELAY .	0.0 s 1 = 0.1 s
1406	RO 2 ON DELAY	See parameter 1404 RO 1 ON DELAY .	0.0 s
1407	RO 2 OFF DELAY	See parameter 1405 RO 1 OFF DELAY .	0.0 s
1408	RO 3 ON DELAY	See parameter 1404 RO 1 ON DELAY .	0.0 s
1409	RO 3 OFF DELAY	See parameter 1405 RO 1 OFF DELAY .	0.0 s
1410	RELAY OUTPUT 4	See parameter 1401 RELAY OUTPUT 1 . Available only if the MREL-01 output relay extension module is connected to the drive.	NOT SEL
1413	RO 4 ON DELAY	See parameter 1404 RO 1 ON DELAY .	0.0 s
1414	RO 4 OFF DELAY	See parameter 1405 RO 1 OFF DELAY .	0.0 s
15 ANALOG OUTPUTS	Selection of the actual signals to be indicated through analog output and output signal processing.		
1501	AO1 CONTENT SEL	Connects a drive signal to analog output AO.	103
x...x	Parameter index in group 01 OPERATING DATA . Eg 102 = 0102 SPEED .		

All parameters			
No.	Name/Value	Description	Def/FbEq
1502 AO1 CONTENT MIN		<p>Defines the minimum value for the signal selected with parameter 1501 AO1 CONTENT SEL.</p> <p>AO minimum and maximum correspond to the 1504 MINIMUM AO1 and 1505 MAXIMUM AO1 settings as follows:</p>	-
x...x		Setting range depends on the parameter 1501 AO1 CONTENT SEL setting.	-
1503 AO1 CONTENT MAX		Defines the maximum value for the signal selected with parameter 1501 AO1 CONTENT SEL . See the figure for parameter 1502 AO1 CONTENT MIN .	-
x...x		Setting range depends on the parameter 1501 AO1 CONTENT SEL setting.	-
1504 MINIMUM AO1		Defines the minimum value for the analog output signal AO. See the figure for parameter 1502 AO1 CONTENT MIN .	0.0 mA
0.0...20.0 mA		Minimum value	1 = 0.1 mA
1505 MAXIMUM AO1		Defines the maximum value for the analog output signal AO. See the figure for parameter 1502 AO1 CONTENT MIN .	20.0 mA
0.0...20.0 mA		Maximum value	1 = 0.1 mA
1506 FILTER AO1		Defines the filter time constant for analog output AO, ie the time within which 63% of a step change is reached. See the figure for parameter 1303 FILTER AI1 .	0.1 s
0.0...10.0 s		Filter time constant	1 = 0.1 s
16 SYSTEM CONTROLS		Parameter view, Run enable, parameter lock etc.	
1601 RUN ENABLE		Selects a source for the external Run enable signal.	NOT SEL
NOT SEL		Allows the drive to start without an external Run enable signal.	0
DI1		External signal required through digital input DI1. 1 = Run enable. If Run enable signal is switched off, the drive will not start or coasts to stop if it is running.	1
DI2		See selection DI1 .	2
DI3		See selection DI1 .	3

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	COMM	Fieldbus interface as the source for inverted Run enable signal (Run disable), ie Control word <i>0301 FB CMD WORD</i> 1 bit 6 (with ABB drives profile <i>5319 EFB PAR</i> 19 bit 3). The Control word is sent by the fieldbus controller through the fieldbus adapter or embedded fieldbus (Modbus) to the drive.	7
	DI1(INV)	External signal required through inverted digital input DI1. 0 = Run enable. If Run enable signal is switched on, the drive will not start or coasts to stop if it is running.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
1602	PARAMETER LOCK	Selects the state of the parameter lock. The lock prevents parameter changing from the control panel.	OPEN
	LOCKED	Parameter values cannot be changed from the control panel. The lock can be opened by entering the valid code to parameter 1603 PASS CODE . The lock does not prevent parameter changes made by macros or fieldbus.	0
	OPEN	The lock is open. Parameter values can be changed.	1
	NOT SAVED	Parameter changes from the control panel are not stored into the permanent memory. To store changed parameter values, set parameter <i>1607 PARAM SAVE</i> value to <i>SAVE....</i>	2
1603	PASS CODE	Selects the pass code for the parameter lock (see parameter 1602 PARAMETER LOCK).	0
0...65535		Pass code. Setting 358 opens the lock. The value reverts back to 0 automatically.	1 = 1

All parameters															
No.	Name/Value	Description	Def/FbEq												
1605	USER PAR SET CHG	<p>Enables the change of the User parameter set through a digital input. See parameter 9902 APPLIC MACRO. The change is only allowed when the drive is stopped. During the change, the drive will not start.</p> <p>Note: Always save the User parameter set with parameter 9902 after changing any parameter setting, or reperforming the motor identification. The last settings saved by the user are loaded into use whenever the power is switched off and on again or the parameter 9902 setting is changed. Any unsaved changes will be lost.</p> <p>Note: The value of this parameter is not included in the User parameter sets. A setting once made remains despite User parameter set change.</p> <p>Note: Selection of User parameter set 2 can be supervised through relay outputs RO 1...4 and digital output DO. See parameters 1401 RELAY OUTPUT 1 ... 1403 RELAY OUTPUT 3, 1410 RELAY OUTPUT 4 and 1805 DO SIGNAL.</p>	NOT SEL												
	NOT SEL	User parameter set change is not possible through a digital input. Parameter sets can be changed only from the control panel.	0												
	DI1	User parameter set control through digital input DI1. Falling edge of digital input DI1: User parameter set 1 is loaded into use. Rising edge of digital input DI1: User parameter set 2 is loaded into use.	1												
	DI2	See selection DI1 .	2												
	DI3	See selection DI1 .	3												
	DI4	See selection DI1 .	4												
	DI5	See selection DI1 .	5												
	DI1,2	User parameter set selection through digital inputs DI1 and DI2. 1 = DI active, 0 = DI inactive.	7												
		<table border="1"> <thead> <tr> <th>DI1</th> <th>DI2</th> <th>User parameter set</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>User parameter set 1</td> </tr> <tr> <td>1</td> <td>0</td> <td>User parameter set 2</td> </tr> <tr> <td>0</td> <td>1</td> <td>User parameter set 3</td> </tr> </tbody> </table>	DI1	DI2	User parameter set	0	0	User parameter set 1	1	0	User parameter set 2	0	1	User parameter set 3	
DI1	DI2	User parameter set													
0	0	User parameter set 1													
1	0	User parameter set 2													
0	1	User parameter set 3													
	DI2,3	See selection DI1,2 .	8												
	DI3,4	See selection DI1,2 .	9												
	DI4,5	See selection DI1,2 .	10												

All parameters															
No.	Name/Value	Description	Def/FbEq												
	SEQ PROG	User parameter set selection through sequence programing. Example: When parameter 8506 MACRO CHG ST is set to STATE 1 and sequence programing enter to stat1, the user macro changed to parameter 8507 USER MACRO SEL setting.	11												
	DI1(INV)	User parameter set control through inverted digital input DI1. Falling edge of inverted digital input DI1: User parameter set 2 is loaded into use. Rising edge of inverted digital input DI1: User parameter set 1 is loaded into use.	-1												
	DI2(INV)	See selection DI1(INV) .	-2												
	DI3(INV)	See selection DI1(INV) .	-3												
	DI4(INV)	See selection DI1(INV) .	-4												
	DI1,2(INV)	User parameter set selection through inverted digital inputs DI1 and DI2. 1 = DI inactive, 0 =DI active. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th>DI1</th> <th>DI2</th> <th>User parameter set</th> </tr> <tr> <td>1</td> <td>1</td> <td>User parameter set 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>User parameter set 2</td> </tr> <tr> <td>1</td> <td>0</td> <td>User parameter set 3</td> </tr> </table>	DI1	DI2	User parameter set	1	1	User parameter set 1	0	1	User parameter set 2	1	0	User parameter set 3	-7
DI1	DI2	User parameter set													
1	1	User parameter set 1													
0	1	User parameter set 2													
1	0	User parameter set 3													
	DI2,3(INV)	See selection DI1,2 .	-8												
	DI3,4(INV)	See selection DI1,2 .	-9												
	DI4,5(INV)	See selection DI1,2 .	-10												
18 FREQ IN & TRAN OUT	Frequency input and transistor output signal processing.														
1804 TO MODE	Selects the operation mode for the transistor output TO.		DIGITAL												
DIGITAL	Transistor output is used as a digital output DO.		0												
FREQUENCY	Transistor output is used as a frequency output FO.		1												
1805 DO SIGNAL	Selects a drive status indicated through digital output DO.		FAULT(-1)												
	See parameter 1401 RELAY OUTPUT 1 .														
1806 DO ON DELAY	Defines the operation delay for digital output DO.		0.0 s												
0.0...3600.0 s	Delay time		1 = 0.1 s												
1807 DO OFF DELAY	Defines the release delay for digital output DO.		0.0 s												
0.0...3600.0 s	Delay time		1 = 0.1 s												
1808 FO CONTENT SEL	Selects a drive signal to be connected to frequency output FO.		104												
x...x	Parameter index in group 01 OPERATING DATA . Eg 102 = 0102 SPEED .														

All parameters			
No.	Name/Value	Description	Def/FbEq
1809	FO CONTENT MIN	Defines the minimum frequency output FO signal value. Signal is selected with parameter 1808 FO CONTENT SEL . FO minimum and maximum correspond to 1811 MINIMUM FO and 1812 MAXIMUM FO settings as follows:	-
x...x		Setting range depends on parameter 1808 FO CONTENT SEL setting.	-
1810	FO CONTENT MAX	Defines the maximum frequency output FO signal value. Signal is selected with parameter 1808 FO CONTENT SEL . See parameter 1809 FO CONTENT MIN .	-
x...x		Setting range depends on parameter 1808 FO CONTENT SEL setting.	-
1811	MINIMUM FO	Defines the minimum value for frequency output FO.	10 Hz
10...16000 Hz		Minimum frequency. See parameter 1809 FO CONTENT MIN .	1 = 1 Hz
1812	MAXIMUM FO	Defines the maximum value for frequency output FO.	1000 Hz
10...16000 Hz		Maximum frequency. See parameter 1809 FO CONTENT MIN .	1 = 1 Hz
1813	FILTER FO	Defines the filter time constant for frequency output FO, ie the time within which 63% of a step change is reached.	0.1 s
0.0...10.0 s		Filter time constant	1 = 0.1 s
19 TIMER & COUNTER		Timer and counter for start and stop control	
1904	COUNTER ENABLE	Selects the source for the counter enable signal.	DISABLED
DI1(INV)		Counter enable signal through inverted digital input DI1. 0 = active, 1 = inactive.	-1
DI2(INV)		See selection DI1(INV) .	-2
DI3(INV)		See selection DI1(INV) .	-3
DI4(INV)		See selection DI1(INV) .	-4
DI5(INV)		See selection DI1(INV) .	-5
DISABLED		No counter enable	0
DI1		Counter enable signal through digital input DI1. 1 = active, 0 = inactive.	1



All parameters			
No.	Name/Value	Description	Def/FbEq
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	ENABLED	Counter enabled	6
1906 COUNTER INPUT		Selects the input signal source for the counter.	PLS IN(DI 5)
PLS IN(DI 5)		Digital input DI5 pulses. When a pulse is detected, the counter value increases by 1.	1
ENC W/O DIR		Encoder pulse edges. When a rising or a falling edge is detected, the counter value increases by 1.	2
ENC WITH DIR		Encoder pulse edges. The direction of rotation is taken into account. When a rising or a falling edge is detected and the direction of rotation is forward, the counter value increases by 1. When the direction of rotation is reverse, the counter value decreases by 1.	3
FILTERED DI5		Filtered digital input DI5 pulses. When a pulse is detected, the counter value increases by 1. Note: Due to filtering, the maximum input signal frequency is 50 Hz.	4
1907 COUNTER RESET		Selects the source for the counter reset signal.	NOT SEL
DI1(INV)		Counter reset through inverted digital input DI1. 0 = active, 1 = inactive.	-1
DI2(INV)		See selection DI1(INV) .	-2
DI3(INV)		See selection DI1(INV) .	-3
DI4(INV)		See selection DI1(INV) .	-4
DI5(INV)		See selection DI1(INV) .	-5
NOT SEL		No reset signal	0
DI1		Counter reset through digital input DI1. 1 = active, 0 = inactive.	1
DI2		See selection DI1 .	2
DI3		See selection DI1 .	3
DI4		See selection DI1 .	4
DI5		See selection DI1 .	5
AT LIMIT		Reset at the limit defined by parameter 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO	6
STRT/STP CMD		Counter reset at start/stop command. Source for the start/stop is selected by parameter 1911 CNTR S/S COMMAND .	7

All parameters			
No.	Name/Value	Description	Def/FbEq
	S/S CMD(INV)	Counter reset at start/stop command (inverted), ie counter is reset when start/stop command is deactivated. Start signal source is selected by parameter 1911 CNTR S/S COMMAND .	8
	RESET	Reset enabled	9
	SEQ PROG	Counter reset through Sequence programming state out control, ie counter is reset when Sequence programming enter to state1 and state1 out control source is selected to RST CNT NEXT by parameter 8423 ST1 OUT CONTROL .	10
	SEQ OR DI1	Counter reset through Sequence programming state out control or DI1 is active.	11
	SEQ OR DI2	See selection SEQ OR DI1.	12
	SEQ OR DI3	See selection SEQ OR DI1.	13
	SEQ OR DI4	See selection SEQ OR DI1.	14
	SEQ OR DI5	See selection SEQ OR DI1.	15
	SEQ OR CV1#0	Counter reset through Sequence programming state out control or 0135 COMM VALUE 1 bit 0 (1 = reset is active).	16
	SEQ OR CV1#1	See selection SEQ OR CV1#0.	17
	SEQ OR CV1#2	See selection SEQ OR CV1#0.	18
	SEQ OR CV1#3	See selection SEQ OR CV1#0.	19
	SEQ OR CV1#4	See selection SEQ OR CV1#0.	20
	SEQ OR CV1#5	See selection SEQ OR CV1#0.	21
	SEQ OR CV1#6	See selection SEQ OR CV1#0.	22
	SEQ OR CV1#7	See selection SEQ OR CV1#0.	23
1910	COUNT DIRECTION	Defines the source for the counter direction selection.	UP
	DI1(INV)	Counter direction selection through inverted digital input DI1. 1 = counts up, 0 = counts down.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	UP	Counts up	0
	DI1	Counter direction selection through digital input DI1. 0 = counts up, 1 = counts down.	1

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	DOWN	Counts down	6
	MOTOR DIR	Counter direction selection by the motor rotating direction. When motor is rotating forward then counter counts upwards. When motor is rotating reverse then counter counts down.	7
1911	CNTR S/S COMMAND	Selects the source for the drive start/stop command when parameter 1001 EXT1 COMMANDS value is set to COUNTER START / COUNTER STOP .	NOT SEL
	DI1(INV)	Start/stop command through inverted digital input DI1. When parameter 1001 EXT1 COMMANDS value is COUNTER STOP : 0 = start. Stop when counter limit defined by parameter 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO has been exceeded. When parameter 1001 value is COUNTER START : 0 = stop. Start when counter limit defined by parameter 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO has been exceeded.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	NOT SEL	Not start/stop command source	0
	DI1	Start/stop command through digital input DI1. When parameter 1001 EXT1 COMMANDS value is COUNTER STOP : 1 = start. Stop when counter limit defined by parameter 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO has been exceeded. When parameter 1001 value is COUNTER START : 1 = stop. Start when counter limit defined by parameter 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO has been exceeded.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	ACTIVATE	External start/stop command, eg through fieldbus	6

All parameters			
No.	Name/Value	Description	Def/FbEq
1912	TAR A HI VALUE	Defines Target A counts high word part (Target A counter is 32bit long double words which divide to high word and low word).	0
	0...65535	Setting the Target A high word part.	-
1913	TAR A LO VALUE	Defines Target A counts low word part.	0
	0...65535	Setting the Target A low word part.	-
1914	TAR B HI VALUE	See parameter 1912 TAR A HI VALUE	0
	0...65535	See parameter 1912 .	-
1915	TAR B LO VALUE	See parameter 1913 TAR A LO VALUE .	0
	0...65535	See parameter 1913 .	-
1916	TAR C HI VALUE	See parameter 1912 TAR A HI VALUE .	0
	0...65535	See parameter 1912 .	-
1917	TAR C LO VALUE	See parameter 1913 TAR A LO VALUE .	0
	0...65535	See parameter 1913 .	-
1918	TAR D HI VALUE	See parameter 1912 TAR A HI VALUE .	0
	0...65535	See parameter 1912 .	-
1919	TAR D LO VALUE	See parameter 1913 TAR A LO VALUE .	0
	0...65535	See parameter 1913 .	-
1920	TAR WINDOW ST	Defines size of positioning status target window. When the counter value enter the Target A(B...D) range which range is defined by target window, the corresponding bit (At Target A) of positioning status word (parameter 0190 POS STATUS) will be set.	0
	0...65535	Setting the target window.	-
1921	POS CORRECT	Defines positioning fine tuning parameter.	100%
	0...300%	Value as the multiplied ratio, it is multiplied with actual speed when using the sequence programing.	1 = 1%
1922	SLOWDOWN WINDOW	Defines size of positioning status target slowdown window.	0

All parameters			
No.	Name/Value	Description	Def/FbEq
0...65535		Slowdown window is used to judge range about slowdown status of each target is set or not. Example: When the counter value enter the range which form “Target A - slowdown window-target window” to “Target A - target window” or from “Target A +target window” to “Target A + slowdown window + target window”, the corresponding positioning slowdown bit (Slowdown A) of status word (parameter 0190 POS STATUS) will be set.	-
1923 COUNTER RES HI VAL		Defines the high part for the counter reset value.	0
0...32767		Counter value	-
1924 COUNTER RES LO VAL		Defines the low part for the counter reset value.	0
0...65535		Counter value	-
1925 COUNTER LIMIT HI		Defines the counter limit value high part.	0
0...32767		Limit value	-
1926 COUNTER LIMIT LO		Defines the counter limit value low part.	1000
0...65535		Limit value	-
1927 DI5 PPR		When DI5 as the counter input source, defines the number of DI5 pulses per one revolution.	1
0...16384		pulse number in pulses per round (ppr).	1 = 1 ppr
1928 COUNTER NUM		Defines the multiplier (numerator) for the pulse counter.	1
1...32767		counter value = pulse counter * numerator/denominator.	-
1929 COUNTER DEN		Defines the divider (denominator) for the pulse counter.	1
1...32767		counter value = pulse counter * numerator/denominator.	-
20 LIMITS		Drive operation limits. Speed values are used in vector control and frequency values are used in scalar control. The control mode is selected by parameter 9904 MOTOR CTRL MODE.	

All parameters			
No.	Name/Value	Description	Def/FbEq
2001	MINIMUM SPEED	<p>Defines the allowed minimum speed. A positive (or zero) minimum speed value defines two ranges, one positive and one negative. A negative minimum speed value defines one speed range.</p>  	0 rpm
	-30000... 30000 rpm	Minimum speed	1 = 1 rpm
2002	MAXIMUM SPEED	Defines the allowed maximum speed. See parameter 2001 MINIMUM SPEED .	E: 1500 rpm / U: 1800 rpm
	0...30000 rpm	Maximum speed	1 = 1 rpm
2013	MIN TORQUE SEL	Selects the minimum torque limit for the drive.	MIN TORQUE 1
	MIN TORQUE 1	Value defined by parameter 2015 MIN TORQUE 1	0
DI1		Digital input DI1. 0 = parameter 2015 MIN TORQUE 1 value. 1 = parameter 2016 MIN TORQUE 2 value.	1
DI2		See selection DI1 .	2
DI3		See selection DI1 .	3
DI4		See selection DI1 .	4
DI5		See selection DI1 .	5
COMM		<p>Fieldbus interface as the source for the torque limit 1/2 selection, ie Control word 0301 FB CMD WORD 1 bit 15. The Control word is sent by the fieldbus controller through the fieldbus adapter or embedded fieldbus (Modbus) to the drive.</p> <p>Minimum torque limit 1 is defined by parameter 2015 MIN TORQUE 1 and minimum torque limit 2 is defined by parameter 2016 MIN TORQUE 2.</p> <p>Note: This setting applies only for the DCU profile.</p>	7
EXT2		Value of signal 0112 EXTERNALREF 2	11

All parameters			
No.	Name/Value	Description	Def/FbEq
	SEQ OUT CTRL	Value of Sequence programing state out control negative value e.g 8423 ST1 OUT CONTROL which range is -600%~0. If SEQ PROG is disabled, value of MIN TORQUE 1 will be used.	12
	DI1(INV)	Inverted digital input DI1. 1 = value of parameter 2015 MIN TORQUE 1 1. 0 = value of parameter 2016 MIN TORQUE 2 .	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
2014	MAX TORQUE SEL	Selects the maximum torque limit for the drive.	MAX TORQUE 1
	MAX TORQUE 1	Value of parameter 2017 MAX TORQUE 1	
	DI1	Digital input DI1. 0 = parameter 2017 MAX TORQUE 1 value. 1 = parameter 2018 MAX TORQUE 2 value.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
COMM		Fieldbus interface as the source for the torque limit 1/2 selection, ie Control word 0301 FB CMD WORD 1 bit 15 bit 15. The Control word is sent by the fieldbus controller through the fieldbus adapter or embedded fieldbus (Modbus) to the drive. Maximum torque limit 1 is defined by parameter 2017 MAX TORQUE 1 and maximum torque limit 2 is defined by parameter 2018 MAX TORQUE 2 . Note: This setting applies only for the DCU profile.	7
EXT2		Value of signal 0112 EXTERNALREF 2	11
	SEQ OUT CTRL	Value of Sequence programing state out control value e.g 8423 ST1 OUT CONTROL which range is 0~600%. If SEQ PROG is disabled, value of MAX TORQUE 1 will be used.	12
	DI1(INV)	Inverted digital input DI1. 1 = parameter 2017 MAX TORQUE 1 value. 0 = parameter 2018 MAX TORQUE 2 value.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5

All parameters			
No.	Name/Value	Description	Def/FbEq
2015	MIN TORQUE 1 -600.0...0.0%	Defines minimum torque limit 1 for the drive. See parameter 2013 MIN TORQUE SEL . Value as a percentage of the motor nominal torque	-300% 1 = 0.1%
2016	MIN TORQUE 2 -600.0...0.0%	Defines minimum torque limit 2 for the drive. See parameter 2013 MIN TORQUE SEL . Value as a percentage of the motor nominal torque	-300% 1 = 0.1%
2017	MAX TORQUE 1 0.0...600.0%	Defines maximum torque limit 1 for the drive. See parameter 2014 MAX TORQUE SEL . Value as a percentage of the motor nominal torque	300% 1 = 0.1%
2018	MAX TORQUE 2 0.0...600.0%	Defines maximum torque limit 2 for the drive. See parameter 2014 MAX TORQUE SEL . Value as a percentage of the motor nominal torque	300% 1 = 0.1%
2021	MAX SPEED SEL PAR 2002 EXT REF 1	Maximum speed source for torque control Value of parameter 2002 MAXIMUM SPEED Value of signal 0111 EXTERNALREF 1	PAR 2002 0 1
	SEQ OUT CTRL	Mutilated results of Sequence programming state out control value and max speed (2002 MAXIMUM SPEED) e.g 8423 ST1 OUT CONTROL * 2002 MAXIMUM SPEED . If SEQ PROG is disabled, value of PAR 2002 will be used.	2
22 ACCEL/DECCEL			
2201	ACC/DEC 1/2 SEL NOT SEL DI1 DI2 DI3 DI4 DI5 COMM SEQ PROG DI1(INV) DI2(INV)	Acceleration and deceleration times Defines the source from which the drive reads the signal that selects between the two ramp pairs, acceleration/deceleration pair 1 and 2. Ramp pair 1 is defined by parameters 2202...2204 . Ramp pair 2 is defined by parameters 2205...2207 . Ramp pair 1 is used. Digital input DI1. 1 = ramp pair 2, 0 = ramp pair 1. See selection DI1 . See selection DI1 . See selection DI1 . See selection DI1 . Fieldbus interface as the source for ramp pair 1/2 selection, ie Control word 0301 FB CMD WORD 1 bit 10. The Control word is sent by the fieldbus controller through the fieldbus adapter or embedded fieldbus (Modbus) to the drive. Note: This setting applies only for the DCU profile. Sequence program ramp defined by parameter 8422 ST1 RAMP (or 8432/.../8492) Inverted digital input DI1. 0 = ramp pair 2, 1 = ramp pair 1. See selection DI1(INV) .	DI5 0 1 2 3 4 5 7 10 -1 -2

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
2202	ACCELER TIME 1	<p>Defines the acceleration time 1, ie the time required for the speed to change from zero to the speed defined by parameter <i>2008 MAXIMUM FREQ</i> (in scalar control) / <i>2002 MAXIMUM SPEED</i> (in vector control). The control mode is selected by parameter <i>9904 MOTOR CTRL MODE</i>.</p> <ul style="list-style-type: none"> If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate. If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference signal. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive operating limits. <p>Actual acceleration time depends on parameter 2204 RAMP SHAPE 1 setting.</p>	5.0 s
	0.0...1800.0 s	Time	1 = 0.1 s
2203	DECELER TIME 1	<p>Defines the deceleration time 1, ie the time required for the speed to change from the value defined by parameter <i>2008 MAXIMUM FREQ</i> (in scalar control) / <i>2002 MAXIMUM SPEED</i> (in vector control) to zero. The control mode is selected by parameter <i>9904 MOTOR CTRL MODE</i>.</p> <ul style="list-style-type: none"> If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the deceleration signal. If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate. If the deceleration time is set too short, the drive will automatically prolong the deceleration in order not to exceed drive operating limits. <p>If a short deceleration time is needed for a high inertia application, the drive should be equipped with a brake resistor.</p> <p>Actual deceleration time depends on parameter 2204 RAMP SHAPE 1 setting.</p>	5.0 s
	0.0...1800.0 s	Time	1 = 0.1 s

All parameters			
No.	Name/Value	Description	Def/FbEq
2204	RAMP SHAPE 1 0.0 = LINEAR 0.1...1000.0 s	<p>Selects the shape of the acceleration/deceleration ramp 1. The function is deactivated during emergency stop and jogging.</p> <p>0.0: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.</p> <p>0.1...1000.0 s: S-curve ramp. S-curve ramps are ideal for conveyors carrying fragile loads, or other applications where a smooth transition is required when changing from one speed to another. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.</p> <p>A rule of thumb: A suitable relation between the ramp shape time and the acceleration ramp time is 1/5.</p> <p>The graph shows two curves starting from the origin. The vertical axis is labeled 'Speed' and the horizontal axis is labeled 't'. A dashed line indicates the maximum speed. The first curve, labeled 'Linear ramp: Par. 2204 = 0 s', is a straight line reaching the maximum speed in a time interval labeled 'Par. 2202'. The second curve, labeled 'S-curve ramp: Par. 2204 > 0 s', follows a smooth S-shape, reaching the maximum speed in a longer time interval labeled 'Par. 2204'. The time interval 'Par. 2204' is shown to be approximately 5 times longer than 'Par. 2202'.</p>	0.0 = LINEAR 1 = 0.1 s
2205	ACCELER TIME 2 0.0...1800.0 s	<p>Defines the acceleration time 2, ie the time required for the speed to change from zero to the speed defined by parameter 2008 MAXIMUM FREQ (in scalar control) / 2002 MAXIMUM SPEED (in vector control). The control mode is selected by parameter 9904 MOTOR CTRL MODE.</p> <p>See parameter 2202 ACCELER TIME 1.</p> <p>Acceleration time 2 is used also as jogging acceleration time.</p>	60.0 s 1 = 0.1 s
2206	DECCELER TIME 2 0.0...1800.0 s	<p>Defines the deceleration time 2, ie the time required for the speed to change from the value defined by parameter 2008 MAXIMUM FREQ (in scalar control) / 2002 MAXIMUM SPEED (in vector control) to zero. The control mode is selected by parameter 9904 MOTOR CTRL MODE.</p> <p>See parameter 2203 DECELER TIME 1.</p> <p>Deceleration time 2 is used also as jogging deceleration time.</p>	60.0 s 1 = 0.1 s

All parameters			
No.	Name/Value	Description	Def/FbEq
2207	RAMP SHAPE 2 0.0 = LINEAR 0.1...1000.0 s	Selects the shape of the acceleration/deceleration ramp 2. The function is deactivated during emergency stop. During jogging, parameter value is set to zero (ie linear ramp). See parameter 2204 RAMP SHAPE 1 .	0.0 = LINEAR 1 = 0.1 s
32 SUPERVISION		Signal supervision. Supervision status can be monitored with relay or transistor output. See parameter groups 14 RELAY OUTPUTS and 18 FREQ IN & TRAN OUT .	
3201	SUPERV 1 PARAM	<p>Selects the first supervised signal. Supervision limits are defined by parameters 3202 SUPERV 1 LIM LO and 3203 SUPERV 1 LIM HI.</p> <p>Example 1: If $3202 \text{ SUPERV 1 LIM LO} \leq 3203 \text{ SUPERV 1 LIM HI}$</p> <p>Case A = 1401 RELAY OUTPUT 1 value is set to SUPRV1 OVER. Relay energizes when value of the signal selected with 3201 SUPERV 1 PARAM exceeds the supervision limit defined by 3203 SUPERV 1 LIM HI. The relay remains active until the supervised value drops below the low limit defined by 3202 SUPERV 1 LIM LO.</p> <p>Case B = 1401 RELAY OUTPUT 1 value is set to SUPRV1 UNDER. Relay energizes when value of the signal selected with 3201 SUPERV 1 PARAM drops below the supervision limit defined by 3202 SUPERV 1 LIM LO. The relay remains active until the supervised value rises above the high limit defined by 3203 SUPERV 1 LIM HI.</p>	103

All parameters			
No.	Name/Value	Description	Def/FbEq
		<p>Example 2: If 3202 SUPERV 1 LIM LO > 3203 SUPERV 1 LIM HI</p> <p>The lower limit 3203 SUPERV 1 LIM HI remains active until the supervised signal exceeds the higher limit 3202 SUPERV 1 LIM LO, making it the active limit. The new limit remains active until the supervised signal drops below the lower limit 3203 SUPERV 1 LIM HI, making it the active limit.</p> <p>Case A = 1401 RELAY OUTPUT 1 value is set to SUPRV1 OVER. Relay is energized whenever the supervised signal exceeds the active limit.</p> <p>Case B = 1401 RELAY OUTPUT 1 value is set to SUPRV1 UNDER. Relay is de-energized whenever the supervised signal drops below the active limit.</p>	
0, x...x		Parameter index in group 01 OPERATING DATA . Eg 102 = 0102 SPEED. 0 = not selected.	1 = 1
3202 SUPERV 1 LIM LO		Defines the low limit for the first supervised signal selected by parameter 3201 SUPERV 1 PARAM . Supervision wakes up if the value is below the limit.	-
x...x		Setting range depends on parameter 3201 setting.	-
3203 SUPERV 1 LIM HI		Defines the high limit for the first supervised signal selected by parameter 3201 SUPERV 1 PARAM . Supervision wakes up if the value is above the limit.	-
x...x		Setting range depends on parameter 3201 setting.	-
3204 SUPERV 2 PARAM		Selects the second supervised signal. Supervision limits are defined by parameters 3205 SUPERV 2 LIM LO and 3206 SUPERV 2 LIM HI . See parameter 3201 SUPERV 1 PARAM .	104
x...x		Parameter index in group 01 OPERATING DATA . Eg 102 = 0102 SPEED.	1 = 1

All parameters			
No.	Name/Value	Description	Def/FbEq
3205	SUPERV 2 LIM LO	Defines the low limit for the second supervised signal selected by parameter 3204 SUPERV 2 PARAM . Supervision wakes up if the value is below the limit.	-
	x...x	Setting range depends on parameter 3204 setting.	-
3206	SUPERV 2 LIM HI	Defines the high limit for the second supervised signal selected by parameter 3204 SUPERV 2 PARAM . Supervision wakes up if the value is above the limit.	-
	x...x	Setting range depends on parameter 3204 setting.	-
3207	SUPERV 3 PARAM	Selects the third supervised signal. Supervision limits are defined by parameters 3208 SUPERV 3 LIM LO and 3209 SUPERV 3 LIM HI . See parameter 3201 SUPERV 1 PARAM .	105
	x...x	Parameter index in group 01 OPERATING DATA . Eg 102 = 0102 SPEED .	1 = 1
3208	SUPERV 3 LIM LO	Defines the low limit for the third supervised signal selected by parameter 3207 SUPERV 3 PARAM . Supervision wakes up if the value is below the limit.	-
	x...x	Setting range depends on parameter 3207 setting.	-
3209	SUPERV 3 LIM HI	Defines the high limit for the third supervised signal selected by parameter 3207 SUPERV 3 PARAM . Supervision wakes up if the value is above the limit.	-
	x...x	Setting range depends on parameter 3207 setting.	-
33 INFORMATION		Firmware package version, test date etc.	
3301	FIRMWARE	Displays the version of the firmware package.	
	0000...FFFF hex	Eg 6200 hex	
36 TIMED FUNCTIONS		Time periods 1 to 4 and booster signal.	
3601	TIMERS ENABLE	Selects the source for the timed function enable signal.	NOT SEL
NOT SEL		Timed function is not selected.	0
DI1		Digital input DI. Timed function enable on the rising edge of DI1.	1
DI2		See selection DI1 .	2
DI3		See selection DI1 .	3
DI4		See selection DI1 .	4
DI5		See selection DI1 .	5
ACTIVE		Timed function is always enabled.	7
DI1(INV)		Inverted digital input DI1. Timed function enable on the falling edge of DI1.	-1
DI2(INV)		See selection DI1(INV) .	-2

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
3602	START TIME 1	Defines the daily start time 1. The time can be changed in 2-second steps. 00:00:00... 23:59:58 hours:minutes:seconds. Example: If parameter value is set to 07:00:00, timed function 1 is activated at 7:00 (7 a.m.).	00:00:00
3603	STOP TIME 1	Defines the daily stop time 1. The time can be changed in 2-second steps. 00:00:00... 23:59:58 hours:minutes:seconds. Example: If parameter value is set to 18:00:00, timed function 1 is deactivated at 18:00 (6 p.m.).	00:00:00
3604	START DAY 1	Defines the start day 1. MONDAY TUESDAY WEDNESDAY THURSDAY FRIDAY SATURDAY SUNDAY	MONDAY 1 2 3 4
3605	STOP DAY 1	Defines the stop day 1. See parameter 3604 START DAY 1 . Example: If parameter is set to FRIDAY , timed function 1 is deactivated on Friday midnight (23:59:58).	MONDAY
3606	START TIME 2	See parameter 3602 START TIME 1 .	
		See parameter 3602 START TIME 1 .	
3607	STOP TIME 2	See parameter 3603 STOP TIME 1 . See parameter 3603 STOP TIME 1 .	
3608	START DAY 2	See parameter 3604 START DAY 1 . See parameter 3604 START DAY 1 .	
3609	STOP DAY 2	See parameter 3605 STOP DAY 1 . See parameter 3605 STOP DAY 1 .	
3610	START TIME 3	See parameter 3602 START TIME 1 . See parameter 3602 START TIME 1 .	
3611	STOP TIME 3	See parameter 3603 STOP TIME 1 . See parameter 3603 STOP TIME 1 .	
3612	START DAY 3	See parameter 3604 START DAY 1 .	

All parameters			
No.	Name/Value	Description	Def/FbEq
		See parameter 3604 START DAY 1 .	
3613	STOP DAY 3	See parameter 3605 STOP DAY 1 .	
		See parameter 3605 STOP DAY 1 .	
3614	START TIME 4	See parameter 3602 START TIME 1 .	
		See parameter 3602 START TIME 1 .	
3615	STOP TIME 4	See parameter 3603 STOP TIME 1 .	
		See parameter 3603 STOP TIME 1 .	
3616	START DAY 4	See parameter 3604 START DAY 1 .	
		See parameter 3604 START DAY 1 .	
3617	STOP DAY 4	See parameter 3605 STOP DAY 1 .	
		See parameter 3605 STOP DAY 1 .	
3622	BOOSTER SEL	Selects the source for the booster activation signal.	NOT SEL
NOT SEL		No booster activation signal	0
DI1		Digital input DI1. 1 = active, 0 = inactive.	1
DI2		See selection DI1 .	2
DI3		See selection DI1 .	3
DI4		See selection DI1 .	4
DI5		See selection DI1 .	5
DI1(INV)		Inverted digital input DI1. 0 = active, 1 = inactive.	-1
DI2(INV)		See selection DI1(INV) .	-2
DI3(INV)		See selection DI1(INV) .	-3
DI4(INV)		See selection DI1(INV) .	-4
DI5(INV)		See selection DI1(INV) .	-5
3623	BOOSTER TIME	Defines the time inside which the booster is deactivated after the booster activation signal is switched off.	00:00:00
00:00:00... 23:59:58		hours:minutes:seconds Example: If parameter 3622 BOOSTER SEL is set to DI1 and 3623 BOOSTER TIME is set to 01:30:00, the booster is active for 1 hour and 30 minutes after digital input DI is deactivated.	

All parameters			
No.	Name/Value	Description	Def/FbEq
3626	TIMED FUNC 1 SRC	Selects the time periods for <i>TIMED FUNC 1 SRC</i> . Timed function can consist of 0...4 time periods and a booster.	NOT SEL
	NOT SEL	No time periods selected	0
	T1	Time period 1	1
	T2	Time period 2	2
	T1+T2	Time periods 1 and 2	3
	T3	Time period 3	4
	T1+T3	Time periods 1 and 3	5
	T2+T3	Time periods 2 and 3	6
	T1+T2+T3	Time periods 1, 2 and 3	7
	T4	Time period 4	8
	T1+T4	Time periods 1 and 4	9
	T2+T4	Time periods 2 and 4	10
	T1+T2+T4	Time periods 1, 2 and 4	11
	T3+T4	Time periods 4 and 3	12
	T1+T3+T4	Time periods 1, 3 and 4	13
	T2+T3+T4	Time periods 2, 3 and 4	14
	T1+T2+T3+T4	Time periods 1, 2, 3 and 4	15
	BOOSTER	Booster	16
	T1+B	Booster and time period 1	17
	T2+B	Booster and time period 2	18
	T1+T2+B	Booster and time periods 1 and 2	19
	T3+B	Booster and time period 3	20
	T1+T3+B	Booster and time periods 1 and 3	21
	T2+T3+B	Booster and time periods 2 and 3	22
	T1+T2+T3+B	Booster and time periods 1, 2 and 3	23
	T4+B	Booster and time period 4	24
	T1+T4+B	Booster and time periods 1 and 4	25
	T2+T4+B	Booster and time periods 2 and 4	26
	T1+T2+T4+B	Booster and time periods 1, 2 and 4	27
	T3+T4+B	Booster and time periods 3 and 4	28
	T1+T3+T4+B	Booster and time periods 1, 3 and 4	29
	T2+T3+T4+B	Booster and time periods 2, 3 and 4	30
	T1+2+3+4+B	Booster and time periods 1, 2, 3 and 4	31
3627	TIMED FUNC 2 SRC	See parameter <i>3626 TIMED FUNC 1 SRC</i> .	
		See parameter <i>3626 TIMED FUNC 1 SRC</i> .	

All parameters			
No.	Name/Value	Description	Def/FbEq
3628	TIMED FUNC 3 SRC	See parameter 3626 TIMED FUNC 1 SRC .	
		See parameter 3626 TIMED FUNC 1 SRC .	
3629	TIMED FUNC 4 SRC	See parameter 3626 TIMED FUNC 1 SRC .	
		See parameter 3626 TIMED FUNC 1 SRC .	
50 ENCODER	Encoder connection.		
	For more information, see <i>MTAC-01 pulse encoder interface module user's manual</i> (3AFE68591091 [English]).		
5001	PULSE NR	States the number of encoder pulses per one revolution.	1024 ppr
	32...16384 ppr	Pulse number in pulses per round (ppr)	1 = 1 ppr
5002	ENCODER ENABLE	Enables the encoder.	DISABLE
	DISABLE	Disabled	0
	ENABLE	Enabled	1
5003	ENCODER FAULT	Defines the operation of the drive if a failure is detected in communication between the pulse encoder and the pulse encoder interface module, or between the module and the drive.	FAULT
	FAULT	The drive trips on fault ENCODER ERR (0023).	1
	ALARM	The drive generates alarm ENCODER ERR (2024).	2
5010	Z PLS ENABLE	Enables the encoder zero (Z) pulse. Zero pulse is used for position reset.	DISABLE
	DISABLE	Disabled	0
	ENABLE	Enabled	1
5011	POSITION RESET	Enables the position reset.	DISABLE
	DISABLE	Disabled	0
	ENABLE	Enabled	1
84 SEQUENCE PROG	Sequence program group 1. See section Settings on page 36 .		
	8401 SEQ PROG ENABLE	Enables Sequence program. If Sequence program enable signal is lost, the Sequence program is stopped. Sequence program state (0168 SEQ PROG STATE) is set to 1 and all timers and outputs (RO/TO/AO) are set to zero.	DISABLE D
	DISABLED	Disabled	0
	EXT2	Enabled in external control location 2 (EXT2)	1
	EXT1	Enabled in external control location 1 (EXT1)	2
	EXT1&EXT2	Enabled in external control locations 1 and 2 (EXT1 and EXT2)	3

All parameters			
No.	Name/Value	Description	Def/FbEq
	ALWAYS	Enabled in external control locations 1 and 2 (EXT1 and EXT2) and in local control (LOCAL)	4
8402	SEQ PROG START	<p>Selects the source for the Sequence program activation signal.</p> <p>When Sequence program is activated, the program starts from the previously used state.</p> <p>If Sequence program activation signal is lost, the Sequence program is stopped and all timers and outputs (RO/TO/AO) are set to zero. Sequence program state (0168 SEQ PROG STATE) remains unchanged.</p> <p>If start from the first Sequence program state is required, the Sequence program must be reset by parameter 8404 SEQ PROG RESET. If start from the first Sequence program state is always required, reset and start signal sources (8404 and 8402 SEQ PROG START) must be through the same digital input.</p> <p>Note: The drive will not start if no Run enable signal is received (1601 RUN ENABLE).</p>	NOT SEL
	DI1(INV)	Sequence program activation through inverted digital input DI1. 0 = active, 1 = inactive.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	NOT SEL	No Sequence program activation signal	0
	DI1	Sequence program activation through digital input DI1. 1 = active, 0 = inactive.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	DRIVE START	Sequence program activation at drive start	6
	TIMED FUNC 1	Sequence program is activated by timed function 1. See parameter group 36 TIMED FUNCTIONS .	7
	TIMED FUNC 2	See selection TIMED FUNC 1 .	8
	TIMED FUNC 3	See selection TIMED FUNC 1 .	9
	TIMED FUNC 4	See selection TIMED FUNC 1 .	10
	RUNNING	Sequence program is always active.	11

All parameters			
No.	Name/Value	Description	Def/FbEq
8403	SEQ PROG PAUSE	Selects the source for the Sequence program pause signal. When Sequence program pause is activated, all timers and outputs (RO/TO/AO) are frozen. Sequence program state transition is possible only by parameter 8405 SEQ ST FORCE .	NOT SEL
	DI1(INV)	Pause signal through inverted digital input DI1. 0 = active, 1 = inactive.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	NOT SEL	No pause signal	0
	DI1	Pause signal through digital input DI1. 1 = active, 0 = inactive.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	PAUSED	Sequence program pause enabled	6
8404	SEQ PROG RESET	Selects the source for the Sequence program reset signal. Sequence program state (0168 SEQ PROG STATE) is set to the first state and all timers and outputs (RO/TO/AO) are set to zero. Reset is possible only when Sequence program is stopped.	NOT SEL
	DI1(INV)	Reset through inverted digital input DI1. 0 = active, 1 = inactive.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	NOT SEL	No reset signal	0
	DI1	Reset through digital input DI1. 1 = active, 0 = inactive.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	RESET	Reset. After reset parameter value is automatically set to NOT SEL .	6

All parameters			
No.	Name/Value	Description	Def/FbEq
8405	SEQ ST FORCE	Forces the Sequence program to a selected state. Note: State is changed only when Sequence program is paused by parameter 8403 SEQ PROG PAUSE and this parameter is set to the selected state.	STATE 1
	STATE 1	State is forced to state 1.	1
	STATE 2	State is forced to state 2.	2
	STATE 3	State is forced to state 3.	3
	STATE 4	State is forced to state 4.	4
	STATE 5	State is forced to state 5.	5
	STATE 6	State is forced to state 6.	6
	STATE 7	State is forced to state 7.	7
	STATE 8	State is forced to state 8.	8
	STATE 9	State is forced to state 9.	9
	STATE 10	State is forced to state 10.	10
	STATE 11	State is forced to state 11.	11
	STATE 12	State is forced to state 12.	12
	STATE 13	State is forced to state 13.	13
	STATE 14	State is forced to state 14.	14
	STATE 15	State is forced to state 15.	15
	STATE 16	State is forced to state 16.	16
8406	SEQ LOGIC VAL 1	Defines the source for the logic value 1. Logic value 1 is compared to logic value 2 as defined by parameter 8407 SEQ LOGIC OPER 1 . Logic operation values are used in state transitions. See parameter 8425 ST1 TRIG TO ST 2 / 8426 ST1 TRIG TO ST N selection LOGIC VAL .	NOT SEL
	DI1(INV)	Logic value 1 through inverted digital input DI1	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	NOT SEL	No logic value	0
	DI1	Logic value 1 through digital input DI1	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	SUPRV1 OVER	Logic value according to supervision parameters 3201...3203 . See parameter group 32 SUPERVISION .	6

All parameters			
No.	Name/Value	Description	Def/FbEq
	SUPRV2 OVER	Logic value according to supervision parameters 3204...3206 . See parameter group 32 SUPERVISION .	7
	SUPRV3 OVER	Logic value according to supervision parameters 3207...3209 . See parameter group 32 SUPERVISION .	8
	SUPRV1 UNDER	See selection SUPRV1 OVER .	9
	SUPRV2 UNDER	See selection SUPRV2 OVER .	10
	SUPRV3 UNDER	See selection SUPRV3 OVER .	11
	TIMED FUNC 1	Logic value 1 is activated by timed function 1. See parameter group 36 TIMED FUNCTIONS . 1 = timed function active.	12
	TIMED FUNC 2	See selection TIMED FUNC 1 .	13
	TIMED FUNC 3	See selection TIMED FUNC 1 .	14
	TIMED FUNC 4	See selection TIMED FUNC 1 .	15
	COMM VAL1 #0	Logic value 1 is activated by 0135 COMM VALUE 1 bit 0.	16
	COMM VAL1 #1	Logic value 1 is activated by 0135 COMM VALUE 1 bit 1.	17
	COMM VAL1 #2	Logic value 1 is activated by 0135 COMM VALUE 1 bit 2.	18
	COMM VAL1 #3	Logic value 1 is activated by 0135 COMM VALUE 1 bit 3.	19
	COMM VAL1 #4	Logic value 1 is activated by 0135 COMM VALUE 1 bit 4.	20
	COMM VAL1 #5	Logic value 1 is activated by 0135 COMM VALUE 1 bit 5.	21
	COMM VAL1 #6	Logic value 1 is activated by 0135 COMM VALUE 1 bit 6.	22
	COMM VAL1 #7	Logic value 1 is activated by 0135 COMM VALUE 1 bit 7.	23
	COMM VAL1 #8	Logic value 1 is activated by 0135 COMM VALUE 1 bit 8.	24
	COMM VAL1 #9	Logic value 1 is activated by 0135 COMM VALUE 1 bit 9.	25
	COMM VAL1 #10	Logic value 1 is activated by 0135 COMM VALUE 1 bit 10.	26
	COMM VAL1 #11	Logic value 1 is activated by 0135 COMM VALUE 1 bit 11.	27
	COMM VAL1 #12	Logic value 1 is activated by 0135 COMM VALUE 1 bit 12.	28
	COMM VAL1 #13	Logic value 1 is activated by 0135 COMM VALUE 1 bit 13.	29

All parameters			
No.	Name/Value	Description	Def/FbEq
	COMM VAL1 #14	Logic value 1 is activated by 0135 COMM VALUE 1 bit 14.	30
	COMM VAL1 #15	Logic value 1 is activated by 0135 COMM VALUE 1 bit 15.	31
	CHANGE DLY	Logic value 1 is activated by delay time (defined by current state's CHANGE DELAY TIME) has elapsed.	32
	AI1HIGH1	Logic value 1 is activated when AI1 value > par. 8411 SEQ VAL 1 HIGH value.	33
	AI1LOW1	Logic value 1 is activated when AI1 value < par. 8412 SEQ VAL 1 LOW value.	34
	AI2HIGH2	Logic value 1 is activated when AI1 value > par. 8413 SEQ VAL 2 HIGH value.	35
	AI2LOW2	Logic value 1 is activated when AI1 value < par. 8414 SEQ VAL 2 LOW value.	36
	AI1	Logic value 1 is activated if AI1 value is valid.	37
	AI2	Logic value 1 is activated if AI2 value is valid.	38
8407	SEQ LOGIC OPER 1	Selects the operation between logic value 1 and 2. Logic operation values are used in state transitions. See parameter 8425 ST1 TRIG TO ST 2 / 8426 ST1 TRIG TO ST N selection LOGIC VAL .	NOT SEL
	NOT SEL	Logic value 1 (no logic comparison)	0
	AND	Logic function: AND	1
	OR	Logic function: OR	2
	XOR	Logic function: XOR	3
	HIGHER	Logic function: HIGHER	4
	LOWER	Logic function: LOWER	5
	EQUAL	Logic function: EQUAL	6
8408	SEQ LOGIC VAL 2	See parameter 8406 SEQ LOGIC VAL 1 .	NOT SEL
		See parameter 8406 .	
8409	SEQ LOGIC OPER 2	Selects the operation between logic value 3 and the result of the first logic operation defined by parameter 8407 SEQ LOGIC OPER 1 .	NOT SEL
	NOT SEL	Logic value 2 (no logic comparison)	0
	AND	Logic function: AND	1
	OR	Logic function: OR	2
	XOR	Logic function: XOR	3
	HIGHER	Logic function: HIGHER	4
	LOWER	Logic function: LOWER	5
	EQUAL	Logic function: EQUAL	6

All parameters			
No.	Name/Value	Description	Def/FbEq
8410	SEQ LOGIC VAL 3	See parameter 8406 SEQ LOGIC VAL 1.	NOT SEL
		See parameter 8406.	
8411	SEQ VAL 1 HIGH	Defines the high limit for the state change when parameter 8425 ST1 TRIG TO ST 2 is set to eg AI 1 HIGH 1.	0.0%
0.0...100.0%		Value as a percentage	1 = 0.1%
8412	SEQ VAL 1 LOW	Defines the low limit for the state change when parameter 8425 ST1 TRIG TO ST 2 is set to eg AI 1 LOW 1.	0.0%
0.0...100.0%		Value as a percentage	1 = 0.1%
8413	SEQ VAL 2 HIGH	Defines the high limit for the state change when parameter 8425 ST1 TRIG TO ST 2 is set to eg AI 2 HIGH 1.	0.0%
0.0...100.0%		Value as a percentage	1 = 0.1%
8414	SEQ VAL 2 LOW	Defines the low limit for the state change when parameter 8425 ST1 TRIG TO ST 2 is set to eg AI 2 LOW 1.	0.0%
0.0...100.0%		Value as a percentage	1 = 0.1%
8415	CYCLE CNT LOC	Activates the cycle counter for Sequence program. Example: When parameter is set to ST6 TO NEXT , the cycle count (0171 SEQ CYCLE CNTR) increases every time the state changes from state 6 to state 7.	NOT SEL
NOT SEL		Disabled	0
ST1 TO NEXT		From state 1 to state 2	1
ST2 TO NEXT		From state 2 to state 3	2
ST3 TO NEXT		From state 3 to state 4	3
ST4 TO NEXT		From state 4 to state 5	4
ST5 TO NEXT		From state 5 to state 6	5
ST6 TO NEXT		From state 6 to state 7	6
ST7 TO NEXT		From state 7 to state 8	7
ST8 TO NEXT		From state 8 to state 9	8
ST1 TO N		From state 1 to state n. State n is defined by parameter 8427 ST1 STATE N.	9
ST2 TO N		From state 2 to state n. State n is defined by parameter 8437 ST2 STATE N , see 8427 ST1 STATE N.	10
ST3 TO N		From state 3 to state n. State n is defined by parameter 8447 ST3 STATE N , see 8427 ST1 STATE N.	11
ST4 TO N		From state 4 to state n. State n is defined by parameter 8457 ST4 STATE N , see 8427 ST1 STATE N.	12
ST5 TO N		From state 5 to state n. State n is defined by parameter 8467 ST5 STATE N , see 8427 ST1 STATE N.	13
ST6 TO N		From state 6 to state n. State n is defined by parameter 8477 ST6 STATE N , see 8427 ST1 STATE N.	14

All parameters			
No.	Name/Value	Description	Def/FbEq
	ST7 TO N	From state 7 to state n. State n is defined by parameter 8487 ST7 STATE N, see 8427 ST1 STATE N .	15
	ST8 TO N	From state 8 to state n. State n is defined by parameter 8497 ST8 STATE N, see 8427 ST1 STATE N .	16
	ST9 TO NEXT	From state 9 to state 10	17
	ST10 TO NEXT	From state 10 to state 11	18
	ST11 TO NEXT	From state 11 to state 12	19
	ST12 TO NEXT	From state 12 to state 13	20
	ST13 TO NEXT	From state 13 to state 14	21
	ST14 TO NEXT	From state 14 to state 15	22
	ST15 TO NEXT	From state 15 to state 16	23
	ST16 TO NEXT	From state 16 to state 1	24
	ST9 TO N	From state 9 to state n. State n is defined by parameter 8527 ST9 STATE N, see 8427 ST1 STATE N .	25
	ST10 TO N	From state 10 to state n. State n is defined by parameter 8537 ST10 STATE N, see 8427 ST1 STATE N .	26
	ST11 TO N	From state 11 to state n. State n is defined by parameter 8547 ST11 STATE N, see 8427 ST1 STATE N .	27
	ST12 TO N	From state 12 to state n. State n is defined by parameter 8557 ST12 STATE N, see 8427 ST1 STATE N .	28
	ST13 TO N	From state 13 to state n. State n is defined by parameter 8567 ST13 STATE N, see 8427 ST1 STATE N .	29
	ST14 TO N	From state 14 to state n. State n is defined by parameter 8577 ST14 STATE N, see 8427 ST1 STATE N .	30
	ST15 TO N	From state 15 to state n. State n is defined by parameter 8587 ST15 STATE N, see 8427 ST1 STATE N .	31
	ST16 TO N	From state 16 to state n. State n is defined by parameter 8597 ST16 STATE N, see 8427 ST1 STATE N .	32
	ST1 TO N2	From state 1 to state n2. State n2 is defined by parameter 8429 ST1 STATE N2 .	33
	ST2 TO N2	From state 2 to state n2. State n2 is defined by parameter 8439 ST2 STATE N2, see 8429 ST1 STATE N2 .	34
	ST3 TO N2	From state 3 to state n2. State n2 is defined by parameter 8449 ST3 STATE N2, see 8429 ST1 STATE N2 .	35
	ST4 TO N2	From state 4 to state n2. State n2 is defined by parameter 8459 ST4 STATE N2, see 8429 ST1 STATE N2 .	36
	ST5 TO N2	From state 5 to state n2. State n2 is defined by parameter 8469 ST5 STATE N2, see 8429 ST1 STATE N2 .	37
	ST6 TO N2	From state 6 to state n2. State n2 is defined by parameter 8479 ST6 STATE N2, see 8429 ST1 STATE N2 .	38

All parameters			
No.	Name/Value	Description	Def/FbEq
	ST7 TO N2	From state 7 to state n2. State n2 is defined by parameter 8489 ST7 STATE N2, see 8429 ST1 STATE N2 .	39
	ST8 TO N2	From state 8 to state n2. State n2 is defined by parameter 8511 ST8 STATE N2, see 8429 ST1 STATE N2 .	40
	ST9 TO N2	From state 9 to state n2. State n2 is defined by parameter 8429 ST9 STATE N2, see 8429 ST1 STATE N2 .	41
	ST10 TO N2	From state 10 to state n2. State n2 is defined by parameter 8539 ST10 STATE N2, see 8429 ST1 STATE N2 .	42
	ST11 TO N2	From state 11 to state n2. State n2 is defined by parameter 8549 ST11 STATE N2, see 8429 ST1 STATE N2 .	43
	ST12 TO N2	From state 12 to state n2. State n2 is defined by parameter 8559 ST12 STATE N2, see 8429 ST1 STATE N2 .	44
	ST13 TO N2	From state 13 to state n2. State n2 is defined by parameter 8569 ST13 STATE N2, see 8429 ST1 STATE N2 .	45
	ST14 TO N2	From state 14 to state n2. State n2 is defined by parameter 8579 ST14 STATE N2, see 8429 ST1 STATE N2 .	46
	ST15 TO N2	From state 15 to state n2. State n2 is defined by parameter 8589 ST15 STATE N2, see 8429 ST1 STATE N2 .	47
	ST16 TO N2	From state 16 to state n2. State n2 is defined by parameter 8599 ST16 STATE N2, see 8429 ST1 STATE N2 .	48
	ST9 TO N3	From state 9 to state n3. State n3 is defined by parameter 8513 ST9 STATE N3.	57
	ST10 TO N3	From state 10 to state n3. State n3 is defined by parameter 8517 ST10 STATE N3	58
	ST9 TO N4	From state 9 to state n4. State n4 is defined by parameter 8515 ST9 STATE N2.	73
	St10 TO N4	From state 10 to state n4. State n4 is defined by parameter 8519 ST15 STATE N2.	74
	STATE1 ENTER	The cycle count (0171 SEQ CYCLE CNTR) increases every time the state enter to state1 from other state.	81
	STATE2 ENTER	Enters the state 2.	82
	STATE3 ENTER	Enters the state 3.	83
	STATE4 ENTER	Enters the state 4.	84
	STATE5 ENTER	Enters the state 5.	85
	STATE6 ENTER	Enters the state 6	86
	STATE7 ENTER	Enters the state 7.	87

All parameters			
No.	Name/Value	Description	Def/FbEq
	STATE8 ENTER	Enters the state 8.	88
	STATE9 ENTER	Enters the state 9.	89
	STATE10 ENTER	Enters the state 10.	90
	STATE11 ENTER	Enters the state 11.	91
	STATE12 ENTER	Enters the state 12.	92
	STATE13 ENTER	Enters the state 13.	93
	STATE14 ENTER	Enters the state 14.	94
	STATE15 ENTER	Enters the state 15.	95
	STATE16 ENTER	Enters the state 16.	96
8416	CYCLE CNT RST	Selects the source for the cycle counter reset signal (0171 NOT SEL SEQ CYCLE CNTR).	
	DI1(INV)	Reset through inverted digital input DI1. 0 = active, 1 = inactive.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	NOT SEL	No reset signal	0
	DI1	Reset through digital input DI1. 1 = active, 0 = inactive.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5
	STATE 1	Reset during state transition to state 1. Counter is reset, when the state has been reached.	6
	STATE 2	Reset during state transition to state 2. Counter is reset, when the state has been reached.	7
	STATE 3	Reset during state transition to state 3. Counter is reset, when the state has been reached.	8
	STATE 4	Reset during state transition to state 4. Counter is reset, when the state has been reached.	9
	STATE 5	Reset during state transition to state 5. Counter is reset, when the state has been reached.	10

All parameters			
No.	Name/Value	Description	Def/FbEq
	STATE 6	Reset during state transition to state 6. Counter is reset, when the state has been reached.	11
	STATE 7	Reset during state transition to state 7. Counter is reset, when the state has been reached.	12
	STATE 8	Reset during state transition to state 8. Counter is reset, when the state has been reached.	13
	SEQ PROG RST	Reset signal source defined by parameter 8404 SEQ PROG RESET	14
	STATE 9	Reset during state transition to state 9. Counter is reset, when the state has been reached.	15
	STATE 10	Reset during state transition to state 10. Counter is reset, when the state has been reached.	16
	STATE 11	Reset during state transition to state 11. Counter is reset, when the state has been reached.	17
	STATE 12	Reset during state transition to state 12. Counter is reset, when the state has been reached.	18
	STATE 13	Reset during state transition to state 13. Counter is reset, when the state has been reached.	19
	STATE 14	Reset during state transition to state 14. Counter is reset, when the state has been reached.	20
	STATE 15	Reset during state transition to state 15. Counter is reset, when the state has been reached.	21
	STATE 16	Reset during state transition to state 16. Counter is reset, when the state has been reached.	22
8420 ST1 REF SEL		Selects the source for the Sequence program state 1 reference. Parameter is used when parameter 1103 REF1 SELECT or 1106 REF2 SELECT is set to SEQ PROG / AI1+SEQ PROG / AI2+SEQ PROG . Note: Constant speeds in group 12 CONSTANT SPEEDS overwrite the selected Sequence program reference.	0.0%
COMM		0136 COMM VALUE 2 .	-1.3
AI1/AI2		Reference is calculated with the following equation: REF = AI1(%) · (50% / AI2 (%))	-1.2
AI1-AI2		Reference is calculated with the following equation: REF = AI1(%) + 50% - AI2(%)	-1.1
AI1*AI2		Reference is calculated with the following equation: REF = AI1(%) · (AI2(%) / 50%)	-1.0
AI1+AI2		Reference is calculated with the following equation: REF = AI1(%) + AI2(%) - 50%	-0.9
DI4U,5D		Digital input DI4: Reference increase. Digital input DI5: Reference decrease.	-0.8

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI3U,4D	Digital input DI3: Reference increase. Digital input DI4: Reference decrease.	-0.7
	DI3U,4DR	Digital input DI3: Reference increase. Digital input DI4: Reference decrease.	-0.6
	AI2 JOY	Analog input AI2 as joystick. The minimum input signal runs the motor at the maximum reference in the reverse direction, the maximum input at the maximum reference in the forward direction. Minimum and maximum references are defined by parameters 1104 REF1 MIN and 1105 REF1 MAX . See parameter 1103 REF1 SELECT selection AI1/JOYST for more information.	-0.5
	AI1 JOY	See selection AI2 JOY .	-0.4
	AI2	Analog input AI2	-0.3
	AI1	Analog input AI1	-0.2
	KEYPAD	Control panel	-0.1
	0.0 ... 100.0%	Constant speed	1 = 0.1%
8421	ST1 COMMANDS	Selects the start, stop and direction for state 1. Parameter 1002 EXT2 COMMANDS must be set to SEQ PROG . Note: If change of direction of rotation is required, parameter 1003 DIRECTION must be set to REQUEST .	DRIVE STOP
	DRIVE STOP	Drive coast or ramps to stop depending on parameter 2102 STOP FUNCTION setting.	0
	START FRW	Direction or rotation is fixed to forward. If the drive is not already running, it is started according to parameter 2101 START FUNCTION settings.	1
	START REV	Direction or rotation is fixed to reverse. If the drive is not already running, it is started according to parameter 2101 START FUNCTION settings.	2
	TARGET A	Drive make the motor toward the Target A (parameter 1912,1913) automatically. Direction or rotation is fixed by current position (parameter 0192,0193 COUNTER VALUE) and Target A.	3
	TARGET B	Drive make the motor toward the Target B (parameter 1914,1915) automatically. Direction or rotation is fixed by current position (parameter 0192,0193 COUNTER VALUE) and Target B.	4
	TARGET C	Drive make the motor toward the Target C (parameter 1916,1917) automatically. Direction or rotation is fixed by current position (parameter 0192,0193 COUNTER VALUE) and Target C.	5

All parameters			
No.	Name/Value	Description	Def/FbEq
	TARGET D	Drive make the motor toward the Target D (parameter 1918,1919) automatically. Direction or rotation is fixed by current position (parameter 0192,0193 COUNTER VALUE) and Target D.	6
8422	ST1 RAMP	Selects the acceleration/deceleration ramp time for Sequence program state 1, ie defines the rate of the reference change.	0.0 s
	-0.2/-0.1/ 0.0...1800.0 s	<p>Time</p> <p>When value is set to -0.2, ramp pair 2 is used. Ramp pair 2 is defined by parameters 2205...2207.</p> <p>When value is set to -0.1, ramp pair 1 is used. Ramp pair 1 is defined by parameters 2202...2204.</p> <p>With ramp pair 1/2, parameter 2201 ACC/DEC 1/2 SEL must be set to SEQ PROG. See also parameters 2202...2207.</p>	1 = 0.1 s
8423	ST1 OUT CONTROL	<p>Selects the relay, transistor and analog output control for Sequence program state 1.</p> <p>The relay/transistor output control must be activated by setting parameter 1401 RELAY OUTPUT 1 / 1805 DO SIGNAL to SEQ PROG. Analog output control must be activated by parameter group 15 ANALOG OUTPUTS.</p> <p>Analog output control values can be monitored with signal 0170 SEQ PROG AO VAL.</p>	AO=0
	RST CNT NEXT	When state x trigger to next and parameter 1907 COUNTER RESET set to sequence programing, parameter 0192,0193 COUNTER VALUE will be reset to parameter 1923,1924 RESET VALUE .	-1.0
	RST CNT STNX	When state 1 trigger to STN, STN2, STN3 or STN4 and parameter 1907 COUNTER RESET set to sequence programing, parameter 0192,0193 COUNTER VALUE will be reset to parameter 1923,1924 RESET VALUE .	-0.9
	RST CNT ENT	When enter to the state 1 and parameter 1907 COUNTER RESET set to sequence programing, parameter 0192,0193 COUNTER VALUE will be reset to parameter 1923,1924 RESET VALUE .	-0.8
	R=0,D=1,AO=0	Relay output is de-energized (opened), transistor output is energized and analog output is cleared.	-0.7
	R=1,D=0,AO=0	Relay output is energized (closed), transistor output is de-energized and analog output is cleared.	-0.6
	R=0,D=0,AO=0	Relay and transistor outputs are de-energized (opened) and analog output value is set to zero.	-0.5
	RO=0,DO=0	Relay and transistor outputs are de-energized (opened) and analog output control is frozen to the previously set value.	-0.4

All parameters			
No.	Name/Value	Description	Def/FbEq
	RO=1,DO=1	Relay and transistor outputs are energized (closed) and analog output control is frozen to the previously set value.	-0.3
	DO=1	Transistor output is energized (closed) and relay output is de-energized. Analog output control is frozen to the previously set value.	-0.2
	RO=1	Transistor output is de-energized (opened) and relay output is energized. Analog output control is frozen to the previously set value.	-0.1
	AO=0	Analog output value is set to zero. Relay and transistor outputs are frozen to the previously set value.	0.0
	0.1...600.0%	<p>Value written to signal 0170 SEQ PROG AO VAL. Value can be connected to control analog output AO by setting parameter 1501 AO1 CONTENT SEL value to 170 (ie signal 0170 SEQ PROG AO VAL). AO value is frozen to this value until it is zeroed.</p> <p>This parameter is also used as Torque min/max limit or Max speed limit if 2013 MIN TORQUE SEL, 2014 MAX TORQUE SEL or 2201 MAX SPEED SEL selects SEQ OUT CTRL.</p>	
8424	ST1 CHANGE DLY	Defines the delay time for state 1. When delay has elapsed, state transition is allowed. See parameters 8425 ST1 TRIG TO ST 2 and 8426 ST1 TRIG TO ST N .	0.0 s
	0.0...6553.5 s	Delay time	1 = 0.1 s
8425	ST1 TRIG TO ST 2	<p>Selects the source for the trigger signal which changes the state from state 1 to state 2.</p> <p>Note: State change to state N (8426 ST1 TRIG TO ST N) has a higher priority than state change to the next state (8425 ST1 TRIG TO ST 2).</p>	NOT SEL
	DI1(INV)	Trigger through inverted digital input DI1. 0 = active, 1 = inactive.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
	NOT SEL	No trigger signal. If parameter 8426 ST1 TRIG TO ST N setting is also NOT SEL , the state is frozen and can be reset only with parameter 8402 SEQ PROG START .	0
	DI1	Trigger through digital input DI1. 1 = active, 0 = inactive.	1
	DI2	See selection DI1 .	2
	DI3	See selection DI1 .	3
	DI4	See selection DI1 .	4
	DI5	See selection DI1 .	5

All parameters			
No.	Name/Value	Description	Def/FbEq
	AI 1 LOW 1	State change when AI1 value < par. 8412 SEQ VAL 1 LOW value.	6
	AI 1 HIGH 1	State change when AI1 value > par. 8411 SEQ VAL 1 HIGH value.	7
	AI 2 LOW 1	State change when AI2 value < par. 8412 SEQ VAL 1 LOW value.	8
	AI 2 HIGH 1	State change when AI2 value > par. 8411 SEQ VAL 1 HIGH value.	9
	AI1 OR 2 LO1	State change when AI1 or AI2 value < par. 8412 SEQ VAL 1 LOW value.	10
	AI1LO1AI2HI1	State change when AI1 value < par. 8412 SEQ VAL 1 LOW value and AI2 value > par. 8411 SEQ VAL 1 HIGH value.	11
	AI1LO1 ORDI5	State change when AI1 value < par. 8412 SEQ VAL 1 LOW value or when DI5 is active.	12
	AI2HI1 ORDI5	State change when AI2 value > par. 8411 SEQ VAL 1 HIGH value or when DI5 is active.	13
	AI 1 LOW 2	State change when AI1 value < par. 8414 SEQ VAL 2 LOW value.	14
	AI 1 HIGH 2	State change when AI1 value > par. 8413 SEQ VAL 2 HIGH value.	15
	AI 2 LOW 2	State change when AI2 value < par. 8414 SEQ VAL 2 LOW value.	16
	AI 2 HIGH 2	State change when AI2 value > par. 8413 SEQ VAL 2 HIGH value.	17
	AI1 OR 2 LO2	State change when AI1 or AI2 value < par. 8414 SEQ VAL 2 LOW value.	18
	AI1LO2AI2HI2	State change when AI1 value < par. 8414 SEQ VAL 2 LOW value and AI2 value > par. 8413 SEQ VAL 2 HIGH value.	19
	AI1LO2 ORDI5	State change when AI1 value < par. 8414 SEQ VAL 2 LOW value or when DI5 is active.	20
	AI2HI2 ORDI5	State change when AI2 value > par. 8413 SEQ VAL 2 HIGH value or when DI5 is active.	21
	TIMED FUNC 1	Trigger with timed function 1. See parameter group 36 TIMED FUNCTIONS .	22
	TIMED FUNC 2	See selection TIMED FUNC 1 .	23
	TIMED FUNC 3	See selection TIMED FUNC 1 .	24
	TIMED FUNC 4	See selection TIMED FUNC 1 .	25
	CHANGE DLY	State change after delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	26
	DI1 OR DELAY	State change after DI1 activation or after delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	27

All parameters			
No.	Name/Value	Description	Def/FbEq
	DI2 OR DELAY	See selection DI1 OR DELAY .	28
	DI3 OR DELAY	See selection DI1 OR DELAY .	29
	DI4 OR DELAY	See selection DI1 OR DELAY .	30
	DI5 OR DELAY	See selection DI1 OR DELAY .	31
	AI1HI1 ORDLY	State change when AI1 value > par. 8411 SEQ VAL 1 HIGH value or after delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	32
	AI2LO1 ORDLY	State change when AI2 value < par. 8412 SEQ VAL 1 LOW value or after delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	33
	AI1HI2 ORDLY	State change when AI1 value > par. 8413 SEQ VAL 2 HIGH value or after delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	34
	AI2LO2 ORDLY	State change when AI2 value < par. 8414 SEQ VAL 2 LOW value or after delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	35
	SUPRV1 OVER	Logic value according to supervision parameters 3201...3203 . See parameter group 32 SUPERVISION .	36
	SUPRV2 OVER	Logic value according to supervision parameters 3204...3206 . See parameter group 32 SUPERVISION .	37
	SUPRV3 OVER	Logic value according to supervision parameters 3207...3209 . See parameter group 32 SUPERVISION .	38
	SUPRV1 UNDER	See selection SUPRV1 OVER .	39
	SUPRV2 UNDER	See selection SUPRV2 OVER .	40
	SUPRV3 UNDER	See selection SUPRV3 OVER .	41
	SPV1OVRORD LY	State change according to supervision parameters 3201...3203 or when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed. See parameter group 32 SUPERVISION .	42
	SPV2OVRORD LY	State change according to supervision parameters 3204...3206 or when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed. See parameter group 32 SUPERVISION .	43
	SPV3OVRORD LY	State change according to supervision parameters 3207...3209 or when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed. See parameter group 32 SUPERVISION .	44
	SPV1UNDORD LY	See selection SPV1OVRORDLY .	45

All parameters			
No.	Name/Value	Description	Def/FbEq
	SPV2UNDORDLY	See selection SPV2OVRORDLY .	46
	SPV3UNDORDLY	See selection SPV3OVRORDLY .	47
	CNTR OVER	State change when counter value exceeds the limit defined by par. 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO . See parameters 1904...1911 .	48
	CNTR UNDER	State change when counter value is below the limit defined by par. 1925 COUNTER LIMIT HI and 1926 COUNTER LIMIT LO . See parameters 1904...1911 .	49
	LOGIC VAL	State change according to logic operation defined by parameters 8406...8410	50
	ENTER SETPNT	State change when drive output frequency/speed enters the reference area (ie the difference is less than or equal to 4% of the maximum reference).	51
	AT SETPOINT	State change when drive output frequency/speed equals the reference value (= is within tolerance limits, ie the error is less than or equal to 1% of the maximum reference).	52
	AI1 L1 & DI5	State change when AI1 value < par. 8412 SEQ VAL 1 LOW and when DI5 is active.	53
	AI2 L2 & DI5	State change when AI2 value < par. 8414 SEQ VAL 2 LOW value and when DI5 is active.	54
	AI1 H1 & DI5	State change when AI1 value > par. 8411 SEQ VAL 1 HIGH value and when DI5 is active.	55
	AI2 H2 & DI5	State change when AI2 value > par. 8413 SEQ VAL 2 HIGH value and when DI5 is active.	56
	AI1 L1 & DI4	State change when AI1 value < par. 8412 SEQ VAL 1 LOW value and when DI4 is active.	57
	AI2 L2 & DI4	State change when AI2 value < par. 8414 SEQ VAL 2 LOW value and when DI4 is active.	58
	AI1 H1 & DI4	State change when AI1 value > par. 8411 SEQ VAL 1 HIGH value and when DI4 is active.	59
	AI2 H2 & DI4	State change when AI2 value > par. 8413 SEQ VAL 2 HIGH value and when DI4 is active.	60
	DLY AND DI1	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and DI1 is active.	61
	DLY AND DI2	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and DI2 is active.	62
	DLY AND DI3	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and DI3 is active.	63
	DLY AND DI4	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and DI4 is active.	64

All parameters			
No.	Name/Value	Description	Def/FbEq
	DLY AND DI5	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and DI5 is active.	65
	DLY & AI2 H2	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and AI2 value > par. 8413 SEQ VAL 2 HIGH value.	66
	DLY & AI2 L2	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and AI2 value < par. 8414 SEQ VAL 2 LOW value.	67
	DLY & AI1 H1	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and AI1 value > par. 8411 SEQ VAL 1 HIGH value.	68
	DLY & AI1 L1	State change when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed and AI1 value < par. 8412 SEQ VAL 1 LOW value.	69
	COMM VAL1 #0	0135 COMM VALUE 1 bit 0. 1 = state change.	70
	COMM VAL1 #1	0135 COMM VALUE 1 bit 1. 1 = state change.	71
	COMM VAL1 #2	0135 COMM VALUE 1 bit 2. 1 = state change.	72
	COMM VAL1 #3	0135 COMM VALUE 1 bit 3. 1 = state change.	73
	COMM VAL1 #4	0135 COMM VALUE 1 bit 4. 1 = state change.	74
	COMM VAL1 #5	0135 COMM VALUE 1 bit 5. 1 = state change.	75
	COMM VAL1 #6	0135 COMM VALUE 1 bit 6. 1 = state change.	76
	COMM VAL1 #7	0135 COMM VALUE 1 bit 7. 1 = state change.	77
	AI2H2DI4SV1O	State change according to supervision parameters 3201...3203 when AI2 value > par. 8413 SEQ VAL 2 HIGH value and DI4 is active.	78
	AI2H2DI5SV1O	State change according to supervision parameters 3201...3203 when AI2 value > par. 8413 SEQ VAL 2 HIGH value and DI5 is active.	79
	STO	State change when STO (Safe torque off) has been triggered.	80
	STO(-1)	State change when STO (Safe torque off) becomes inactive and the drive operates normally.	81
	COMM VAL1 #8	0135 COMM VALUE 1 bit 8. 1 = state change.	82
	COMM VAL1 #9	0135 COMM VALUE 1 bit 9. 1 = state change.	83

All parameters			
No.	Name/Value	Description	Def/FbEq
	COMM VAL1 #10	0135 COMM VALUE 1 bit 10. 1 = state change.	84
	COMM VAL1 #11	0135 COMM VALUE 1 bit 11. 1 = state change.	85
	COMM VAL1 #12	0135 COMM VALUE 1 bit 12. 1 = state change.	86
	COMM VAL1 #13	0135 COMM VALUE 1 bit 13. 1 = state change.	87
	COMM VAL1 #14	0135 COMM VALUE 1 bit 14. 1 = state change.	88
	COMM VAL1 #15	0135 COMM VALUE 1 bit 15. 1 = state change.	89
	CV1#0 & DLY	State change when 0135 COMM VALUE 1 bit 0 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	90
	CV1#1 & DLY	State change when 0135 COMM VALUE 1 bit 1 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	91
	CV1#2 & DLY	State change when 0135 COMM VALUE 1 bit 2 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	92
	CV1#3 & DLY	State change when 0135 COMM VALUE 1 bit 3 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	93
	CV1#4 & DLY	State change when 0135 COMM VALUE 1 bit 4 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	94
	CV1#5 & DLY	State change when 0135 COMM VALUE 1 bit 5 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	95
	CV1#6 & DLY	State change when 0135 COMM VALUE 1 bit 6 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	96
	CV1#7 & DLY	State change when 0135 COMM VALUE 1 bit 7 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	97
	CV1#8 & DLY	State change when 0135 COMM VALUE 1 bit 8 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	98
	CV1#9 & DLY	State change when 0135 COMM VALUE 1 bit 9 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	99

All parameters			
No.	Name/Value	Description	Def/FbEq
	CV1#10 & DLY	State change when 0135 COMM VALUE 1 bit 10 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	100
	CV1#11 & DLY	State change when 0135 COMM VALUE 1 bit 11 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	101
	CV1#12 & DLY	State change when 0135 COMM VALUE 1 bit 12 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	102
	CV1#13 & DLY	State change when 0135 COMM VALUE 1 bit 13 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	103
	CV1#14 & DLY	State change when 0135 COMM VALUE 1 bit 14 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	104
	CV1#15 & DLY	State change when 0135 COMM VALUE 1 bit 15 = 1 and delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed.	105
	SPV1OVANDD LY	State change according to supervision parameters 3201...3203 and when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed. See parameter group 32 SUPERVISION .	106
	SPV2OVANDD LY	State change according to supervision parameters 3204...3206 and when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed. See parameter group 32 SUPERVISION .	107
	SPV3OVANDD LY	State change according to supervision parameters 3207...3209 and when delay time defined by parameter 8424 ST1 CHANGE DLY has elapsed. See parameter group 32 SUPERVISION .	108
	SPV1UNANDD LY	See selection SPV1OVRORDLY .	109
	SPV2UNANDD LY	See selection SPV1OVRORDLY .	110
	SPV3UNANDD LY	See selection SPV1OVRORDLY .	111
	AT TARGET A	State change when parameter 0190 POS STATUS bit 0 (AT Target A) =1.	112
	AT TARGET B	State change when parameter 0190 POS STATUS bit 1 (AT Target B) =1.	113
	AT TARGET C	State change when parameter 0190 POS STATUS bit 2 (AT Target C) =1.	114
	AT TARGET D	State change when parameter 0190 POS STATUS bit 3 (AT Target D) =1.	115

All parameters			
No.	Name/Value	Description	Def/FbEq
	LOGIC2 VAL	State change according to logic operation defined by parameters 8501....8505 .	116
	SLOWDOWN A	State change when parameter 0190 POS STATUS bit 8 (Slowdown A) =1.	117
	SLOWDOWN B	State change when parameter 0190 POS STATUS bit 9 (Slowdown B) =1.	118
	SLOWDOWN C	State change when parameter 0190 POS STATUS bit 10 (Slowdown C) =1.	119
	SLOWDOWN D	State change when parameter 0190 POS STATUS bit 11 (Slowdown D) =1.	120
8426	ST1 TRIG TO ST N	Selects the source for the trigger signal which changes the state from state 1 to state N. State N is defined with parameter 8427 ST1 STATE N . Note: State change to state N (8426 ST1 TRIG TO ST N) has a higher priority than state change to the next state (8425 ST1 TRIG TO ST 2).	NOT SEL
		See parameter 8425 ST1 TRIG TO ST 2 .	
8427	ST1 STATE N	Defines the state N. See parameter 8426 ST1 TRIG TO ST N .	STATE 1
	STATE 1	State 1	1
	STATE 2	State 2	2
	STATE 3	State 3	3
	STATE 4	State 4	4
	STATE 5	State 5	5
	STATE 6	State 6	6
	STATE 7	State 7	7
	STATE 8	State 8	8
	STATE 9	State 9	9
	STATE 10	State 10	10
	STATE 11	State 11	11
	STATE 12	State 12	12
	STATE 13	State 13	13
	STATE 14	State 14	14
	STATE 15	State 15	15
	STATE 16	State 16	16

All parameters			
No.	Name/Value	Description	Def/FbEq
8428	ST1 TRIG TO STN2	Selects the source for the trigger signal which changes the state from state 1 to state N2. State N2 is defined with parameter 8429 ST1 STATE N2 . Note: State change to state N2 (8428 ST1 TRIG TO STN2) has a higher priority than state change to the N state (8426 ST1 TRIG TO ST N). See parameter 8425 ST1 TRIG TO ST 2 .	NOT SEL
8429	ST1 STATE N2	Defines the state N2. See parameter 8427 ST1 STATE N .	STATE 1
		See parameter 8427 ST1 STATE N	
8430	ST2 REF SEL	See parameters 8420 ... 8429 .	
...			
8495	ST8 TRIG TO ST1	See parameter 8425 . Note: State change to NEXT state 9 (8510 ST8 TRIG TO ST 9) has a higher priority than state change to state 1.	
8496	ST8 TRIG TO ST N	See parameter 8425 .	
8497	ST8 STATE N	See parameter 8426 .	
8498	ST8 TRIG TO STN2	See parameter 8428 ST1 TRIG TO STN2 .	
8499	ST8 STATE N2	See parameter 8429 ST1 STATE N2 .	
85 SEQUENCE PROG2		Sequence program group 2. See section Settings on page 36 .	
8501	SEQ LOGIC2 VAL 1	See parameter 8406 .	
8502	LOGIC2 OPER1	See parameter 8407 .	
8503	SEQ LOGIC2 VAL2	See parameter 8406 .	
8504	LOGIC2 OPER2	See parameter 8407 .	
8505	SEQ LOGIC2 VAL3	See parameter 8406 .	
8506	MACRO CHG ST	User Macro was changed when the sequence programming enter the setting state. Example: When parameter is set to state 1 and sequence programming enter to stat1, the user macro changed to parameter 8507 USER MACRO SEL setting. Note: The sequence programming user macro changing function should activate by the parameter 1605 USER PAR SET CHG set to SEQ PROG .	NOT SEL
NOT SEL	Disable	0	
STATE 1	State 1	1	

All parameters			
No.	Name/Value	Description	Def/FbEq
	STATE 2	State 2	2
	STATE 3	State 3	3
	STATE 4	State 4	4
	STATE 5	State 5	5
	STATE 6	State 6	6
	STATE 7	State 7	7
	STATE 8	State 8	8
	STATE 9	State 9	9
	STATE 10	State 10	10
	STATE 11	State 11	11
	STATE 12	State 12	12
	STATE 13	State 13	13
	STATE 14	State 14	14
	STATE 15	State 15	15
	STATE 16	State 16	16
8507	USER MACRO SEL	Defines the user macro selection.	USER LOAD1
	USER S1 LOAD	When sequence programing enter to parameter 8506 MACRO CHG ST setting, User 1 macro loaded into use. Note: The sequence programing user macro changing function should activate by the parameter 1605 USER PAR SET CHG set to SEQ PROG .	1
	USER S2 LOAD	See the USER S1 LOAD.	2
	USER S3 LOAD	See the USER S1 LOAD.	3
8510	ST8 TRIG TO ST 9	See parameter 8425 .	
8512	ST9 TRIG TO STN3	Selects the source for the trigger signal which changes the state from state 9 to state N3. State N3 is defined with parameter 8513 ST9 STATE N3 . Note: State change to state N3 (parameter 8512 ST9 TRIG TO STN3) has a higher priority than state change to the N2 state (parameter 8528 ST9 TRIG TO STN2).	NOT SEL
		See parameter 8425 ST1 TRIG TO ST 2 .	
8513	ST9 STATE N3	Defines the state N3. See parameter 8427 ST1 STATE N .	STATE 1

All parameters			
No.	Name/Value	Description	Def/FbEq
8514	ST9 TRIG TO STN4	Selects the source for the trigger signal which changes the state from state 9 to state N4. State N4 is defined with parameter 8515 ST9 STATE N4 . Note: State change to state N4 (parameter 8514 ST9 TRIG TO STN4) has a higher priority than state change to the N3 state (parameter 8512 ST9 TRIG TO STN3).	NOT SEL
		See parameter 8425 ST1 TRIG TO ST 2 .	
8515	ST9 STATE N4	Defines the state N4. See parameter 8427 ST1 STATE N .	STATE 1
8516	ST10 TRIG TO STN3	See parameter 8512 ST9 TRIG TO STN3 .	
8517	ST10 STATE N3	See parameter 8513 ST9 STATE N3 .	
8518	ST10 TRIG TO STN4	See parameter 8514 ST9 TRIG TO STN4 .	
8519	ST10 STATE N4	See parameter 8515 ST9 STATE N4 .	
8520	ST9 REF SEL	See parameters 8420...8429 .	
...			
8599	ST16 STATE N2		

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to www.abb.com/drives and select *Training courses*.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Go to www.abb.com/drives and select *Document Library – Manuals feedback form (LV AC drives)*.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet. Go to www.abb.com/drives and select *Document Library*. You can browse the library or enter selection criteria, for example a document code, in the search field.

Contact us

www.abb.com/drives
www.abb.com/drivespartners

3AXD5000017465 Rev A (EN) EFFECTIVE: 2012-06-18