

Panasonic®

Hello! GM1 Expansion Unit Edition



memo

Copyright and Trademarks

- The copyright of this manual is owned by Panasonic Industry Co., Ltd.
- Unauthorized reproduction of this manual is strictly prohibited.
- Windows is a registered trademark of Microsoft Corporation in the United States and other countries.
- Ethernet is a registered trademark of Fuji Xerox Co., Ltd. and Xerox Corporation in the United States.
- EtherCAT is a registered trademark of and patented technology licensed by Beckhoff Automation GmbH in Germany.
- SDHC and SD logos are trademarks of SD-3C, LLC.
- Other company and product names are trademarks or registered trademarks of their respective companies.

Safety Precautions

This section explains important rules that must be observed to prevent personal injury and property damage.

• Injuries and damages that may occur as a result of incorrect use are classified into the following levels and safety precautions are explained according to the level.

- ⚠ WARNING Indicates that there is a risk of death or serious injury
⚠ CAUTION Indicates that there is a risk of minor injury or property damage

- ⊘ Indicates an action that is prohibited
! Indicates an action that must be taken

⚠ WARNING

- ! • Take safety measures outside this product to ensure the safety of the entire system even if this product fails or an error occurs due to external factors.
- ⊘ • Do not use this product in atmospheres that contain flammable gases. Doing so may result in explosion.
- ⊘ • Do not throw this product into the fire. Doing so may cause the batteries or other electronic parts to explode.

⚠ CAUTION

- ! • To prevent abnormal heat generation or smoke generation, use this product with some leeway from the guaranteed characteristics and performance values of the product.
- ⊘ • Do not disassemble or modify this product. Doing so may result in abnormal heat generation or smoke generation.
- ⊘ • Do not touch any terminals while the power is on.
- ! • Configure emergency stop and interlock circuits outside this product.
- ! • Connect wires and connectors properly. Failure to do so may result in abnormal heat generation or smoke generation.
- ⊘ • Do not perform work (such as connection or removal) with the power turned on.
- ! • If this product is used in any way that is not specified by Panasonic, its protection function may be impaired.
- ! • This product has been developed and manufactured for factory use only.

Contents of This Textbook and Scope of Responsibility

This textbook describes how to set up the GM1 Series Expansion Unit and operate GM Programmer, but does not describe safety precautions or notes on use for each device.

Be sure to obtain the instruction manuals and other manuals for the devices used in this textbook and read safety precautions and notes on use before using the devices.

Panasonic shall not take any responsibility for any damages that may arise in relation to our products or software, or this textbook.

GM1 Expansion Unit Edition (Pulse Output Unit)


| | |
|---|-----------|
| Installation Overview | 6 |
| • Operation patterns..... | 6 |
| • Operation images | 7 |
| • Setup flow | 7 |
| 0 Preparation | 8 |
| Installing tool software | 8 |
| 1 Basic Setup..... | 10 |
| 1.1 Preparing and Wiring the Required Devices..... | 10 |
| 1.2 Registering an Expansion Unit | 12 |
| 1.3 Setting up a Pulse Output Unit..... | 15 |
| 2 Programming | 19 |
| 2.1 Creating Servo ON Program | 19 |
| 2.2 Creating Home Return Program | 23 |
| 2.3 Creating JOG Operation Program | 25 |
| 2.4 Creating Positioning Operation Program (Absolute Value Positioning) | 28 |
| 2.5 Creating Positioning Operation Program (Relative Value Positioning)..... | 30 |
| 3 Operation Check..... | 34 |
| 3.1 Network Scanning | 34 |
| 3.2 Login and Download | 38 |
| 3.3 Executing Commissioning and Home Return | 40 |
| 3.4 Performing Positioning Operation | 43 |
| 4 Monitoring | 44 |
| 4.1 Monitoring the Pulse Output Unit..... | 44 |
| 4.2 Registering in Watch..... | 45 |
| 4.3 Adding Trace..... | 48 |

GM1 Expansion Unit Edition (Analog I/O Unit)

| | |
|---|-----------|
| Installation Overview | 56 |
| • Operation images | 56 |
| • Setup flow | 56 |
| • Unit types | 57 |
| Analog output unit | 58 |
| • Basic analog output operations..... | 58 |
| • Timing chart of output processing..... | 58 |
| Analog input unit..... | 59 |
| • Basic analog input operations | 59 |
| • Timing chart of input processing | 59 |
| 1 Basic Setup..... | 60 |
| 1.1 Preparing and Wiring the Required Devices..... | 60 |
| 1.2 IP Address Setting to Network Scanning..... | 61 |
| 2 I/O Unit Setup | 62 |
| 2.1 Adding I/O Units..... | 62 |
| 2.2 Setting up the Analog Output Unit (AGM1DA4) | 65 |
| 2.3 Setting up the Analog Input Unit (AGM1AD8) | 66 |
| 3 Programming..... | 67 |
| 3.1 Adding New POU | 67 |
| 3.2 Programming | 70 |
| 4 Communication Operation Check | 75 |
| 5 Scale Conversion Function | 77 |
| 6 Disconnection Detection Function | 79 |
| 7 Analog Output Hold Function in STOP Mode | 82 |

Pulse Output Unit

Installation Overview



- Operation patterns

After home return is complete, Operation ① to Operation ③ are performed continuously.

Home return

The object moves to its home position (0).

Operation ①: Absolute value positioning

The object moves from its home position to target position ① (5000).

Operation ②: Relative value positioning

The object moves from target position ① (5000) to target position ② (15000).

Operation ③: Relative value positioning

The object moves from target position ② (15000) to target position ③ (12000).

INFO

The command unit used by the GM1 Pulse Output Unit is "u", and 1u is equivalent to 1 pulse.


Conversion to the unit used in a mechanical system to be prepared by the customer must be added by executing processing in programs or implementing other measures as necessary.

Unless otherwise specified, units are omitted in this textbook.

• Operation images


Home return

The object is moved to its home position (0).




Operation ①: Absolute value positioning

The object is moved from its home position (0) to target position ① (5000).




Operation ②: Relative value positioning

The object is moved from target position ① (5000) to target position ② (15000).




Operation ③: Relative value positioning

The object is moved from target position ② (15000) to target position ③ (12000).



• Setup flow



0 Preparation

Installing tool software

Install GM Programmer from the following website:

GM Programmer: <https://industrial.panasonic.com/ac/j/motor/motion-controller/mc/gm1/index.jsp>

INFO

When GM Programmer is installed, PANATERM Lite for GM, Gateway (CODESYS Gateway), and CodeMeter applications are installed at the same time.

- GM Programmer: This is a setup tool for the GM1 controller. Using GM Programmer makes it possible to set positioning data and various positioning parameters, and perform various monitoring operations.
- PANATERM Lite for GM1 (not used in this textbook): This is a setup support tool for the MINAS series servo amplifiers manufactured by Panasonic Corporation. When GM Programmer is installed, PANATERM Lite for GM is also installed at the same time. By using this tool, parameter setup within servo amplifiers, control status monitoring, setup support, machine analysis, and other operations can be executed on a PC.

Before installing GM Programmer on a PC, log on to the PC with Administrator privileges.

If other applications are running, be sure to close all the applications before installing GM Programmer.



Column ①: Installing PANATERM

If a PC on which PANATERM is installed is connected to a MINAS servo amplifier with a USB cable, parameter setup, control status monitoring, setup support, machine analysis, and other operations can be performed easily.


If necessary, install PANATERM from the following Panasonic website.

- PANATERM: https://www3.panasonic.biz/ac/j/dl/software/index.jsp?series_cd=3514



Column ②: Components of each tool software product

GM Programmer



| No. | Name | Description |
|-----|-----------------|--|
| (1) | Title bar | The title bar displays the project file name, minimize button, maximize button, and close button. |
| (2) | Menu bar | The menu bar displays the menu commands for each purpose in list format. |
| (3) | Toolbar | The toolbar displays each command as an icon. |
| (4) | Navigation pane | The navigation pane displays the objects (such as devices, applications, and programs) added to the project in a tree structure. |
| (5) | Main pane | The main pane displays a program, function settings, messages, and other data. The sub-pane can be switched by selecting a desired tab. |
| (6) | Status bar | The status bar displays the build status, logged-in users, and other information. |


1 Basic Setup

1.1 Preparing and Wiring the Required Devices

Prepare the following devices.

| No. | Name |
|-----|--|
| (1) | GM1 controller (RTEX type) |
| (2) | GM1 pulse output unit (Line driver output type): AGM1PG04L |
| (3) | Motor driver |
| (4) | Stepping motor (Line driver input type) |
| (5) | PC (with GM Programmer installed) |
| (6) | LAN cable |
| (7) | AC power supply |
| (8) | 24 V DC power supply |

Wire each device as shown below.






Column ③: Wiring pulse command outputs


Pulse output units are divided into two types: Line driver output type and transistor output type.

Select and connect an appropriate pulse output unit according to the interface of the motor driver to be used.

Line driver output type



Transistor output type



1.2 Registering an Expansion Unit

This section describes how to register an expansion unit.

Step 1


Start GM Programmer. Select **New Project** from the **File** menu, assign any name, and then click **OK**.

Device: AGM1CSEC16 (Panasonic Corporation)

Version: Any applicable version


Program in: Ladder Logic Diagram (LD)

Select the above values and click **OK**.




Step 2

Right-click **Empty1** and select **Unit Management**.




Step 3

The **Unit Management** pop-up window will be displayed. Register an expansion unit to be attached to the GM1 controller. Double-click on the first row.




Step 4

The **Select Device** pop-up window will be displayed. Select **AGM1PG04L** and click **Select Device**.




Step 5

Click **OK** to close the pop-up window.



Check that **Empty1** has been changed to **slot1_Pulse_4Axis(AGM1PG01L)** as shown below.




1.3 Setting up a Pulse Output Unit

This section explains the parameter setting procedure and parameter settings for the pulse output unit.


Step 1

Right-click **Slot1_Pulse_4Axes(AGM1PG04L)**, which is the expansion unit that has been registered previously, and select **Edit Object**.



Step 2

A setting window will open as the main pane. Select the **Pulse_4Axes** parameter tab.



Step 3

This time, we will use Axis 1 of the pulse output unit, so click **Axis1_AGM1PG04ExUnitCfg** and set up parameters.

The screenshot shows the 'Pulse_4Axes parameter' configuration window. On the left, there are tabs for 'Pulse_4Axes I/O Mapping', 'Status', and 'Information'. The main area is divided into 'Category Selection(T)' and 'Parameter Setting (R)'. In 'Category Selection(T)', 'Axis1_AGM1PG04ExUnitCfg' is selected. 'Parameter Setting (R)' is a table with the following parameters and values:

| Parameter | Value |
|------------------------------------|------------------------------------|
| Axis1_PulseInputRotationDirection | Forward |
| Axis1_PulseInputCount | Enable |
| Axis1_PulseInputMode | 2-phase input |
| Axis1_PulseInputMultiplication | x1 |
| Axis1_PulseOutputRotationDirection | Forward |
| Axis1_PulseOutputMode | CW/CCW |
| Axis1_PulseOutputDividedMode | Divided by 1 |
| Axis1_DeviationCounterClearTime | 1ms |
| Axis1_PulseOutAccDec | Linear Acceleration/Deceleration |
| Axis1_HomeDirection | (-) Direction of the elapsed value |
| Axis1_StartUpTime | 0.02ms |
| Axis1_HomeInputLogic | Normal Open |
| Axis1_NearHomeInputLogic | Normal Open |
| Axis1_HomeSearch | Enable |
| Axis1_LimitInputLogic | Normal Close |
| Axis1_SAccDec | Sin curve |
| Axis1_PulseOutputMultiplication | x1 |
| Axis1_StartupSpeed | 500 |
| Axis1_PulseInputSignalInCnst | Not InCnst |
| Axis1_HomeInputInCnst | Not InCnst |

This time, set up parameters as below.

| | |
|-----------------------|-------------|
| Axis1_PulseOutputMode | CW/CCW |
| Axis1_HomeInputLogic | Normal Open |
| Axis1_HomeSearch | Enable |
| Axis1_StartupSpeed | 500 |

INFO

If there is no limit input sensor, set **Axis1_LimitInputLogic** to **Normal Open**. If **Axis1_LimitInputLogic** is set to **Normal Close**, a limit error will occur.

Set **Axis1_HomeSearch** to **Disable**.




Column ④: Pulse output mode (Pulse/Sign and CW/CCW)

The pulse input mode for the motor driver is divided into two types: Pulse/Sign mode and CW/CCW mode. Therefore, an appropriate pulse output mode must be selected according to the driver specification.


- Pulse/Sign mode

In this mode, the rotational direction of the motor is identified according to the high or low level of the rotational direction signal when a pulse is input into the pulse input terminal of the motor driver.



- CW/CCW mode

In this mode, the rotational direction of the motor is identified according to the pulse input terminal of the motor driver (CW input or CCW input) into which a pulse is input.



Column ⑤: Home search valid mode and home search invalid mode


Home search valid mode

- If there is a near home signal when the object is moving in the home return direction, the object will slow down near the home position and stop at the home input position.
- If there is no home input signal when the object is moving in the home return direction, the object will reverse automatically when a limit input is detected. If the near home signal turns ON, the object will reverse again and then stop when the home input signal turns ON.
- If the near home signal is input during acceleration, the object will reverse automatically and then return to the home position after the change of the near home signal state from ON to OFF is detected.

Home search invalid mode

- If there is a near home signal when the object is moving in the home return direction, the object will slow down near the home position and stop at the home input position.
- If there is no home input signal when the object is moving in the home return direction, the object will stop when a limit input is detected.

 Column ⑥: Home return parameters using only home input signals



- Axis1_HomeInputLogic: Normal Open
- Axis1_NearHomeInputLogic: Normal Close
- Axis1_HomeSearch: Disable

The above settings cause the near home input to be already enabled after home return operation is started. Then, the home return operation stops when the home input signal turns ON. These parameters can be used only in the home search invalid mode.

2 Programming


2.1 Creating Servo ON Program

Step 1

Code a program within MC_PRG.

Double-click **MC_PRG** to open the program pane.


Right-click the leftmost section of the network (the red section in the figure below) and select **Insert Box**.



Step 2

The **Input Assistant** dialog box will open. In the **Categories** tab, select **Function blocks**.

In the right pane, select { } **Panasonic_PG**, **Function Blocks**, and then **PG_Power** and click **OK**.






Column ⑦: List of function blocks for pulse output unit

| Function block | Outline |
|-------------------|---|
| PG_Power | This is a function block (FB) that performs servo ON/OFF control on the axis of the pulse output unit. |
| PG_Jog | This is a function block (FB) that causes the axis of the pulse output unit to keep traveling in a forward or backward direction. |
| PG_MoveAbsolute | This is a function block (FB) that causes the axis of the pulse output unit to travel to a position specified as an absolute position. |
| PG_Move_Relative | This is a function block (FB) that causes the axis of the pulse output unit to travel to a position specified as a relative position. |
| PG_LatchPosition | This is a function block (FB) that causes the axis of the pulse output unit to travel to a position specified by an external signal input as a relative position. |
| PG_Pulser | This is a function block (FB) that enables constant speed operation for the axis of the pulse output unit using external pulse input. |
| PG_Stop | This is a function block (FB) that causes the axis of the pulse output unit to make a forced stop or deceleration stop. |
| PG_Home | This is a function block (FB) that performs home return of the pulse output unit. |
| PG_SetPosition | This is a function block (FB) that sets the elapsed value and the feedback counter of the pulse output unit to desired values. |
| PG_WriteParameter | This is a function block (FB) that writes the parameters to the pulse output unit. |
| PG_ReadParameter | This is a function block (FB) that reads the parameters of the pulse output unit. |
| PG_ClearError | This is a function block (FB) that clears the limit error or the set value error of the pulse output unit. |
| PG_ReadStatus | This is a function block (FB) that reads the status of the pulse output unit. |


Step 3

Make sure that the cursor stays on **PG_Power_0** above the **PG_Power** function block that has been added, and then press the Enter key.



Variables will be automatically declared for PG_Power and the **Auto Declare** dialog box will be displayed. Check the contents of the dialog box and then click **OK**.


Complete the function block as show below.




| | Type | Parameter name | Set value | Description |
|-----|--------|---------------------|------------|--|
| (1) | | UnitID | 1 | Specifies the unit ID. |
| (2) | Input | AxisNo | 1 | Specifies the axis No. |
| (3) | | Enable | TRUE | TRUE: FB ready for execution |
| | | bRegulatorOn | xPowerON | TRUE: Servo lock FALSE: Servo lock released |
| (4) | Output | Status | Delete ??? | TRUE: Axis ready for operation |
| | | bRegulatorRealState | Delete ??? | TRUE: FB ready for execution |
| | | Busy | Delete ??? | TRUE: Execution of the FB is incomplete |
| | | Error | Delete ??? | TRUE: Error has occurred within FB |
| | | ErrorID | Delete ??? | An error ID is output |

INFO

For the unit ID, specify the number of the slot in which the pulse output unit is mounted.



For Axis No., specify an axis number of the pulse output unit.





Column ⑧: Variables

Space and special characters (such as !, ", \$, %, @, or &) cannot be used and a numeric character cannot be used as the first character.

Underscores cannot be used consecutively.

-Variable naming examples (naming conventions used in this textbook)

Variable names are assigned as English letters.

Each variable name starts with a prefix that indicates the type and scope of the variable.

A prefix is followed by a meaningful word name.

Only the first character of each word name is capitalized (to make it easy to understand the border between the prefix and the word).

Global variables must start with "g_".

Examples) BOOL type: xServoON

REAL type: rVelocity

BOOL type (Global variable): g_xPowerON


REAL type (Global variable): g_rPosition

List of data types

| Data type | Prefix | Remarks |
|---------------------|--------|--|
| BOOL | X or b | |
| BYTE | by | Not used for arithmetic operations |
| WORD | w | Not used for arithmetic operations |
| DWORD | dw | Not used for arithmetic operations |
| LWORD | lw | Not used for arithmetic operations |
| SINT | si | |
| USINT | usi | |
| INT | i | |
| UINT | ui | |
| DINT | di | |
| UDINT | udi | |
| LINT | li | |
| ULINT | uli | |
| REAL | r | |
| LREAL | lr | |
| STRING | s | |
| WSTRING | ws | |
| TIME | tim | |
| LTIME | ltim | |
| TIME_OF_DAY | tod | |
| DATE_AND_TIME | dt | |
| DATE | date | |
| POINTER | p | |
| ARRAY | a | |
| ENUM | e | |
| SCOPE | | A prefix to identify the scope of a variable |
| VAR_GLOBAL | g_ | For global variables, a concrete example is g_uiTest; |
| VAR_CONSTANT | c_ | For local constants, a concrete example is c_uiTest:INT; |
| VAR_GLOBAL_CONSTANT | gc_ | For global constants, a concrete example is gc_uiTest:INT; |


2.2 Creating Home Return Program

Insert PG_Home to execute home return.




Step 1

Insert a new network. Right-click in the network and select **Insert Network (below)**.




Step 2

Right-click the leftmost section of the new network and select **Insert Box**.




Step 3

The **Input Assistant** dialog box will open. In the **Categories** tab, select **Function blocks**. In the right pane, select **{ } Panasonic_PG, Function Blocks**, and then **PG_Home** and click **OK**.



Step 4

Complete the function block as show below.



| | Type | Parameter name | Set value | Description |
|-----|--------|----------------|------------|--|
| (1) | Input | UnitID | 1 | Specifies the unit ID. |
| | | AxisNo | 1 | Specifies the axis No. |
| (2) | Input | Execute | xHome | Starts execution at the rising edge. |
| | | Velocity | 1000 | Specifies the maximum velocity (u/s). |
| (3) | Input | AccDec | 1000 | Specifies the acceleration/deceleration (u/s ²). |
| (4) | Output | Done | Delete ??? | TRUE: FB operation is completed |
| | | Busy | Delete ??? | TRUE: FB operation in progress |
| | | CommandAborted | Delete ??? | TRUE: FB operation is interrupted |
| | | Error | Delete ??? | TRUE: FB is abnormally completed |
| | | ErrorID | Delete ??? | An error ID is output |

2.3 Creating JOG Operation Program


Create a program for JOG operation.

Step 1

Insert a new network using the same procedure as in "2.2 Creating Home Return Program".
Right-click in the network and select **Insert Network (below)**.


Step 2

Right-click the leftmost section of the new network and select **Insert Box**.




Step 3

The **Input Assistant** dialog box will open. In the **Categories** tab, select **Function blocks**.
In the right pane, select **{ } Panasonic_PG, Function Blocks**, and then **PG_Jog** and click **OK**.



Step 4

Complete the function block as show below.



| | Type | Parameter name | Set value | Description |
|-----|--------|----------------|--------------|--|
| (1) | Input | UnitID | 1 | Specifies the unit ID. |
| | | AxisNo | 1 | Specifies the axis No. |
| (2) | Input | JogForward | xJogForward | TRUE: Travels in a forward direction |
| (3) | | JogBackWard | xJogBackward | TRUE: Travels in a backward direction |
| (4) | Input | Velocity | 1000 | Specifies the target speed (u/s). |
| | | AccDec | 1000 | Specifies the acceleration/deceleration (u/s ²). |
| (5) | Output | Done | Delete ??? | TRUE: FB operation is completed |
| | | Busy | Delete ??? | TRUE: FB operation in progress |
| | | CommandAborted | Delete ??? | TRUE: FB operation is interrupted |
| | | Error | Delete ??? | TRUE: FB is abnormally completed |
| | | ErrorID | Delete ??? | An error ID is output |

INFO

Set either JogForward or JogBackward to TRUE to execute the function block.

Depending on the direction in which the axis is to be moved, set either JogForward or JogBackward to TRUE.

If JogForward and JogBackward are simultaneously executed, a PG_JOG_INVALID_REQUEST error will occur.

To execute the function block again after the occurrence of the error, set both JogForward and JogBackward to FALSE once beforehand.




Column ⑨: Difference between absolute value positioning and relative value positioning

• Absolute value positioning


This is a positioning control method in which the target position is specified as an absolute position from the home position.

<Example>

Operation 1) Moving the object to position 6,000 (command value + 6,000)



Operation 2) Moving the object to position 4,000 (command value + 4,000)




• Relative value positioning


This is a positioning control method in which the target position is specified as a movement distance from the current position.

<Example>

Operation 1) Moving the object to position 6,000 (command value + 5,000)




Operation 2) Moving the object to position 4,000 (command value - 2,000)



2.4 Creating Positioning Operation Program (Absolute Value Positioning)

Create a program for absolute value positioning. (PG_MoveAbsolute instruction)

Operation 1) Moving the object from the home position (0) to target position ① (5000) (Absolute value positioning)




Step 1

Insert a new network using the same procedure as in "2.2 Creating Home Return Program".
Right-click in the network and select **Insert Network (below)**.


Step 2

Right-click the leftmost section of the new network and select **Insert Box**.




Step 3

The **Input Assistant** dialog box will open. In the **Categories** tab, select **Function blocks**. In the right pane, select **{ } Panasonic_PG, Function Blocks**, and then **PG_MoveAbsolute** and click **OK**.



Step 4

Complete the function block as show below.



| | Type | Parameter name | Set value | Description |
|-----|--------|------------------|------------|--|
| (1) | Input | UnitID | 1 | Specifies the unit ID. |
| | | AxisNo | 1 | Specifies the axis No. |
| (2) | | Execute | xMove | Starts execution at the rising edge. |
| (3) | | Position | 5000 | Specifies the target position (u). |
| | | Velocity | 5000 | Specifies the maximum velocity (u/s). |
| | | AccDec | 50000 | Specifies the acceleration/deceleration (u/s ²). |
| (4) | Output | ContinuousEnable | Delete ??? | TRUE: Position, Velocity, and AccDec can be changed. |
| | | Done | xDone1 | TRUE: FB operation is completed |
| | | Busy | Delete ??? | TRUE: FB operation in progress |
| | | CommandAborted | Delete ??? | TRUE: FB operation is interrupted |
| | | Error | Delete ??? | TRUE: FB is abnormally completed |
| | | ErrorID | Delete ??? | An error ID is output |



Column ⑩: Assigning numerical variables

In the previous example, fixed value "5000" is substituted for the "Position" input parameter, but you can also declare a variable and set "5000" as the default value.


Declaring a variable enables you to change the value flexibly.

The 'Auto Declare' dialog box is shown with the following details:

- Scope: VAR
- Name: lrPosition
- Type: LREAL
- Object: MC_PRG [Application]
- Initialization: 5000
- Flags: CONSTANT, RETAIN, PERSISTENT

2.5 Creating Positioning Operation Program (Relative Value Positioning)

Create a program for relative value positioning. (MC_MoveRelative instruction)




Step 1

Insert a new network using the same procedure as in "2.2 Creating Home Return Program".
Right-click in the network and select **Insert Network (below)**.


Step 2

Right-click the leftmost section of the new network and select **Insert Box**.




Step 3

The **Input Assistant** dialog box will open. In the **Categories** tab, select **Function blocks**. In the right pane, select **{ } Panasonic_PG, Function Blocks**, and then **PG_MoveRelative** and click **OK**.



Step 4


Complete the function block as show below.



| | Type | Parameter name | Set value | Description |
|-----|--------|------------------|------------|--|
| (1) | Input | UnitID | 1 | Specifies the unit ID. |
| | | AxisNo | 1 | Specifies the axis No. |
| (2) | Input | Execute | xDone1 | Starts execution at the rising edge. |
| (3) | | Position | 10000 | Specifies the target position (u). |
| | | Velocity | 2000 | Specifies the maximum velocity (u/s). |
| | | AccDec | 20000 | Specifies the acceleration/deceleration (u/s ²). |
| (4) | Output | ContinuousEnable | Delete ??? | TRUE: Position, Velocity, and AccDec can be changed. |
| | | Done | xDone2 | TRUE: FB operation is completed |
| | | Busy | Delete ??? | TRUE: FB operation in progress |
| | | CommandAborted | Delete ??? | TRUE: FB operation is interrupted |
| | | Error | Delete ??? | TRUE: FB is abnormally completed |
| | | ErrorID | Delete ??? | An error ID is output |

Create a second program for relative value positioning. (MC_MoveRelative instruction)

Operation 4) Moving the object from target position ② (15000) to target position ③ (12000) (Relative value positioning)




Step 1

Insert a new network using the same procedure as in "2.2 Creating Home Return Program".
Right-click in the network and select **Insert Network (below)**.


Step 2

Right-click the leftmost section of the new network and select **Insert Box**.




Step 3

The **Input Assistant** dialog box will open. In the **Categories** tab, select **Function blocks**. In the right pane, select **{ } Panasonic_PG, Function Blocks**, and then **PG_MoveRelative** and click **OK**.



Step 4

Complete the function block as show below.



| | Type | Parameter name | Set value | Description |
|-----|--------|------------------|------------|--|
| (1) | Input | UnitID | 1 | Specifies the unit ID. |
| | | AxisNo | 1 | Specifies the axis No. |
| (2) | Input | Execute | xDone2 | Starts execution at the rising edge. |
| (3) | | Distance | -3000 | Specifies the target position (u). |
| | | Velocity | 3000 | Specifies the maximum velocity (u/s). |
| | | AccDec | 30000 | Specifies the acceleration/deceleration (u/s ²). |
| (4) | Output | ContinuousEnable | Delete ??? | TRUE: Position, Velocity, and AccDec can be changed. |
| | | Done | Delete ??? | TRUE: FB operation is completed |
| | | Busy | Delete ??? | TRUE: FB operation in progress |
| | | CommandAborted | Delete ??? | TRUE: FB operation is interrupted |
| | | Error | Delete ??? | TRUE: FB is abnormally completed |
| | | ErrorID | Delete ??? | An error ID is output |

3 Operation Check

3.1 Network Scanning

The PC communicates with the GM1 controller using GM Programmer and LAN ports.

The IP address (default) of LAN port 1 is set as below.

An IP address on the same network that is different from the IP address of LAN port 1 must be set for the PC.


Interface: LAN port 1

| | |
|------------------|---------------|
| IP address: | 192.168.1.5 |
| Subnet mask: | 255.255.255.0 |
| Default gateway: | 192.168.1.1 |

Interface: PC


| | |
|------------------|---------------|
| IP address: | 192.168.1.10 |
| Subnet mask: | 255.255.255.0 |
| Default gateway: | 192.168.1.1 |

* The IP address of the GM1 controller can be checked and set in the main pane displayed by selecting **PLC Parameters** in the **Device** tab.





Step 1

Double-click the **Device** object and open the **Communication Settings** tab.




Step 2

Click **Scan Network**, select a controller to be connected, and click **OK**.




When a connection is completed, the lamps light up in green (●).
 If the display appears as shown in the figure below, it is OK.




Step 3

Select **Build** from the **Build** menu to execute build.



If the processing is normal, "**Compile complete – 0 errors, 0 warnings**" will be displayed as shown below.



INFO

When a created program or settings are subject to a build process, objects in the application are compiled.
 If codes are generated after the build process is executed, an application to be downloaded to the GM1 controller will be generated.

The syntax of all objects is verified when the build process is executed for the first time.

The syntax of only differences is verified when the build process is executed a second time and thereafter. No application code will be generated.




Column ⑪: Communication using USB ports


USB ports can be set as a communication interface between the GM1 controller and tool software such as GM Programmer or PANATERM Lite for GM, as below.

- (1) Select **Add USB Port** from the **Online** menu.
- (2) The **Add USB Port** dialog box will be displayed.
- (3) Click **OK** to display a dialog box that restarts the gateway.
- (4) Click **OK** to display the **Select Device** dialog box.
- (5) Select a GM1 controller that you want to connect and click **OK**.
- (6) When a connection is established, USB ports are added as a communication interface between the PC and GM1 controller.

(1)




(5)



3.2 Login and Download

Step 1

Right-click the **Application** object and select **Login** to execute a download.



INFO


The **Device** and **Application** objects are displayed in the green background, indicating that they are in an online (connected) state.

🟢 mark appears on the left side of the **Device** object, indicating that the device is connected to the real machine.

⏹ mark appears on the right side of the **Application** object, indicating that the application is not running.


🟢 mark also appears on the left side of each device that is operating normally.

⚠ mark appears on the left side of each device that is not connected.



INFO


You can also log in from the toolbar.



Step 2

Right-click the **Application [stop]** object and select **Start**.

When the application enters a running state, **RUN** appears in the status area on the bottom of the GM Programmer window.



INFO

At the time of login (connection), there are two states: STOP and RUN.

"STOP" indicates that the program is not running, and "RUN" indicates that the program is running.

3.3 Executing Commissioning and Home Return


Step 1

Execute Servo ON.

To execute Servo ON, input **bRegulatorOn** in the **PG_Power** section must be set to TRUE.


xServoON is set to FALSE by default and the inside of the contact is displayed in white, indicating that the servo is OFF.

Double-click the inside of the **xServoON** contact (the portion surrounded by the red frame in the figure below).




Double-clicking the above portion displays the set value **<TRUE>** for the variable on the right side of the contact.

At this stage, the value has not yet been written to perform operation.



To write input status change values such as TRUE and FALSE, **in this state**, press the F7 key while holding down the Ctrl key.




When **xServoON** is set to ON, the inside of the contact is displayed in blue, indicating that the servo is ON.

"Status" and "bRegulatorRealState" outputs are also set to **TRUE**, indicating that the servo is ON.



Column ⑫: How to write values

After displaying **<TRUE>** by double-clicking the relevant portion, you can also write values by right-clicking and selecting **Write All Values of 'Device.Application'**.




Step 2

When servo ON is complete, perform commissioning on the motor in JOG operation mode.

Double-click the startup contact of **JogForward** or **JogBackWard** for the **PG_JOG** instruction (JOG operation). When **<TRUE>** is displayed, press the Ctrl+F7 keys to execute JOG operation.


The PG_Jog instruction runs the motor while the startup contact is set to TRUE. To stop the motor, double-click the startup contact that is set to TRUE. When **<FALSE>** is displayed, press the Ctrl+F7 keys.



Step 3

When the operation check in JOG operation mode is complete, perform home return operation as below.

Double-click the startup contact of the **PG_Home** instruction (home return). When **<TRUE>** is displayed, press the Ctrl+F7 keys to execute home return operation.



The motor runs and home return operation is executed.


When the home return operation is completed, **Done** is set to TRUE.



Column ⑬: What to do when a limit error occurs

If the over-limit input signal turns ON during motor operation, a limit error will occur, causing the ERR LED on the pulse output unit to light up.

In this case, use the PG_ClearError instruction to reset the error state and the PG_Home or PG_Jog instruction to move the object to a position where it is not detected by the over-limit input function.





3.4 Performing Positioning Operation

Step 1

Reset **xMove** to TRUE.

After **MC_MoveAbsolute_0** operation is complete, **xDone1** is set to TRUE and **MC_MoveRelative_0** operates.

After **MC_MoveRelative_0** operation is complete, **xDone2** is set to TRUE and **MC_MoveRelative_1** operates.




Step 2

Upon completion of operation check, stop the operation and log out.

4 Monitoring

4.1 Monitoring the Pulse Output Unit

The PG_ReadStatus instruction can be used to monitor the status of each axis.



| | Type | Parameter name | Set value | Description |
|-----|--------|-----------------|------------|-----------------------------------|
| (1) | Input | UnitID | 1 | Specifies the unit ID. |
| | | AxisNo | 1 | Specifies the axis No. |
| (2) | | Enable | TRUE | TRUE: Enables execution of the FB |
| (3) | Output | AbsoluteCounter | Delete ??? | Read value (Elapsed value) |
| | | FeedbackCounter | Delete ??? | Read value (Feedback value) |
| | | InputFlag | Delete ??? | Read value content (Input flag) |
| | | Valid | Delete ??? | TRUE: Enables use of parameters |
| | | Error | Delete ??? | TRUE: FB is abnormally completed |
| | | ErrorID | Delete ??? | An error ID is output |

For details on InputFlag for the PG_ReadStatus instruction, see the following table.

| Parameter | Name | Description |
|----------------------------|-----------------------|---|
| PulseOutputBusy | Pulse output busy | TRUE when pulse output is in progress |
| PulseOutputDone | Pulse output done | TRUE when pulse output is completed |
| AccelerationZone | Acceleration zone | TRUE when in the acceleration zone |
| ConstantSpeedZone | Constant speed zone | TRUE when in the constant speed zone |
| DecelerationZone | Deceleration zone | TRUE when in the deceleration zone |
| RotationDirection | Rotation direction | Elapsed value of monitoring in the rotation direction TRUE when the elapsed value is incrementing |
| HomeInput | Home input | Monitors the home input signal TRUE when the home input is enabled |
| NearHomeInput | Near home input | Monitors the near home input signal TRUE when the near home input is enabled |
| HomingDone | Home return done | TRUE when the home return is completed |
| OutputStopError | Output stop error | TRUE when an error occurs in the pulse output unit and output is stopped |
| SetValueChangeConfirmation | Set value change | Used to check rewriting of the set value during P-point control |
| OverPositiveLimitInput | Over limit (+) | TRUE when monitor contact limit input (+) for the over-limit input (+) signal is enabled |
| OverNegativeLimitInput | Over limit (-) | TRUE when monitor contact limit input (-) for the over-limit input (-) signal is enabled |
| TRUE TimingInputMonitor | Timing input monitor | TRUE when monitor contact position control start input for position control start input (timing input) is enabled |
| SetValueError | Set value error | TRUE when a set value error occurs |
| TRUE LimitError | Limit error | TRUE when an over-limit input signal is input during operation or at startup |
| TRUE ServoOnOutputState | Servo ON output state | TRUE when servo ON is output |

4.2 Registering in Watch

By registering variables in the watch view, you can perform variable value management such as checking or changing variable values. This time, register each contact and elapsed values of pulse output.

Step 1

From the **View** menu, select **Watch** and then **Watch 1**. **Watch 1** will be displayed on the bottom of the main window.

| 変数名 | タイプ | 値 | 設定済みの値 | アドレス |
|---|---------------------|------------|--------|------|
| Device.Application.SM_Drive_ETC_Panasonic_MINAS_A6B | SM3_Drive_ETC_Pa... | | | |
| wAxisStructID | WORD | 65042 | | |
| nAxisState | SMC_AXIS_STATE | standstill | | |
| bRegulatorOn | BOOL | TRUE | | |
| bDriveStart | BOOL | TRUE | | |
| bCommunication | BOOL | TRUE | | |
| wCommunicationState | WORD | 100 | | |
| uiDriveInterfaceError | LINT | 0 | | |
| bRegulatorRealState | BOOL | TRUE | | |
| bDriveStartRealState | BOOL | TRUE | | |
| wDriveId | WORD | 0 | | |
| iOwner | INT | 0 | | |
| iNoOwner | INT | 11 | | |
| fCycleTimeSpent | LREAL | 0 | | |
| fTaskCycle | LREAL | 0.001 | | |
| bError | BOOL | FALSE | | |
| dwErrorID | DWORD | 0 | | |
| bErrorAckn | BOOL | FALSE | | |
| bDisableErrorLogging | BOOL | FALSE | | |
| fBeFError | ARRAY [0..g_SMC_... | | | |
| dwRatioTechUnitsDenom | DWORD | 8388608 | | |
| iRatioTechUnitsNum | DINT | 1 | | |
| nDirection | MC_DIRECTION | negative | | |
| fScalefactor | LREAL | 8388608 | | |

| 式 | アプリケーション | タイプ | 値 | 設定済みの値 | 実行点 | アドレス | コメント |
|-----------------|--------------------|------|-------|--------|-----|------|------|
| MC_PRG.xPowerOn | Device.Application | BOOL | FALSE | | | | |

Step 2

The variables to be monitored can be registered in **Watch 1** by dragging and dropping them into the **Watch 1** pane. Drag and drop **xPowerOn** to register it.

| 式 | アプリケーション | タイプ | 値 |
|-----------------|--------------------|------|-------|
| MC_PRG.xPowerOn | Device.Application | BOOL | FALSE |

Register xHomeOn and xMoveOn in the same way.

Step 3

Register a variable to watch the elapsed value of pulse output.
Double-click in the empty column and then click

| 式 | アプリケーション | タイプ | 値 | 設定済みの値 | 実行点 | アドレス | コメント |
|-----------------|--------------------|------|-------|--------|--------------|------|------|
| MC_PRG.xPowerOn | Device.Application | BOOL | FALSE | | サイクリックモニタリング | | |
| MC_PRG.xHomeOn | Device.Application | BOOL | FALSE | | サイクリックモニタリング | | |
| MC_PRG.xMoveOn | Device.Application | BOOL | FALSE | | サイクリックモニタリング | | |
| | | | | | | | |

Select **Device**, **Application**, and then **MC_PRG**, select **PG_ReadStatus_0** and then **AbsoluteCounter**, and click **OK**.


| 式 | アプリケーション | タイプ | 値 | 設定済みの値 | 実行点 | アドレス | コメント |
|--|--------------------|-------|-------|--------|--------------|------|------------|
| MC_PRG.xPowerOn | Device.Application | BOOL | FALSE | | サイクリックモニタリング | | |
| MC_PRG.xHomeOn | Device.Application | BOOL | FALSE | | サイクリックモニタリング | | |
| MC_PRG.xMoveOn | Device.Application | BOOL | FALSE | | サイクリックモニタリング | | |
| MC_PRG.PG_ReadStatus_0.AbsoluteCounter | Device.Application | LREAL | 0 | | サイクリックモニタリング | | Absolut... |



Column⑭: Feedback counter

The pulse output unit has a function to count pulse signals from external inputs such as encoders.

The number of pulses from external inputs is stored in the feedback counter and can be read using the PG_ReadStatus instruction. Stepping motor step-out can be detected by comparing feedback values with the elapsed values of pulse output.





Column ⑮: How to separate tabs

Each tab of the main view can be separately displayed by dragging and dropping it.

| 式 | タイプ | 値 | 設定済みの値 | アドレス | コメント |
|----------------------|--------------|-------------------|--------|------|-----------------|
| nDirection | MC_DIRECTION | negative | | | Parameter numbe |
| fScalefactor | LREAL | 8388608 | | | Parameter numbe |
| fFactorVel | LREAL | 8388608 | | | Parameter numbe |
| fFactorAcc | LREAL | 8388608 | | | Parameter numbe |
| fFactorTor | LREAL | 6250 | | | Parameter numbe |
| fFactorJerk | LREAL | 8388608 | | | Factor jerk |
| fFactorCur | LREAL | 1 | | | Parameter numbe |
| iMovementType | INT | 1 | | | Parameter numbe |
| fPositionPeriod | LREAL | 360 | | | Parameter numbe |
| eRampType | SMC_RAMPTYPE | trapez | | | Parameter numbe |
| byControllerMode | BYTE | 3 | | | Parameter numbe |
| byRealControllerMode | BYTE | 3 | | | Parameter numbe |
| fSetPosition | LREAL | 300 | | | Parameter numbe |
| fActPosition | LREAL | 300.0000002384... | | | Parameter numbe |
| fAimPosition | LREAL | 300 | | | Parameter numbe |
| fMarkPosition | LREAL | 300 | | | Parameter numbe |
| fSavePosition | LREAL | 300 | | | Parameter numbe |
| fSetVelocity | LREAL | 0 | | | Parameter numbe |
| fActVelocity | LREAL | 0.000238418579... | | | Parameter numbe |
| fMaxVelocity | LREAL | 0 | | | Maximum velocit |
| fSWMaxVelocity | LREAL | 5 | | | Maximum velocit |
| bConstantVelocity | BOOL | TRUE | | | Parameter numbe |
| fMarkVelocity | LREAL | 0 | | | Parameter numbe |

| 式 | タイプ | 値 |
|-------------------|-----------------|-------|
| ETC_CO_SdoWrite_0 | ETC_CO_SdoWrite | |
| wWrite | BOOL | FALSE |
| usiCom | USINT | 0 |
| uiDevice | UINT | 0 |
| wIndexWrite | WORD | 0 |
| byIndexWrite | BYTE | 0 |
| udiTmOut | UDINT | 0 |


| 式 | タイプ | 値 | 設定済みの値 |
|----------------------|--------------|-------------------|--------|
| fFactorVel | LREAL | 8388608 | |
| fFactorAcc | LREAL | 8388608 | |
| fFactorTor | LREAL | 6250 | |
| fFactorJerk | LREAL | 8388608 | |
| fFactorCur | LREAL | 1 | |
| iMovementType | INT | 1 | |
| fPositionPeriod | LREAL | 360 | |
| eRampType | SMC_RAMPTYPE | trapez | |
| byControllerMode | BYTE | 3 | |
| byRealControllerMode | BYTE | 3 | |
| fSetPosition | LREAL | 300 | |
| fActPosition | LREAL | 300.0000004768... | |
| fAimPosition | LREAL | 300 | |
| fMarkPosition | LREAL | 300 | |
| fSavePosition | LREAL | 300 | |
| fSetVelocity | LREAL | 0 | |
| fActVelocity | LREAL | 0.000119209289... | |
| fMaxVelocity | LREAL | 0 | |
| fSWMaxVelocity | LREAL | 5 | |
| bConstantVelocity | BOOL | TRUE | |
| fMarkVelocity | LREAL | 0 | |
| fSaveVelocity | LREAL | 0 | |

4.3 Adding Trace

The trace function allows the variable value histories in the GM1 controller to be checked in GM Programmer.

Step 1

Double-click **Trace**.




Step 2

Register variables to be traced. You can register and trace global variables and variables within function blocks.

Clicking **Add Variable** on the top right of the **Trace** window displays the **Trace Configuration** dialog box.

Click **...** on the right side of the **Variable** field to display the **Input Assistant** dialog box.

* **!** indicates required input items. "Variable" is a required input item.







Column ⑩: Adding objects (trace)


Right-click **Application** and select **Add Object** and then **Trace**.

The **Add Trace** dialog box will be displayed. Enter a trace name and click **Add**.




Step 3

In the **Input Assistant** window, select a variable to be traced and click **OK**, as below.
Select **Application**, **MC_PRG**, **PG_ReadStatus_0**, and then **AbsoluteCounter**.




Step 4

Click **OK**.




Step 5

Clicking **Configuration** on the top right of the **Trace** window displays the **Trace Configuration** dialog box. Open the drop-down list of **Task** (required input item) and select **MotionTask**.



Step 6

When a task is selected, **Resolution** becomes a required input item. Open the drop-down list of **Resolution** and select **µs**.



INFO


| | |
|-------------------|--|
| Task | When tracing a variable related to motion control, select MotionTask . |
| Resolution | The Motion Task interval is 1 ms. Therefore, if ms (default) is selected in the Resolution drop-down list, a caution message will be output, indicating that sampling resolution is too coarse. As a guide, sampling resolution should be half the interval. |

Step 7

After selecting resolution, click **Advanced**.

Change the setting of **Trace editor buffer size per variable (samples)** to 100000.

Trace editor buffer size per variable (samples): Data display area viewed from the horizontal axis (time) of the **Trace** window



When **Trace editor buffer size per variable (samples)** is set to 100000, the buffer size becomes 50 times the recommended runtime buffer size.

Data equivalent to $2 \text{ s} \times 50 = \text{approx. } 100 \text{ s}$ can be displayed in the **Trace** window.

* This buffer size depends on the PC specifications. Therefore, note that if too large buffer size is set, the tool behavior will become sluggish.

INFO

| | |
|--|---|
| Measure in every n-th cycle | Measurement interval = Set task interval |
| Recommended runtime buffer size (samples) | Number of buffers required for the recommended runtime (2 s) To collect trace data precisely, set Measure in every n-th cycle to 1 (measurement at every task interval) and prepare buffers equivalent to the recommended size. |
| Override runtime buffer size | Specifies the size of data to be overwritten in the number of buffers that is specified above Check box cleared: Leaves histories intact without overwriting data Check box selected: Leaves the amount of data that is specified in the override specification field on the right side |
| Trace editor buffer size per variable (samples) | Data display area viewed from the horizontal axis (time) of the Trace window |

Step 8

Set xPowerON registered in Watch to TRUE to execute servo ON.

Change the value in the **Prepared value** column to **<TRUE>** and write the setting by pressing the Ctrl+F7 keys.


| 式 | アプリケーション | タイプ | 値 | 設定済みの値 |
|--|--------------------|-------|-------|--------|
| MC_PRG.xPowerOn | Device.Application | BOOL | FALSE | TRUE |
| MC_PRG.xHomeOn | Device.Application | BOOL | FALSE | |
| MC_PRG.xMoveOn | Device.Application | BOOL | FALSE | |
| MC_PRG.PG_ReadStatus_0.AbsoluteCounter | Device.Application | LREAL | 0 | |

Step 9


Next, change the setting of xHomeOn to TRUE.

Step 10

Before checking trace operation, right-click in the **Trace** window. Select **Download Trace**.




When **Download Trace** is selected, waveforms are displayed.



Step 11


Write **<TRUE>** to xMove registered in Watch 1.

Check that MC_PRG.PG_ReadStatus_0.AbsoluteCounter registered in Watch 1 during positioning operation contains the current value.



Step 12


After positioning operation is complete, right-click in the **Trace** window and select **Stop Trace**.




- Operation ①: The object moves from the home position to target position ① (5000) (Absolute positioning)
- Operation ②: The object moves from target position ① (5000) to target position ② (15000) (Relative positioning)
- Operation ③: The object moves from target position ② (15000) to target position ③ (12000) (Relative positioning)

INFO

By right-clicking in the **Trace** window and selecting **Save Trace**, you can save data in XML, text, or CSV format.



Selecting **Trace file (.trace)** saves the trace setting environment and data without making any changes. This function is convenient when you perform operation checks on devices in remote locations, for example.




Analog I/O Unit


Installation Overview

- Operation images

In this textbook, the analog values output from the GM1 analog output unit are imported into the GM1 input unit. CH0 in each unit uses voltage output and voltage input.



- Setup flow



● Unit types

| Name | Specifications | Product number |
|------------------------|----------------|----------------|
| GM1 Analog Input Unit | Input 8ch | AGM1AD8 |
| GM1 Analog Output Unit | Output 4ch | AGM1DA4 |

INFO

■ Optional functions

Analog input unit


| Function | Specifications |
|---|---|
| Average processing settings function | Selects average processing for the analog values captured by sampling |
| Offset / Gain processing function | Adjusts and corrects offset values (addition correction) or gain values (magnification correction) |
| Scale conversion function | Converts the scale of converted values to an easy-to-handle data range |
| Upper limit / lower limit comparison function | Compares acquired analog input data with the preset upper limit and lower limit values |
| Max./Min. hold function | Holds the maximum and minimum values of acquired data |
| Disconnection detection function | Sets the disconnection detection status to ON to warn of an error state when input is disconnected or unconnected |

Analog output unit

| Function | Specifications |
|--|--|
| Offset / Gain processing function | Adjusts and corrects offset values (addition correction) or gain values (magnification correction) |
| Scale conversion function | Sets the analog output range to any easy-to-handle range |
| Clipping function | Sets the upper limit and lower limit to analog output values in advance |
| Analog output hold function in STOP mode | Holds the analog output when the operation mode of the GM1 controller changes from RUN to STOP |

Analog output unit

- Basic analog output operations



(1) Writing digital data

A user program is used to write digital data to the variable that corresponds to the "Ch*_OutputValue" channel in the analog output unit. The analog signal to be converted changes with the setting of the range.

(2) Analog conversion processing

The data written to the variable is automatically converted to analog signals sequentially inside the unit.


(3) Output to analog-driven device

Converted analog signals are output to analog-driven devices such as inverters.

- Timing chart of output processing

- The "Ch0 output value" written to the GM1 controller is imported into the analog output unit at the time of I/O refresh.

- The analog output unit converts the latest data imported from the GM1 controller into analog values and outputs the converted values.




(Note 1) The processing time of the analog output unit is 50 µs, regardless of the number of valid channels.

(Note 2) The unit outputs converted values when all processing is completed for CH0 to CH3.

Analog input unit

• Basic analog input operations



(1) Importing analog input signals

Analog input signals from analog devices such as laser analog sensors and pressure sensors are imported into the input section of the analog input unit.

(2) Digital conversion processing

Analog input signals imported into the unit are automatically converted to digital values sequentially inside the unit.

(3) Storing digital values


The converted digital values are stored in the channel next to "Analog_8IN I/O Mapping". The asterisk "*" below represents the channel number. (0 to 7)

| | |
|---------------------|---|
| Channel | |
| Ch*_InputValue | Stores a value before Offset / Gain processing and scale conversion |
| Ch*_ConversionValue | Stores a value after Offset / Gain processing and scale conversion |

• Timing chart of input processing

- The data converted by the analog input unit is imported into the GM1 controller at the time of I/O refresh.
- When the GM1 controller performs an I/O refresh, the latest data is written to the "Ch0 input value" in the GM1 controller.

For one channel worth of data (Conversion processing time: 50 μs)



INFO

The conversion processing time differs according to the settings of "Unit-specific configuration setting" for the Analog_8IN parameter.

Select **Not Execute** or **Execute** for **ConversionProcess** on a channel-by-channel basis.

This can save the conversion time for channels that do not execute conversion processing. The conversion time per channel is 50 μs.

Example: Conversion time for one channel (when channels other than CH0 are set to "Disable")

Data for only Ch0 is converted repeatedly. 1 cycle = 50 μs


1 Basic Setup

1.1 Preparing and Wiring the Required Devices

Prepare the following devices.

| No. | Name |
|-----|-----------------------------------|
| (1) | GM1 controller x 1 (RTEX type) |
| (2) | GM1 analog input unit |
| (3) | GM1 analog output unit |
| (4) | PC (with GM Programmer installed) |
| (5) | LAN cable: x 1 |

Wire each device as shown below.



The terminals used when the output range is set to voltage output are different from those used when it is set to current output.

- For voltage output: Vn
- For current output: In

"n" indicates a channel number. (0 to 3)

Common terminals are used for analog voltage input and analog current input.

1.2 IP Address Setting to Network Scanning

Step 1

Open GM Programmer and double-click **Device**.

Select **PLC Parameters** and check the IP address of LAN port 1.

| Parameter | Type | Value | Default Value |
|------------------------|---------------------|--------------------|--------------------|
| A unit error occurred | Enumeration of BYTE | Continue operation | Continue operation |
| Network setting | | | |
| LAN port1 | | | |
| IP Address | STRING | '192.168.1.5' | '192.168.1.5' |
| Subnet Mask | STRING | '255.255.255.0' | '255.255.255.0' |
| Default Gateway | STRING | '192.168.1.1' | '192.168.1.1' |
| LAN port2 | | | |
| IP Address | STRING | '192.168.2.5' | '192.168.2.5' |
| Subnet Mask | STRING | '255.255.255.0' | '255.255.255.0' |
| Default Gateway | STRING | '0.0.0.0' | '0.0.0.0' |

LAN port 1 (default value)

| | |
|-----------------|---------------|
| IP address | 192.168.1.5 |
| Subnet mask | 255.255.255.0 |
| Default gateway | 192.168.1.1 |

Step 2

Select **Communication Settings** and click **Scan Network**.

Step 3

Select a device to be connected and click **OK**.


2 I/O Unit Setup

2.1 Adding I/O Units

First, add a device object for the I/O unit to the project.


Step 1

Select **Device** and then **Unit_Configuration**, right-click **Empty1**, and select **Unit Management**.




Step 2

The **Unit Management** dialog box will be displayed.
Double-click on the No. 1 row.




Step 3

The **Select Device** dialog box will be displayed. Select an expansion unit to be added.
In this textbook, the GM1 controller, analog output unit (AGM1DA4), and analog input unit (AGM1AD8) are arranged in this order from left to right. For this reason, register AGM1DA4 in the No. 1 row.




AGM1DA4 has been registered in the No. 1 row, as below.



Step 4

Register AGM1AD8 in the No. 2 row in the same way as above.


When registration is completed, click **OK**.



Check that AGM1DA4 and AGM1AD8 have been registered as shown in the figure to the right.

Empty1 → Slot1_Analog_4OUT (AGM1DA4)

Empty2 → Slot2_Analog_8IN (AGM1AD8)




2.2 Setting up the Analog Output Unit (AGM1DA4)

Set up parameters for the analog output unit and register I/O mapping.

Step 1


Double-click **Slot1_Analog_4OUT (AGM1DA4)**, which has been registered previously.



Step 2


Select **Analog_4OUT Parameter** and then **Ch0_Unit specific configuration settings**.

In **Parameter Setting (R)**, select **-10 ~ +10V** (default value) in **RangeSetting**.



INFO

Voltage output range: -10 to +10 V (Resolution: 1/64,000)



| Digital input value | Analog output value (V) |
|---------------------|-------------------------|
| +32000 | +10 |
| +25600 | +8 |
| +19200 | +6 |
| +12800 | +4 |
| +6400 | +2 |
| 0 | 0 |
| - 6400 | - 2 |
| - 12800 | - 4 |
| - 19200 | - 6 |
| - 25600 | - 8 |
| - 32000 | - 10 |

When the rated range is exceeded


| Digital input value | Analog output value (V) |
|---------------------|-------------------------|
| +32640 or more | +10.2 |
| -32640 or less | - 10.2 |

2.3 Setting up the Analog Input Unit (AGM1AD8)

Set up parameters for the analog input unit and register I/O mapping.

Step 1


Double-click **Slot2_Analog_8IN (AGM1AD8)**, which has been registered previously.



Step 2


Select **Analog_8IN Parameter** and then **Ch0_Unit specific configuration settings**.

In **Parameter Setting (R)**, select **-10 ~ +10V** (default value) in **RangeSetting**.



INFO

Voltage output range: -10 to +10 V (Resolution: 1/64,000)



| Analog input value (V) | Digital converted value |
|------------------------|-------------------------|
| +10 | +32000 |
| +8 | +25600 |
| +6 | +19200 |
| +4 | +12800 |
| +2 | +6400 |
| 0 | 0 |
| -2 | -6400 |
| -4 | -12800 |
| -6 | -19200 |
| -8 | -25600 |
| -10 | -32000 |

When the rated range is exceeded


| Analog input value | Digital converted value |
|--------------------|-------------------------|
| +10.2 V or more | +32640 or more |
| -10.2 V or less | -32640 or less |

3 Programming

3.1 Adding New POU

Step 1


Right-click **Application** and select **Add Object** and then **POU** to create a new POU.




Step 2

In the **Add POU** dialog box, specify settings as below and click **Add**.

| | |
|--------------------------------|-----------------------------|
| Name | Analog_PRG |
| Type | Program |
| Implementation language | Structured Text (ST) |




Analog_PRG (PRG) will be added to **Application**.




Step 3

Right-click **2.User** and select **Add Object** and then **UserTask**.




Step 4

The **Add UserTask** dialog box will be displayed. Leave **UserTask01** (default) unchanged in the **Name(N)** field and click **Add**.




UserTask01 will be added.



Step 5

Drag and drop **Analog_PRG (PRG)** into the **UserTask01** object, which has been added, to add it to the task.



Column ⑥: Tasks

| Task | Description |
|------------|--|
| MotionTask | This is a user program task to perform motion control. It is given the highest priority. Only one MotionTask is allowed for each project. |
| UserTask | This is a user program task to perform control other than motion control. The user can set the level of priority. Up to 50 tasks can be registered in a single project. |
| SystemTask | This is a task that is used by the system and cannot be added by user programs. It is processed while other tasks are inactive. |


3.2 Programming

First, programming for the analog input unit (AGM1DA4) is explained.

Step 1

Open the **Analog_PRG** tab and add local variables as below.

| Name | Data type |
|------------------|-----------|
| iOutputValue | INT |
| iCh0_OutputValue | INT |



Step 2


Using the variables registered in Step 1 above, code a program as below.

```
1 iCh0_OutputValue := iOutputValue;
```

Step 3







In **Analog_4OUT I/O Mapping**, link iCh0_OutputValue to the corresponding channel, as below.

Double-click **Slot1_Analog_4OUT (AGM1DA4)** and open the **Analog_4OUT I/O Mapping** tab.









Step 4

Expand **OutputArea_t** through to **Ch0_OutputArea** by clicking .

| Variable | Mapping | Channel | Address | Type |
|---|---------|---------------------|---------|------|
|  | | InputArea_t | %IW32 | |
|  | | OutputArea_t | %QD14 | |
|  | | Ch0_OutputArea | %QW30 | |
|  | | Ch0_OutputValue | %QW30 | INT |
|  | | Ch0_RequestRegister | %QW31 | WORD |
|  | | Ch1_OutputArea | %QW32 | |

Step 5


Double-click in the empty row corresponding to **Ch0_OutputValue** and then click .

| Variable | Mapping | Channel | Address | Type |
|---|---------|---------------------|---------|------|
|  | | InputArea_t | %IW32 | |
|  | | OutputArea_t | %QD14 | |
|  | | Ch0_OutputArea | %QW30 | |
|  | | Ch0_OutputValue | %QW30 | INT |
|  | | Ch0_RequestRegister | %QW31 | WORD |
|  | | Ch1_OutputArea | %QW32 | |

Step 6

The **Input Assistant** dialog box will be displayed.

Select **Application**, **Analog_PRG**, and then **iCh0_OutputValue**.



Input Assistant

Text Search Categories

Variables

| Name | Type | Address | Origin |
|-------------------------|-------------|----------------------|--------|
| Application | Application | | |
| Analog_PRG | PROGRAM | | |
| iCh0_OutputValue | INT | | |
| iOutputValue | INT | | |
| COM | Library | CAA SerialCom, 3.5 | |
| FILE | Library | CAA File, 3.5.15.0 | |
| SM3_Basic | Library | SM3_Basic, 4.6.1.0 | |
| IoDrvEthernet | Library | IoDrvEthernet, 3.5 | |
| NBS | Library | CAA Net Base Servi | |
| SM3_Math | Library | SM3_Math, 4.6.2.0 | |
| Util | Library | Util, 3.5.15.0 (Syst | |
| IoConfig_Globals | VAR_GLOBAL | | |

Structured view Filter: None

Insert with arguments Insert with namespace prefix

Documentation

```
iCh0_OutputValue: INT;  
(VAR)
```

OK Cancel

iCh0_OutputValue will be linked to the corresponding channel.

| Variable | Mapping | Channel | Address | Type |
|---|---------|---------------------|---------|------|
| | | InputArea_t | %IW32 | |
| | | OutputArea_t | %QD14 | |
| | | Ch0_OutputArea | %QW30 | |
| Application.Analog_PRG.iCh0_OutputValue | | Ch0_OutputValue | %QW30 | INT |
| | | Ch0_RequestRegister | %QW31 | WORD |
| | | Ch1_OutputArea | %QW32 | |

Next, programming for the analog output unit (AGM1AD8) is explained.

Step 1

Double-click **Analog_PRG** to open the program that has been created previously.
Add variables as below.

| Name | Data type |
|----------------------|-----------|
| iLocal | INT |
| iCh0_ConversionValue | INT |

| Scope | Name | Address | Data type |
|-------|---------------------------------|---------|-----------|
| 1 | VAR iOutputValue | | INT |
| 2 | VAR iCh0_OutputValue | | INT |
| 3 | VAR iLocal | | INT |
| 4 | VAR iCh0_ConversionValue | | INT |

Step 2

Using the variables registered in Step 1 above, code a program as below.


```

1  iCh0_OutputValue := iOutputValue;
2  iLocal := iCh0_ConversionValue;

```


Step 3

In **Analog_8IN I/O Mapping**, link iCh0_ConversionValue to the corresponding channel, as below.
 Double-click **Slot2_Analog_8IN (AGM1AD8)** and open the **Analog_8IN I/O Mapping** tab.



Step 4

Expand **InputArea_t** through to **Ch1_InputArea** by clicking **+**.

| Variable | Mapping | Channel | Address | Type |
|----------|---------|---------------------|---------|------|
| | | InputArea_t | %IW40 | |
| | | Ch0_InputArea | %IW40 | |
| | | Ch0_InputValue | %IW40 | INT |
| | | Ch0_ConversionValue | %IW41 | INT |
| | | Ch0_MaxHoldingValue | %IW42 | INT |
| | | Ch0_MinHoldingValue | %IW43 | INT |
| | | Ch0_StatusRegister | %IW44 | WORD |
| | | Ch1_InputArea | %IW46 | |

Step 5


Double-click in the empty row corresponding to **Ch0_ConversionValue** and then click **...**.

| Variable | Mapping | Channel | Address | Type |
|----------|---------|---------------------|---------|------|
| | | InputArea_t | %IW40 | |
| | | Ch0_InputArea | %IW40 | |
| | | Ch0_InputValue | %IW40 | INT |
| | | Ch0_ConversionValue | %IW41 | INT |
| | | Ch0_MaxHoldingValue | %IW42 | INT |
| | | Ch0_MinHoldingValue | %IW43 | INT |
| | | Ch0_StatusRegister | %IW44 | WORD |

Step 6

The **Input Assistant** dialog box will be displayed.

Select **Application**, **Analog_PRG**, and then **iCh0_ConversionValue**.




iCh0_ConversionValue will be linked to the corresponding channel.

| Variable | Mapping | Channel | Address | Type |
|--|---------|----------------------------|--------------|------------|
| | | InputArea_t | %IW40 | |
| | | Ch0_InputArea | %IW40 | |
| | | Ch0_InputValue | %IW40 | INT |
| Application.Analog_PRG.iCh0_ConversionValue | | Ch0_ConversionValue | %IW41 | INT |
| | | Ch0_MaxHoldingValue | %IW42 | INT |
| | | Ch0_MinHoldingValue | %IW43 | INT |
| | | Ch0_StatusRegister | %IW44 | WORD |

4 Communication Operation Check


Step 1

Right-click **Application** and then select **Login**.




Step 2

Right-click **Application [stop]** and then select **Start** to switch the state from STOP to RUN.



Step 3

Open the **Analog_PRG** tab and then double-click **0** on the right side of **iOutputValue** to open the **Prepare Value** dialog box.



Step 4

Enter 1000 in the **Prepare a new value for the next write or force operation** field and then click **OK**.

Prepare Value

Expression: Analog_PRG.iOutputValue

Type: INT

Current value: 0

What do you want to do?

Prepare a new value for the next write or force operation
1000

Remove preparation with a value.

Release the force, without modifying the value.

Release the force and restore the variable to the value it had before forcing it.

OK Cancel

Step 5

Check that "1000" has been entered only in the **iOutputValue** variable.

In this state, press the Ctrl+F7 keys.

```
1 iCh0_OutputValue 0 := iOutputValue 0 <1000>;  
2 iLocal -3 := iCh0_ConversionValue -3 ;RETURN
```



```
1 iCh0_OutputValue 1000 := iOutputValue 1000 ;  
2 iLocal 996 := iCh0_ConversionValue 996 ;RETURN
```

"1000" will be entered in the **iCh0_OutputValue** variable.

At the same time, "1000" will also be entered in the **iCh0_ConversionValue** variable that has been mapped to the input unit.

In this textbook, **RangeSetting** is set to **-10 ~ +10V** (default value) for both the output unit and input unit. Therefore, if "1000" is entered in the **Prepare a new value for the next write or force operation** field, the output unit will output the corresponding voltage value and the input unit will convert the received voltage value to approximately "1000".

INFO

As shown in the figure above, when "0", "-3", and "1000" are entered, "996" is output. This is based on the specifications of the analog input and output units.

When **RangeSetting** is set to **-10 ~ +10V**, an error occurs within 0.2% of F.S. $\pm 32,000$.

| | |
|----------------|---|
| Total accuracy | $\pm 0.2\% \text{F.S. or less (at } +25^\circ\text{C)}$ $\pm 0.4\% \text{F.S. or less (at 0 to } +55^\circ\text{C)}$ |
|----------------|---|


To avoid this error, use the Offset / Gain processing function.

For details, refer to Section 5.3 or 6.2 in the GM1 Series Reference Manual (Analog I/O Unit Edition).

5 Scale Conversion Function

The scale conversion function can be used in both analog input and output units in the same way. In this textbook, the scale conversion function is enabled in the analog input unit. Check that "+16000" is output and "+5000" is input.

- This function converts the scale of analog input to an easy-to-handle data range.
- Data subjected to scale conversion is stored in the I/O mapping.
- The function can be used for unit conversion, etc.
- Scale conversion processing is executed on a channel-by-channel basis.



Step 1

Double-click **Slot2_Analog_8IN** and open the **Analog_8IN** parameter tab.

Select **Ch0_Unit specific configuration settings** and then **ScaleConversion**, and change the setting from **Not Execute** to **Execute**.

| Parameter | Value |
|------------------------------|-----------------|
| ConversionProcess | Execute |
| RangeSetting | -10 ~ +10V |
| AveragingProcess | No averaging |
| AverageConstant | 200 |
| OffsetGainProcess | Not Execute |
| OffsetValue | 0 |
| GainValue | 10000 |
| ScaleConversion | Not Execute |
| ScaleConversionMaxValue | Not Execute |
| ScaleConversionMinValue | Execute |
| UpperAndLowerLimitComparison | Not Execute |
| UpperLimitComparisonONLevel | 1000 |
| UpperLimitComparisonOFFLevel | 1000 |
| LowerLimitComparisonONLevel | 0 |
| LowerLimitComparisonOFFLevel | 0 |
| MaxMinValueRetention | Not Execute |
| DisconnectionDetection | Not Execute |
| DisconnectionDetectionReset | Automatic Reset |

Step 2

Change the settings as below.

ScaleConversionMaxValue: 10000

ScaleConversionMinValue: -10000

Slot2_Analog_8IN x

Analog_8IN parameter

Analog_8IN I/O Mapping

Status

Information

Category Selection(T)

- Unit specific configuration settings
 - Ch0_Unit specific configuration settings
 - Ch1_Unit specific configuration settings
 - Ch2_Unit specific configuration settings
 - Ch3_Unit specific configuration settings
 - Ch4_Unit specific configuration settings
 - Ch5_Unit specific configuration settings
 - Ch6_Unit specific configuration settings
 - Ch7_Unit specific configuration settings

Parameter Setting (R)

| Parameter | Value |
|------------------------------|-----------------|
| ConversionProcess | Execute |
| RangeSetting | -10 ~ +10V |
| AveragingProcess | No averaging |
| AverageConstant | 200 |
| OffsetGainProcess | Not Execute |
| OffsetValue | 0 |
| GainValue | 10000 |
| ScaleConversion | Execute |
| ScaleConversionMaxValue | 10000 |
| ScaleConversionMinValue | -10000 |
| UpperAndLowerLimitComparison | Not Execute |
| UpperLimitComparisonONLevel | 1000 |
| UpperLimitComparisonOFFLevel | 1000 |
| LowerLimitComparisonONLevel | 0 |
| LowerLimitComparisonOFFLevel | 0 |
| MaxMinValueRetention | Not Execute |
| DisconnectionDetection | Not Execute |
| DisconnectionDetectionReset | Automatic Reset |

Step 3

Right-click **Application** and select **Login**, and then enter 16000 into **iOutputValue** in the program.

```
1 ● iCh0_OutputValue 16000 := iOutputValue 16000 ;
2 ● iLocal 5000 := iCh0_ConversionValue 5000 ; RETURN
```

The output unit outputs +16000, which is equivalent to +5 V.

We can see that the input unit receives +5 V, which is then scale-converted to +5000 for input.


6 Disconnection Detection Function

- This function sets the disconnection detection status to ON to warn of an error state when input is disconnected or unconnected.
- The disconnection detection function operates only in the following ranges.

| Range | Detection level |
|------------|-----------------|
| 1 to 5 V | 0.7 V or less |
| 4 to 20 mA | 2.8 mA or less |


■ Behavior when "Disconnection detection reset" is set to "Auto"

When the input value exceeds the detection level while "Ch* disconnection detection request" is ON, "Ch* disconnection detection status" is automatically set to OFF.



■ Behavior when "Disconnection detection reset" is set to "Manual"

In manual setting mode, when "Ch* disconnection detection request" is set to OFF using the user program, "Ch* disconnection detection status" is set to OFF.



| | |
|-----|---|
| (1) | "Ch* disconnection detection status" is not set to OFF automatically even when the disconnection is restored. |
| (2) | When "Ch* disconnection detection request" is set to OFF, "Ch* disconnection detection status" is set to OFF. |

Step 1

Double-click **Slot2_Analog_8IN** and open the **Analog_8IN** parameter tab.

Select **Ch0_Unit specific configuration settings** and then set the following items.

RangeSetting 1 ~ +5V

DisconnectionDetection: Execute

DisconnectionDetectionReset: Automatic Reset

| Parameter | Value |
|------------------------------|-----------------|
| ConversionProcess | Execute |
| RangeSetting | 1 ~ +5V |
| AveragingProcess | No averaging |
| AverageConstant | 200 |
| OffsetGainProcess | Not Execute |
| OffsetValue | 0 |
| GainValue | 10000 |
| ScaleConversion | Not Execute |
| ScaleConversionMaxValue | 10000 |
| ScaleConversionMinValue | -10000 |
| UpperAndLowerLimitComparison | Not Execute |
| UpperLimitComparisonONLevel | 1000 |
| UpperLimitComparisonOFFLevel | 1000 |
| LowerLimitComparisonONLevel | 0 |
| LowerLimitComparisonOFFLevel | 0 |
| MaxMinValueRetention | Not Execute |
| DisconnectionDetection | Execute |
| DisconnectionDetectionReset | Automatic Reset |

Step 2

Double-click **Slot1_Analog_4OUT** and open the **Analog_4OUT** parameter tab.

Select **Ch0_Unit specific configuration settings** and then set **RangeSetting** to the same value as for analog input, as below.

RangeSetting: 1 ~ +5V

| Parameter | Value |
|---------------------------------------|-------------------------------|
| OutputProcess | Output |
| RangeSetting | 1 ~ +5V |
| AnalogOutputAtStop | Hold with user-specified v... |
| OutputValueAtStop | 0 |
| OffsetGainProcess | No output |
| OffsetValue | 0 |
| GainValue | 10000 |
| ScaleConversion | No output |
| ScaleConversionMaxValue | 10000 |
| ScaleConversionMinValue | 0 |
| UpperAndLowerOutputClipping | No output |
| UpperAndLowerOutputClippingUpperLimit | 0 |
| UpperAndLowerOutputClippingLowerLimit | 0 |

Step 3

Right-click **Application** and select **Login**, and then open the **Analog_8IN I/O Mapping** tab. Expand **Ch0_StatusRegister**. Set **Ch0_Disconnection Detection Request** to **TRUE**.


| Variable | Mapping | Channel | Address | Type | Current Value | Prepared Value | Description |
|--|---------|--|---------|------|---------------|----------------|--|
| InputArea_t | | InputArea_t | %IW40 | | | | Input Area |
| Ch0_InputArea | | Ch0_InputArea | %IW40 | | | | Ch0_Input Area |
| Ch0_InputValue | | Ch0_InputValue | %IW40 | INT | -10 | | Ch0_Analog Input Value |
| Application.Analog_PRG.Ch0_ConversionValue | | Ch0_ConversionValue | %IW41 | INT | -10 | | Ch0_Analog Conversion Value |
| Ch0_MaxHoldingValue | | Ch0_MaxHoldingValue | %IW42 | INT | 0 | | Ch0_Max Holding Value |
| Ch0_MinHoldingValue | | Ch0_MinHoldingValue | %IW43 | INT | 0 | | Ch0_Min Holding Value |
| Ch0_StatusRegister | | Ch0_StatusRegister | %IW44 | WORD | 0 | | Ch0_Status Register |
| Ch0_DisconnectionDetectionStatus | | Ch0_DisconnectionDetectionStatus | %DX88.0 | BOOL | FALSE | | Ch0_Disconnection Detection Status |
| Ch0_UpperLimitComparisonStatus | | Ch0_UpperLimitComparisonStatus | %DX88.1 | BOOL | FALSE | | Ch0_Upper Limit Comparison Status |
| Ch0_LowerLimitComparisonStatus | | Ch0_LowerLimitComparisonStatus | %DX88.2 | BOOL | FALSE | | Ch0_Lower Limit Comparison Status |
| Ch0_UpperLowerLimitComparisonStatus | | Ch0_UpperLowerLimitComparisonStatus | %DX88.3 | BOOL | FALSE | | Ch0_Upper/Lower Limit Value Comparison Status |
| Ch0_MaxMinHoldingStatus | | Ch0_MaxMinHoldingStatus | %DX88.4 | BOOL | FALSE | | Ch0_Max/Min Holding Value Request |
| Ch0_SettingErrorStatus | | Ch0_SettingErrorStatus | %DX88.5 | BOOL | FALSE | | Ch0_Error Status |
| Ch1_InputArea | | Ch1_InputArea | %IW46 | | | | Ch1_Input Area |
| Ch2_InputArea | | Ch2_InputArea | %IW52 | | | | Ch2_Input Area |
| Ch3_InputArea | | Ch3_InputArea | %IW58 | | | | Ch3_Input Area |
| Ch4_InputArea | | Ch4_InputArea | %IW64 | | | | Ch4_Input Area |
| Ch5_InputArea | | Ch5_InputArea | %IW70 | | | | Ch5_Input Area |
| Ch6_InputArea | | Ch6_InputArea | %IW76 | | | | Ch6_Input Area |
| Ch7_InputArea | | Ch7_InputArea | %IW82 | | | | Ch7_Input Area |
| OutputArea_t | | OutputArea_t | %QD19 | | | | Output Area |
| Ch0_RequestRegister | | Ch0_RequestRegister | %QW40 | WORD | 0 | | Ch0_Request Register |
| Ch0_DisconnectionDetectionExecutionRequest | | Ch0_DisconnectionDetectionExecutionRequest | %QX80.0 | BOOL | FALSE | TRUE | Ch0_Disconnection Detection Request |
| Ch0_UpperLowerLimitComparisonRequest | | Ch0_UpperLowerLimitComparisonRequest | %QX80.1 | BOOL | FALSE | | Ch0_Upper/Lower Limit Value Comparison Request |
| Ch0_MaxMinHoldingRequest | | Ch0_MaxMinHoldingRequest | %QX80.2 | BOOL | FALSE | | Ch0_Max/Min Holding Value Request |

Step 4

Disconnect the connector from the input unit while checking the value in the **Current Value** column corresponding to **Ch0_InputValue**.

As soon as "-640" (equivalent to 0.7 V or less) is entered, **Ch0_DisconnectionDetectionStatus** is set to **TRUE**.

Because **DisconnectionDetectionReset** is set to **Automatic Reset**, **Ch0_DisconnectionDetectionStatus** is set to **FALSE** when the connector is reconnected.



| Variable | Mapping | Channel | Address | Type | Current Value | Prepared Value | Description |
|--|---------|--|---------|------|---------------|----------------|--|
| InputArea_t | | InputArea_t | %IW40 | | | | Input Area |
| Ch0_InputArea | | Ch0_InputArea | %IW40 | | | | Ch0_Input Area |
| Ch0_InputValue | | Ch0_InputValue | %IW40 | INT | -640 | | Ch0_Analog Input Value |
| Application.Analog_PRG.Ch0_ConversionValue | | Ch0_ConversionValue | %IW41 | INT | -640 | | Ch0_Analog Conversion Value |
| Ch0_MaxHoldingValue | | Ch0_MaxHoldingValue | %IW42 | INT | 0 | | Ch0_Max Holding Value |
| Ch0_MinHoldingValue | | Ch0_MinHoldingValue | %IW43 | INT | 0 | | Ch0_Min Holding Value |
| Ch0_StatusRegister | | Ch0_StatusRegister | %IW44 | WORD | 1 | | Ch0_Status Register |
| Ch0_DisconnectionDetectionStatus | | Ch0_DisconnectionDetectionStatus | %DX88.0 | BOOL | TRUE | | Ch0_Disconnection Detection Status |
| Ch0_UpperLimitComparisonStatus | | Ch0_UpperLimitComparisonStatus | %DX88.1 | BOOL | FALSE | | Ch0_Upper Limit Comparison Status |
| Ch0_LowerLimitComparisonStatus | | Ch0_LowerLimitComparisonStatus | %DX88.2 | BOOL | FALSE | | Ch0_Lower Limit Comparison Status |
| Ch0_UpperLowerLimitComparisonStatus | | Ch0_UpperLowerLimitComparisonStatus | %DX88.3 | BOOL | FALSE | | Ch0_Upper/Lower Limit Value Comparison Status |
| Ch0_MaxMinHoldingStatus | | Ch0_MaxMinHoldingStatus | %DX88.4 | BOOL | FALSE | | Ch0_Max/Min Holding Value Request |
| Ch0_SettingErrorStatus | | Ch0_SettingErrorStatus | %DX88.5 | BOOL | FALSE | | Ch0_Error Status |
| Ch1_InputArea | | Ch1_InputArea | %IW46 | | | | Ch1_Input Area |
| Ch2_InputArea | | Ch2_InputArea | %IW52 | | | | Ch2_Input Area |
| Ch3_InputArea | | Ch3_InputArea | %IW58 | | | | Ch3_Input Area |
| Ch4_InputArea | | Ch4_InputArea | %IW64 | | | | Ch4_Input Area |
| Ch5_InputArea | | Ch5_InputArea | %IW70 | | | | Ch5_Input Area |
| Ch6_InputArea | | Ch6_InputArea | %IW76 | | | | Ch6_Input Area |
| Ch7_InputArea | | Ch7_InputArea | %IW82 | | | | Ch7_Input Area |
| OutputArea_t | | OutputArea_t | %QD19 | | | | Output Area |
| Ch0_RequestRegister | | Ch0_RequestRegister | %QW40 | WORD | 1 | | Ch0_Request Register |
| Ch0_DisconnectionDetectionExecutionRequest | | Ch0_DisconnectionDetectionExecutionRequest | %QX80.0 | BOOL | TRUE | | Ch0_Disconnection Detection Request |
| Ch0_UpperLowerLimitComparisonRequest | | Ch0_UpperLowerLimitComparisonRequest | %QX80.1 | BOOL | FALSE | | Ch0_Upper/Lower Limit Value Comparison Request |
| Ch0_MaxMinHoldingRequest | | Ch0_MaxMinHoldingRequest | %QX80.2 | BOOL | FALSE | | Ch0_Max/Min Holding Value Request |

7 Analog Output Hold Function in STOP Mode

This function holds the analog output when the operation mode of the GM1 controller changes from RUN to STOP.

- Analog output hold settings are configured on a channel-by-channel basis.
- "Hold at any value" or "Hold at current value" can be selected for the analog output value for each channel.

INFO

- If "Hold at any value" is selected, the analog signal to be output differs according to the value of **RangeSetting**.
- When an error occurs, the output is turned OFF (0 V or 0 mA).

Step 1

Double-click **Slot1_Analog_4OUT** and open the **Analog_4OUT parameter** tab.
Select **Ch0_Unit specific configuration settings** and then set the following item.

AnalogOutputAtStop: Hold at current value


| Parameter | Value |
|---------------------------------------|-----------------------|
| OutputProcess | Output |
| RangeSetting | 1 ~ +5V |
| AnalogOutputAtStop | Hold at current value |
| OutputValueAtStop | 0 |
| OffsetGainProcess | No output |
| OffsetValue | 0 |
| GainValue | 10000 |
| ScaleConversion | No output |
| ScaleConversionMaxValue | 10000 |
| ScaleConversionMinValue | 0 |
| UpperAndLowerOutputClipping | No output |
| UpperAndLowerOutputClippingUpperLimit | 0 |
| UpperAndLowerOutputClippingLowerLimit | 0 |

Step 2

Right-click **Application** and select **Login**, and then open the **Analog_PRG** tab.
Enter "1000" into **iOutputValue** and check that "1000" has been input into **iCh0_OutputValue**.

```
1 iCh0_OutputValue 1000 := iOutputValue 1000 ;  
2 iLocal 992 := iCh0_ConversionValue 992 ; RETURN
```

Step 3

In this state, switch the RUN/STOP selector switch on the GM1 controller to STOP. 
Check that "1000", which is the value (current value) displayed before the switch was switched to STOP, is maintained as the output value.

```
1 iCh0_OutputValue 1000 := iOutputValue 1000 ;  
2 iLocal 992 := iCh0_ConversionValue 992 ; RETURN
```

Memo

Revision History

| Date of issue | Manual code | Revision details |
|---------------|-------------|------------------|
| April 2022 | AIM0013_01 | First edition |

Panasonic Industry Co., Ltd.

7-1-1 Morofuku, Daito City, Osaka, 574-0044, Japan

Industrial. Panasonic.com/ac/e

© Panasonic Industry Co., Ltd 2022

April 2022